


2015 PARTS CATALOG

 **TOHATSU**



BFT 200A
BFT 225A

OB NO.002-14ZY2-1
1411US

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of October 1, 2014.**
- See the Service Bulletin for any revision that is made after October 1, 2014.
- **Always specify the part number when ordering a part.**
 - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
 - Note that the illustrations (part drawings) can differ from the actual parts in shape.
Illustrations are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.**

Initial version issue date October 1, 2014

CONTENTS

E-1	CYLINDER HEAD COVER	1
E-3	CYLINDER BLOCK	3
E-3-10	CRANKCASE	7
E-4	EXHAUST MANIFOLD/THERMOSTAT	9
E-5	OIL PUMP/FLYWHEEL	11
E-6	OIL PAN	13
E-6-10	MOUNT CASE	15
E-7	CRANKSHAFT/PISTON	19
E-9	CYLINDER HEAD	23
E-9-10	CAMSHAFT/ROCKER ARM	25
E-13	TIMING BELT	27
E-13-10	TIMING BELT COVER	29
E-14	FUEL PIPE/INJECTOR	31
E-14-10	INTAKE MANIFOLD	35
E-15	THROTTLE BODY	37
E-18	VAPOR SEPARATOR ASSY	39
E-18-2	WATER SEPARATOR/FUEL STRAINER	43
E-18-10	PIPING	47
E-19	A.C.GENERATOR	49
E-20	SPARK PLUG	51
E-20-11	ELECTRONIC CONTROL UNIT	53
E-21	STARTER MOTOR	55
F-2	SHIFT SHAFT	57
F-3	GEAR CASE	61
F-3-10	GEAR CASE ASSY	63
F-3-20	EXTENSION CASE	65
F-4	WATER PUMP/VERTICAL SHAFT	71
F-5	PROPELLER SHAFT	75
F-5-1	PROPELLER SHAFT (COUNTER ROTATION)	79
F-6	FUEL TUBE	83
F-7	WIRE HARNESS	85
F-7-11	STARTER CABLE	87
F-7-30	FUSE BOX/RELAY	89
F-8	ENGINE COVER	91
F-8-10	FR.COVER BRACKET/FR.LOCK SHAFT	93
F-8-20	FUEL TUBE (2)	97
F-10	STERN BRACKET/SWIVEL CASE	99
F-11	POWER TRIM-TILT	105
F-12	LABEL	109
F-13	TOOL	111
FOP-2	WATER PUMP IMPELLER SET	113
FOP-3	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)	115
FOP-3-2	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)	119
FOP-3-4	REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)	123
FOP-3-6	REMOTE CONTROL	125
FOP-4	SWITCH PANEL KIT (1)	131
FOP-4-1	SWITCH PANEL KIT (2)	135
FOP-5-1	METER	137
FOP-7	BOLT KIT	139
FOP-9	TRIM ADJUST PLATE SET	141
FOP-10	PROPELLER	143
FOP-12	INTERFACE CABLE KIT	145
INDEX		147
INDEX (Parts Number)		153

E-1 CYLINDER HEAD COVER	E-2 CYLINDER BLOCK	E-3-10 CRANKCASE
E-4 EXHAUST MANIFOLD/THERMOSTAT	E-5 OIL PUMP/FLYWHEEL	E-6 OIL PAN

E-14-10 INTAKE MANIFOLD



		Q' ty	
m	m		

A diagram of a horizontal beam supported by two triangular supports. A downward-pointing arrow is located at the center of the beam, representing a load.

INDEX (Parts Number)

90-00110-0	15-55	90-00400-0	15-28	90-04515-1	15-28
90-00117-0	6-7	90-04040-1	15-28-24	90-04581-1	11-6-10
90-00120-0	15-55	90-04040-2	15-28-24	90-04581-2	11-6-10
90-00570-0	8-11	90-04125-0	15-28-24	90-04800-0	6-7-5
90-00570-1	8-11	90-04125-1	15-28-24	90-04800-1	6-7-5
90-00570-2	8-11	90-04125-2	15-28-24	90-04800-2	6-7-5
90-00570-3	8-11	90-04125-3	15-28-24	90-04800-3	6-7-5
90-00570-4	8-11	90-04125-4	15-28-24	90-04800-4	6-7-5
90-00570-5	8-11	90-04125-5	15-28-24	90-04800-5	6-7-5
90-00570-6	8-11	90-04125-6	15-28-24	90-04800-6	6-7-5
90-00570-7	8-11	90-04125-7	15-28-24	90-04800-7	6-7-5
90-00570-8	8-11	90-04125-8	15-28-24	90-04800-8	6-7-5
90-00570-9	8-11	90-04125-9	15-28-24	90-04800-9	6-7-5
90-00570-10	8-11	90-04125-10	15-28-24	90-04800-10	6-7-5
90-00570-11	8-11	90-04125-11	15-28-24	90-04800-11	6-7-5
90-00570-12	8-11	90-04125-12	15-28-24	90-04800-12	6-7-5
90-00570-13	8-11	90-04125-13	15-28-24	90-04800-13	6-7-5
90-00570-14	8-11	90-04125-14	15-28-24	90-04800-14	6-7-5
90-00570-15	8-11	90-04125-15	15-28-24	90-04800-15	6-7-5
90-00570-16	8-11	90-04125-16	15-28-24	90-04800-16	6-7-5
90-00570-17	8-11	90-04125-17	15-28-24	90-04800-17	6-7-5
90-00570-18	8-11	90-04125-18	15-28-24	90-04800-18	6-7-5
90-00570-19	8-11	90-04125-19	15-28-24	90-04800-19	6-7-5
90-00570-20	8-11	90-04125-20	15-28-24	90-04800-20	6-7-5
90-00570-21	8-11	90-04125-21	15-28-24	90-04800-21	6-7-5
90-00570-22	8-11	90-04125-22	15-28-24	90-04800-22	6-7-5
90-00570-23	8-11	90-04125-23	15-28-24	90-04800-23	6-7-5
90-00570-24	8-11	90-04125-24	15-28-24	90-04800-24	6-7-5
90-00570-25	8-11	90-04125-25	15-28-24	90-04800-25	6-7-5
90-00570-26	8-11	90-04125-26	15-28-24	90-04800-26	6-7-5
90-00570-27	8-11	90-04125-27	15-28-24	90-04800-27	6-7-5
90-00570-28	8-11	90-04125-28	15-28-24	90-04800-28	6-7-5
90-00570-29	8-11	90-04125-29	15-28-24	90-04800-29	6-7-5
90-00570-30	8-11	90-04125-30	15-28-24	90-04800-30	6-7-5
90-00570-31	8-11	90-04125-31	15-28-24	90-04800-31	6-7-5
90-00570-32	8-11	90-04125-32	15-28-24	90-04800-32	6-7-5
90-00570-33	8-11	90-04125-33	15-28-24	90-04800-33	6-7-5
90-00570-34	8-11	90-04125-34	15-28-24	90-04800-34	6-7-5
90-00570-35	8-11	90-04125-35	15-28-24	90-04800-35	6-7-5
90-00570-36	8-11	90-04125-36	15-28-24	90-04800-36	6-7-5
90-00570-37	8-11	90-04125-37	15-28-24	90-04800-37	6-7-5
90-00570-38	8-11	90-04125-38	15-28-24	90-04800-38	6-7-5
90-00570-39	8-11	90-04125-39	15-28-24	90-04800-39	6-7-5
90-00570-40	8-11	90-04125-40	15-28-24	90-04800-40	6-7-5
90-00570-41	8-11	90-04125-41	15-28-24	90-04800-41	6-7-5
90-00570-42	8-11	90-04125-42	15-28-24	90-04800-42	6-7-5
90-00570-43	8-11	90-04125-43	15-28-24	90-04800-43	6-7-5
90-00570-44	8-11	90-04125-44	15-28-24	90-04800	

[illegible]

Part catalogue structure

①

E-14-10

INTAKE MANIFOLD

⑨

FR.

⑩

⑪

33

③

④

⑤

⑥


⑦

⑧

Ref.No.	Part No.	Description	Q.ty	Remarks
E-14-10	1	HCY9-17109-004	1	1
E-14-10	2	HCY9-17109-004	1	1
E-14-10	3	HCY9-17110-003	1	1
E-14-10	4	HCY9-17113-003	1	1
E-14-10	5	HCY9-17130-0032A	1	1
E-14-10	6	HCY9-17138-004	1	1
E-14-10	7	HM09-17001-000	1	1
E-14-10	8	HCY9-20129-000	1	1
E-14-10	9	HPM-30140-004	1	1
E-14-10	10	HCY9-30163-003	1	1
E-14-10	11	HPM-30165-005	1	1
E-14-10	12	HPM-37030-A01	1	1
E-14-10	13	HPM-37030-A01	1	1
E-14-10	14	HCY9-90023-000	10	10
E-14-10	15	HCY9-90029-000	1	1
E-14-10	16	HCY9-90031-000	1	1
E-14-10	17	HCY9-90039-000	1	1
E-14-10	18	HCY9-90106-000	7	7
E-14-10	19	HCY9-90205-000	2	2
E-14-10	20	HCO-90001-05040-40	1	1
E-14-10	21	HCO-90001-05130-40	1	1
E-14-10	22	HCO-90001-05040-40	1	1
E-14-10	23	HCO-90001-05030-60	1	1
E-14-10	24	HCO-90001-05060-40	1	1

- ① Fig. Number
- ② Fig. Title
- ③ Ref. Number
- ④ Parts Number
- ⑤ Parts Name
- ⑥ Q.ty
- ⑦ Remarks
- ⑧ Defferent specification
- ⑨ Direction Arrow
- ⑩ Parts enclosed within a dotted line are sub assembly parts.
- ⑪ A solid arrow indicates the block No. the part in question is connected to.

How to check the part block and serial numbers



Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.
			Model	Type		
BFT 200A	LA	LA	BF 200AK3	SE1	BEAEJ-1300001~	BAEJ-6000051~
	XA	XA				BAEJ-7000004~
	XCA	XCA				
BFT225A	LA	LA	BF 225AK3	SE1	BEAGJ-1300001~	BAGJ-6000083~
	XA	XA				BAGJ-7000013~
	XCA	XCA				

Features of each type

- See the following table for the features of each type. (Items in brackets are optional)

Model		BFT 200AK3		
		LA	XA	XCA
Specifications	Transom height			
	508 mm	●		
	635 mm		●	●
Gear case cover				●
Trim tab		●	●	
Counter rotation				●


Model		BFT 225AK3		
		LA	XA	XCA
Specifications	Transom height			
	508 mm	●		
	635 mm		●	●
Gear case cover				●
Trim tab		●	●	
Counter rotation				●

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.


Example: 95001-75001-50M




CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


E-1 CYLINDER HEAD COVER




E-3 CYLINDER BLOCK




E-3-10 CRANKCASE




E-4 EXHAUST MANIFOLD/THERMOSTAT




E-5 OIL PUMP/FLYWHEEL




E-6 OIL PAN




E-6-10 MOUNT CASE




E-7 CRANKSHAFT/PISTON




E-9 CYLINDER HEAD




E-9-10 CAMSHAFT/ROCKER ARM




E-13 TIMING BELT




E-13-10 TIMING BELT COVER




E-14 FUEL PIPE/INJECTOR




E-14-10 INTAKE MANIFOLD




E-15 THROTTLE BODY




E-18 VAPOR SEPARATOR ASSY




E-18-2 WATER SEPARATOR/FUEL STRAINER




E-18-10 PIPING




E-19 A.C.GENERATOR




E-20 SPARK PLUG




E-20-11 ELECTRONIC CONTROL UNIT




E-21 STARTER MOTOR




F-2 SHIFT SHAFT




F-3 GEAR CASE




F-3-10 GEAR CASE ASSY



F-3-20 EXTENSION CASE




F-4 WATER PUMP/VERTICAL SHAFT




F-5 PROPELLER SHAFT	F-5-1 PROPELLER SHAFT (COUNTER ROTATION)	F-6 FUEL TUBE
F-7 WIRE HARNESS	F-7-11 STARTER CABLE	F-7-30 FUSE BOX/RELAY
F-8 ENGINE COVER	F-8-10 FR.COVER BRACKET/FRLOCK SHAFT	F-8-20 FUEL TUBE (2)


F-10 STERN BRACKET/SWIVEL CASE




F-11 POWER TRIM-TILT




F-12 LABEL




F-13 TOOL




FOP-2 WATER PUMP IMPELLER SET




FOP-3 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)




FOP-3-2 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)




FOP-3-4 REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)




FOP-3-6 REMOTE CONTROL




FOP-4 SWITCH PANEL KIT (1)




FOP-4-1 SWITCH PANEL KIT (2)




FOP-5-1 METER




FOP-7 BOLT KIT




FOP-9 TRIM ADJUST PLATE SET




FOR-10 PROPELLER




FOP-12 INTERFACE CABLE KIT







Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-1	1	HZY3-12310-405ZA	COVER, R. CYLINDER HEAD	1	1	*NH8* DARK GRAY
E-1	2	HZY3-12312-000	PACKING, HEAD COVER	2	2	
E-1	3	HZY3-12320-405ZA	COVER, L. CYLINDER HEAD	1	1	*NH8* DARK GRAY
E-1	4	HP08-12342-004	SEAL, SPARK PLUG TUBE(NOK)	6	6	
E-1	5	HZY3-15425-010	TUBE, OIL	2	2	
E-1	7	HZY3-16203-000	BRACKET, SOLENOID VALVE	1	1	
E-1	9	HZX2-16700-003	PUMP ASSY., FUEL	1	1	
E-1	12	HZY3-16895-C00	TUBE COMP. G, FUEL	1	1	
E-1	14	HMT2-17193-000	T-JOINT	1	1	
E-1	15	HZW9-32114-730	BRACKET, CLIP B	1	1	
E-1	16	HZY3-32129-000	BRACKET C, HARNESS CLIP	3	3	
E-1	17	HHE0-50310-003	CLIP A, WIRE	1	1	
E-1	18	HSE0-53740-953	CLIP, SENSOR HOSE	1	1	
E-1	19	HSD9-54316-013	CLIP, SHIFT WIRE	1	1	
E-1	20	HZW9-90011-000	BOLT, FLANGE, 6X14(CT200)	5	5	
E-1	21	HZW9-90019-000	BOLT, FLANGE, 6X35	16	16	
E-1	22	HZY3-90036-000	BOLT, FLANGE, 8X32	1	1	
E-1	23	HZY3-90406-000	WASHER, PLAIN, 8MM	2	2	
E-1	25	HZY3-90602-020	CLAMP, TUBE(D32.5)	2	2	
E-1	27	HZV0-90604-000	CLIP, TUBE(B12)	4	4	
E-1	28	HZB7-90691-003	CLIP, HARNESS	1	1	
E-1	29	HKT7-91305-003	O-RING, 37X2.4(ARAI)	1	1	
E-1	30	HZY3-91401-A00	TUBE COMP. A, BREATHER	1	1	
E-1	31	HZY3-91402-020	TUBE B, BREATHER	1	1	
E-1	32	HZY3-91403-000	TUBE C, BREATHER	1	1	
E-1	33	HSK7-91566-003	CLIP D, WASHER TUBE	1	1	
E-1	34	HZX2-16870-C00	TUBE COMP., FUEL(C)	1	1	
E-1	35	HZW4-90126-000	BOLT, FLANGE, 8X45	1	1	

FR. 


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-3	1	HZY3-11200-010ZA	COVER ASSY., CRANKCASE UPPER	1	1	*NH8* DARK GRAY
E-3	2	HZY3-11300-C00	CASE ASSY., OIL SEAL	1	1	
E-3	3	HZY3-12000-436ZA	BLOCK ASSY., CYLINDER	1	1	*NH8* DARK GRAY
E-3	4	HZV4-12155-A00	METAL, ANODE	6	6	
E-3	5	HZY3-12155-000	METAL, ANODE	2	2	
E-3	6	HZY3-12164-000	BOLT, SEALING, 22MM	6	6	
E-3	7	HZY3-12171-305	WASHER, SEALING, 22MM	6	6	
E-3	8	HZV5-12214-000	WASHER, SEALING(22MM)	1	1	
E-3	9	HP8A-15115-A01	PACKING, OIL HOLE	1	1	
E-3	10	HP8A-15140-A00	ORIFICE ASSY., OIL CONTROL	2	2	
E-3	11	HP8A-15142-A00	O-RING, 8.8X2.4	2	2	
E-3	12	HP8A-15150-A00	JOINT ASSY., OIL PIPE	1	1	
E-3	14	HZY3-15656-000	COVER, OIL LEVEL GAUGE	1	1	
E-3	15	HZY3-15657-000	PACKING, OIL LEVEL GAUGE	1	1	
E-3	16	HZY2-15810-000ZA	VALVE ASSY., SPOOL	1		*NH8* DARK GRAY
E-3		HZY3-15810-003ZA	VALVE ASSY., SPOOL		1	*NH8* DARK GRAY
E-3	17	HZY2-15825-000	FILTER ASSY., SPOOL VALVE	1		
E-3		HZY3-15825-003	FILTER ASSY., SPOOL VALVE		1	
E-3	18	HRNA-30530-A01	SENSOR COMP., KNOCK	1	1	
E-3	19	HZW9-32114-730	BRACKET, CLIP B	1	1	
E-3	20	HZY3-32116-000	BRACKET B, HARNESS CLIP	1	1	
E-3	21	HZY3-32193-C00	CORD, SWITCH	1	1	
E-3	22	HZW9-35490-003	SWITCH ASSY., OIL PRESSURE	1	1	
E-3	23	HZY3-35490-004	SWITCH ASSY., OIL PRESSURE	1	1	
E-3	24	HZY3-35673-003	SENSOR ASSY., WATER	1	1	TEMPERATURE
E-3	25	HZY3-35700-003	SENSOR ASSY., CRANK	1	1	
E-3	26	HZY3-90001-000	BOLT, FLANGE, 12X95	2	2	
E-3	27	HZY3-90006-003	BOLT-WASHER, 10X109	1	1	
E-3	28	HZY3-90008-003	BOLT-WASHER, 10X60	5	5	

FR. 


Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
E-3	29	HZY3-90009-003	BOLT-WASHER, 10X80	2	2
E-3	30	HRCA-90014-A01	BOLT-WASHER, 11X105	8	8
E-3	31	HZY3-90017-000	BOLT, FLANGE, 6X16	1	1
E-3	32	HZW9-90019-000	BOLT, FLANGE, 6X35	7	7
E-3	33	HZY3-90021-000	BOLT, FLANGE, 6X14	2	2
E-3	34	HZY3-90028-000	BOLT, FLANGE, 6X18	4	4
E-3	35	HZY3-90030-000	BOLT, FLANGE, 6X22	8	8
E-3	36	HZY3-90038-000	BOLT, FLANGE, 8X75	1	1
E-3	37	HZV5-90081-010	BOLT, SEALING, 22MM	1	1
E-3	38	HZW4-90156-000	BOLT, FLANGE, 8X50	2	2
E-3	39	HPH7-90715-000	DOWEL PIN, 13X37	8	8
E-3	40	HZY3-91212-003	OIL SEAL, 41X66X8	1	1
E-3	41	HPNA-91214-014	OIL SEAL, 80X98X10(ARAI)	1	1
E-3	42	HPNA-91307-003	O-RING, 9.5X1.9	1	1
E-3	43	HP8A-91308-A01	O-RING, 18.3X3.5	1	1
E-3	44	HPK1-91308-003	O-RING, 26.2X2.4(NOK)	1	1
E-3	45	HP8A-91309-A01	O-RING, 16.3X3.5	1	1
E-3	46	HPR3-91319-003	O-RING, 13X1.5(ARAI)	1	1
E-3	47	HP0X-91321-003	O-RING, 25X2.4(NOK)	1	1
E-3	48	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	1	2 (145MM)
E-3	49	HCO-93500-05016-4J	SCREW, PAN, 5X16	2	2
E-3	50	HCO-93500-05020-4J	SCREW, PAN, 5X20	6	6
E-3	51	HCO-94301-06100	DOWEL PIN, 6X10	4	4
E-3	52	HCO-94303-05080	DOWEL PIN, 5X8	1	1
E-3	53	HZX2-15655-000	GAUGE COMP., OIL LEVEL	1	1

FR. 


[illegible]

FR. 

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-4	1	HZV5-12155-000	METAL, ANODE	4	4	
E-4	2	HZY3-18110-010ZA	MANIFOLD COMP., R. EX.	1	1	*NH8* DARK GRAY
E-4	3	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	
E-4	4	HZY3-18120-C01ZA	MANIFOLD COMP., L. EX.	1	1	*NH8* DARK GRAY
E-4	5	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	
E-4	6	HZY3-19255-000	TUBE, R. WATER RETURN	1	1	
E-4	7	HZY3-19256-010	TUBE, WATER RELIEF	2	2	
E-4	8	HZY3-19257-000	TUBE, WATER	2	2	
E-4	9	HZY3-19261-000	TUBE, L. WATER RETURN	1	1	
E-4	10	HZY3-19300-023	THERMOSTAT ASSY.	2	2	
E-4	11	HZY3-19315-020ZA	COVER, THERMOSTAT	2	2	*NH8* DARK GRAY
E-4	12	HZY3-19319-A00ZA	SPACER, THERMOSTAT	1	1	*NH8* DARK GRAY
E-4	13	HZY3-35655-C01	SENSOR, OXYGEN	1	1	
E-4	14	HZY3-35673-003	SENSOR ASSY., WATER	2	2	TEMPERATURE
E-4	16	HZW9-90019-000	BOLT, FLANGE, 6X35	1	1	
E-4	17	HZY3-90027-000	BOLT, FLANGE, 8X60	8	8	
E-4	18	HZY3-90034-000	BOLT, FLANGE, 6X60	2	2	
E-4	19	HZW4-90146-000	BOLT, FLANGE, 6X50	3	3	
E-4	20	HZW4-90155-000	BOLT, FLANGE, 8X40	8	8	
E-4	21	HZY3-90601-030	CLAMP, TUBE(D10.5)	4	4	
E-4	22	HZY3-90603-020	CLAMP, TUBE(D29)	4	4	
E-4	23	HZY3-90604-020	CLAMP, TUBE(D21)	2	2	
E-4	24	HZY3-91301-003	O-RING, 66.4X3.1	2	2	
E-4	25	HPNA-91307-003	O-RING, 9.5X1.9	2	2	
E-4	26	HSD4-91356-952	O-RING, 31.5X2.4(ARAI)	3	3	
E-4	27	HCO-93500-06018-4J	SCREW, PAN, 6X18	4	4	


FR. 

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-5	1	HZY3-15100-000ZA	PUMP ASSY., OIL	1	1	*NH8* DARK GRAY
E-5	2	HZY3-15112-013	PACKING, OIL PUMP BODY	1	1	
E-5	3	HZY3-15113-000	RUBBER, OIL PUMP	1	1	
E-5	4	HZY3-15121-000	COVER, OIL PUMP	1	1	
E-5	5	HZY3-15131-405	ROTOR, OIL PUMP INNER	1	1	
E-5	6	HZY3-15132-405	ROTOR, OIL PUMP OUTER	1	1	
E-5	7	HZY3-15220-020	STRAINER COMP., OIL	1	1	
E-5	8	HPE0-15231-000	VALVE, RELIEF	1	1	
E-5	9	HPG6-15232-000	SPRING, RELIEF VALVE	1	1	
E-5	10	HPC6-15233-000	BOLT, SEALING, 18MM	1	1	
E-5	11	HZY3-31110-000ZA	FLYWHEEL COMP.	1	1	*TBLACK* BLACK
E-5	12	HZY3-31116-000	BOSS, FLYWHEEL	1	1	
E-5	13	HZW5-90002-013	BOLT, SPECIAL, 8MM	8	8	
E-5	14	HPH3-90011-000	BOLT, FLANGE, 12MM	8	8	
E-5	15	HZV5-90081-010	BOLT, SEALING, 22MM	2	2	
E-5	16	HPW5-90701-000	DOWEL PIN, 14X15	1	1	
E-5	17	HZW5-91201-003	OIL SEAL, 46X60X9	1	1	
E-5	18	HP01-91212-003	OIL SEAL, 31X46X7(NOK)	1	1	
E-5	19	HPC6-91324-000	O-RING, 20.6X2.6	1	1	
E-5	20	HCO-93600-06016-0A	SCREW, FLAT, 6X16	8	8	
E-5	21	HCO-94302-10160	PIN B, DOWEL, 10X16	1	1	
E-5	22	HCO-95701-06014-09	BOLT, FLANGE, 6X14	2	2	
E-5	23	HCO-95701-06018-09	BOLT, FLANGE, 6X18	2	2	
E-5	24	HCO-95701-08030-09	BOLT, FLANGE, 8X30	4	4	
E-5	25	HCO-96220-50080	ROLLER, 5X8	2	2	

FR. 


[illegible]

FR. →




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
E-6-10	1	HGHB-16163-610	CLIP, TUBE	1	1	
E-6-10	2	HZY3-18141-A00ZA	GUIDE, R. EX.	1	1	*TGRAY* GRAY
E-6-10	3	HZY3-18148-003	SEAL, EXHAUST GUIDE	2	2	
E-6-10	4	HZY3-18149-A01	SEAL B, EX. GUIDE	2	2	
E-6-10	5	HZY3-18151-A00ZA	GUIDE, L. EX.	1	1	*TGRAY* GRAY
E-6-10	6	HZY3-19277-000ZA	COVER, FLUSH VALVE	1	1	*NH8* DARK GRAY
E-6-10	7	HZY3-19278-000	CASE, FLUSH VALVE	1	1	
E-6-10	8	HZW9-19279-000	SPRING, FLUSH VALVE	1	1	
E-6-10	9	HZW5-19291-000	VALVE, RELIEF	2	2	
E-6-10	10	HZW9-19291-000	VALVE, FLASH	1	1	
E-6-10	11	HZW5-19292-000	SPRING, RELIEF VALVE	2	2	
E-6-10	12	HZY3-19294-000ZB	SPACER, R. RELIEF VALVE	1	1	*TGRAY* GRAY
E-6-10	13	HZY3-19295-000	COVER, R. RELIEF VALVE	1	1	
E-6-10	14	HZY3-19296-000	PACKING, RELIEF VALVE COVER	2	2	
E-6-10	15	HZW5-19297-000	PACKING, RELIEF VALVE	2	2	
E-6-10	16	HZW9-19297-000	PACKING, FLASH VALVE	1	1	
E-6-10	17	HZY3-19297-000	COVER, L. RELIEF VALVE	1	1	
E-6-10	18	HZY3-19298-000ZB	SPACER, L. RELIEF VALVE	1	1	*TGRAY* GRAY
E-6-10	19	HZY3-19361-000	COVER, R. WATER JACKET	1	1	
E-6-10	20	HZY3-19362-000	PACKING, WATER JACKET COVER	2	2	
E-6-10	21	HZY3-19366-000	COVER, L. WATER JACKET	1	1	
E-6-10	22	HZY3-23170-030ZA	CASE COMP., MOUNT	1	1	*NH8* DARK GRAY
E-6-10	23	HZY3-23172-003	GASKET, MOUNT CASE	1	1	
E-6-10	24	HZY3-23173-010	RUBBER, MOUNT CASE SEAL	1	1	
E-6-10	25	H371-90009-015	BOLT, FLANGE, 10X120(SATO)	1	1	
E-6-10	26	HZY3-90010-000	BOLT, HEX., 12X120	2	2	
E-6-10	27	HZY3-90011-000	BOLT, HEX., 12X65	1	1	
E-6-10	28	HZY3-90013-000	BOLT, HEX., 10X85	1	1	
E-6-10	29	HZY3-90015-000	BOLT, HEX., 10X60	2	2	


FR. →




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-6-10	30	HZY3-90030-000	BOLT, FLANGE, 6X22	2	2	
E-6-10	31	HZY3-90031-000	BOLT, FLANGE, 6X32	4	4	
E-6-10	32	HZY3-90045-000	BOLT, STUD, 10X45	2	2	
E-6-10	33	HZY3-90046-000	BOLT, FLANGE, 8X100	2	2	
E-6-10	34	HZY3-90047-000	BOLT, WASHER, 6X121	6	6	
E-6-10	35	HZY3-90049-000	BOLT, FLANGE, 8X30	4	4	
E-6-10	36	HZY3-90059-000	BOLT-WASHER, 6X29	1	1	
E-6-10	37	HHW1-90207-671	BOLT, FLANGE, 6X40	2	2	
E-6-10	38	HZV5-90559-000	WASHER, PLAIN, 12MM	3	3	
E-6-10	39	HZV5-90563-000	WASHER, PLAIN, 10MM	3	3	
E-6-10	40	HZV4-90603-000	CLIP, TUBE(B10)	1	1	
E-6-10	41	HZV4-90605-000	CLIP, TUBE(B12.5)	2	2	
E-6-10	42	HPW5-90701-000	DOWEL PIN, 14X15	1	1	
E-6-10	43	HZY3-91001-003	BEARING, NEEDLE, 20X28X13	1	1	(SOLID)
E-6-10	44	HZW5-91202-003	SEAL, WATER, 22X35X7	2	2	
E-6-10	45	H800-91303-000	O-RING, 16MM	1	1	
E-6-10	46	HZY3-91304-000	O-RING, 49.4X3.1	2	2	
E-6-10	47	HZY3-91305-003	O-RING, 33.5X2	2	2	
E-6-10	48	HZY3-91306-003	O-RING, 23.5X2	2	2	
E-6-10	49	HZY3-91404-000	TUBE, WATER CHECK	1	1	
E-6-10	50	HZY3-91405-000	TUBE, FLUSH VALVE	1	1	
E-6-10	51	HCO-94302-10160	PIN B, DOWEL, 10X16	1	1	
E-6-10	52	HCO-95701-10070-09	BOLT, FLANGE, 10X70	2	2	
E-6-10	53	HCO-95701-12120-09	BOLT, FLANGE, 12X120	2	2	

FR. 


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-7	1	HZY3-13010-A00	RING SET, PISTON(STD.)	6	6	
E-7		HZY3-13011-A00	RING SET, PISTON(0.25)	6	6	
E-7	2	HZY3-13101-A00	PISTON	6	6	
E-7		HZY3-13102-A00	PISTON(0.25)	6	6	
E-7	3	HPEA-13111-000	PIN, PISTON	6	6	
E-7	4	HP5A-13115-000	CLIP, PISTON PIN	12	12	
E-7	5	HP8A-13204-A01	BOLT, CONNECTING ROD	12	12	
E-7	6	HR70-13210-A10	ROD COMP., CONNECTING	6	6	
E-7	7	HP8F-13211-A11	BEARING A, CONNECTING ROD	12	12	(BLACK)(TAIHO)
E-7		HP8F-13212-A11	BEARING B, CONNECTING ROD	12	12	(BROWN)(TAIHO)
E-7		HP8F-13213-A11	BEARING C, CONNECTING ROD	12	12	(GREEN)(TAIHO)
E-7		HP8F-13214-A11	BEARING D, CONNECTING ROD	12	12	(YELLOW)(TAIHO)
E-7		HP8F-13215-A11	BEARING E, CONNECTING ROD	12	12	(PINK)(TAIHO)
E-7	8	HRGL-13310-A00	CRANKSHAFT COMP.	1	1	
E-7	9	HP8A-13321-A01	BEARING A, MAIN UPPER(BLACK)	4	4	(DAIDO)
E-7		HP8A-13322-A01	BEARING B, MAIN UPPER(BROWN)	4	4	(DAIDO)
E-7		HP8A-13323-A01	BEARING C, MAIN UPPER(GREEN)	4	4	(DAIDO)
E-7		HP8A-13324-A01	BEARING D, MAIN UPPER(YELLOW)	4	4	(DAIDO)
E-7		HP8A-13325-A01	BEARING E, MAIN UPPER(PINK)	4	4	(DAIDO)
E-7		HP8A-13326-A01	BEARING F, MAIN UPPER(RED)	4	4	(DAIDO)
E-7	10	HZY3-13331-A03	WASHER, THRUST	2	2	
E-7		HZY3-13331-A04	WASHER, THRUST	2		#1300393~ #6000037~
E-7		HZY3-13331-A04	WASHER, THRUST		2	#1300972~ #6000070~
E-7	11	HP8A-13341-A01	BEARING A, MAIN LOWER(BLACK)	4	4	(DAIDO)
E-7		HP8A-13342-A01	BEARING B, MAIN LOWER(BROWN)	4	4	(DAIDO)
E-7		HP8A-13343-A01	BEARING C, MAIN LOWER(GREEN)	4	4	(DAIDO)
E-7		HP8A-13344-A01	BEARING D, MAIN LOWER(YELLOW)	4	4	(DAIDO)
E-7		HP8A-13345-A01	BEARING E, MAIN LOWER(PINK)	4	4	(DAIDO)
E-7		HP8A-13346-A01	BEARING F, MAIN LOWER(RED)	4	4	(DAIDO)

FR. 


[illegible]




[illegible]

FR. 


Ref.No.	Part No.	Description	Q'ty		Remarks
			BFT200A	BFT225A	
E-9-10	1	HZY2-14111-A00	CAMSHAFT, R.	1	
E-9-10		HZY3-14111-A00	CAMSHAFT, R.	1	
E-9-10	2	HZY2-14211-A00	CAMSHAFT, L.	1	
E-9-10		HZY3-14211-A00	CAMSHAFT, L.	1	
E-9-10	3	HZY3-14436-000	ARM, FUEL PUMP ROCKER	1	1
E-9-10	4	HRDV-14610-J00	ARM ASSY., FR. INTAKE ROCKER	6	
E-9-10	5	HP8A-14620-A01	ARM ASSY., INTAKE ROCKER		6
E-9-10	6	HP8A-14626-A00	ARM COMP. A, EX. ROCKER	6	6
E-9-10	7	HP8A-14627-A00	ARM COMP. B, EX. ROCKER	6	6
E-9-10	8	HRDV-14631-J00	SHAFT COMP., FR. INTAKE ROCKER	2	
E-9-10		HP8A-14631-A00	SHAFT COMP., INTAKE ROCKER ARM		2
E-9-10	9	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	2	2
E-9-10	10	HP8A-14645-A01	SPRING, ROCKER ARM	6	6
E-9-10	11	HRDV-14646-J00	WASHER, THRUST	12	
E-9-10	12	HPXK-14711-000	VALVE, IN.	12	12
E-9-10	13	HRJA-14721-E00	VALVE, EX.	12	12
E-9-10	14	HPM3-14744-000	SCREW, TAPPET ADJUSTING	12	
E-9-10	15	HPT0-14744-004	SCREW, TAPPET ADJUSTING	12	24
E-9-10	16	HP8E-14761-A01	SPRING, IN. VALVE(GRAY)	12	12
E-9-10	17	HP8E-14762-A01	SPRING, EX. VALVE	12	12
E-9-10	18	HRDV-14765-J00	RETAINER, VALVE SPRING	24	24
E-9-10	19	HPM3-14775-000	SEAT, VALVE SPRING	24	24
E-9-10	20	HRGM-14781-A01	COTTER, VALVE(FUJI VALVE)	48	48
E-9-10	21	HP8A-90003-A00	BOLT, FLANGE, 8X30	12	12
E-9-10	22	HP8A-90004-A00	BOLT, FLANGE, 8X40	8	8
E-9-10	23	HPM3-90206-004	NUT, TAPPET ADJUSTING	12	
E-9-10	24	HPT0-90206-004	NUT, TAPPET ADJUSTING	12	24

FR. 


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
E-13	1	HZY3-13621-C01	PULLEY, TIMING BELT DRIVE	1	1	
E-13	2	HZY3-13622-C00	PLATE, TIMING BELT GUIDE	1	1	
E-13	3	HZY3-13811-A00	PULLEY, CRANKSHAFT	1	1	
E-13	4	HZY3-14261-C00	PULLEY COMP., R. TIMING BELT	1	1	DRIVEN
E-13	5	HZY3-14270-C00	PULLEY COMP., L. TIMING BELT	1	1	DRIVEN
E-13	6	HP8A-14400-A01	BELT, TIMING(197YU26 B-333)	1	1	
E-13	7	HZY3-14510-003	TENSIONER COMP., TIMING BELT	1	1	
E-13	8	HZY3-14515-000	CAP, TIMING BELT TENSIONER	3	3	
E-13	9	HZY3-14520-000	SPRING COMP., TIMING BELT	1	1	ADJUSTING
E-13	10	HZY3-14526-405ZA	BASE COMP., TIMING BELT	1	1	TENSIONER *NH8* DARK GRAY
E-13	11	HZY3-14529-000	O-RING, TIMING BELT TENSIONER	1	1	BASE
E-13	12	HZY3-14550-003	IDLER, TIMING BELT(KOYO SEIKO)	1	1	
E-13	13	HP8A-14551-A01	BOLT, IDLER	1	1	
E-13	14	HZY3-14553-003	BOLT, TIMING BELT IDLER A	1	1	
E-13	15	HZY3-14555-003	IDLER B, TIMING BELT	1	1	
E-13	16	HZY3-31638-003	BELT, A.C. GENERATOR	1	1	(6PK745 M-180)
E-13	17	HZY3-32111-010	BRACKET, COUPLER D	1	1	
E-13	18	HZV0-41122-000	PIN, VERTICAL SHAFT	1	1	
E-13	19	HZW9-90011-000	BOLT, FLANGE, 6X14(CT200)	1	1	
E-13	20	HZV5-90012-013	BOLT, TIMING BELT ADJUSTING	1	1	SPRING
E-13	21	HRJA-90017-003	BOLT-WASHER, 16X49	1	1	
E-13	22	HZY3-90030-000	BOLT, FLANGE, 6X22	1	1	
E-13	23	HP8A-90031-A01	BOLT-WASHER, 12X35	2	2	
E-13	24	HZY3-90039-000	BOLT, FLANGE, 10X40	3	3	
E-13	25	HZY3-90040-000	BOLT, FLANGE, 10X43	1	1	
E-13	26	HRCA-90704-A00	KEY, 4.5X24	1	1	
E-13	27	HZY3-90741-000	KEY, SPECIAL	2	2	
E-13	28	HCO-94301-06100	DOWEL PIN, 6X10	1	1	

FR. 


[illegible]

FR. 

Ref.No.	Part No.	Description	Q'ty		Remarks
			BFT200A	BFT225A	
E-14	1	HZY6-16450-003	INJECTOR ASSY., FUEL	6	6
E-14	2	HZY3-16451-000	CLIP, INJECTOR	6	6
E-14	3	HZY3-16611-A00	PIPE, R. FUEL	1	1
E-14	4	HP5G-16614-003	MESH, FUEL FILTER	1	1
E-14	5	HZY3-16620-A00	PIPE COMP., L. FUEL	1	1
E-14	6	HZY3-16740-A01	REGULATOR ASSY., PRESSURE	1	1
E-14	7	HPG7-16741-005	O-RING, PRESSURE REGULATOR	1	1
E-14	8	HZY3-16752-A00	JOINT, FUEL PIPE	3	3
E-14	9	HZY3-16755-003	HOSE COMP., FUEL	1	1
E-14	10	HZY3-16757-003	HOSE COMP., FUEL JOINT	1	1
E-14	11	HZY3-17051-A00	BASE, R. INJECTOR	1	1
E-14	12	HRCA-17055-A01	GASKET, FR. INJECTOR BASE	1	1
E-14	13	HZY3-17061-A00	BASE, L. INJECTOR	1	1
E-14	14	HRCA-17065-A01	GASKET, RR. INJECTOR BASE	1	1
E-14	15	HP8E-17105-A01	GASKET, INTAKE MANIFOLD	1	1
E-14	16	HZY3-17108-000	SPACER, INTAKE MANIFOLD	1	1
E-14	17	HZY3-32112-000	BRACKET, HARNESS CLIP A	4	4
E-14	18	HSJ6-78419-003	CLIP D, SPEEDOMETER CABLE	2	2
E-14	19	HZW9-90016-000	BOLT, FLANGE, 6X25	4	4
E-14	20	HZW9-90019-000	BOLT, FLANGE, 6X35	4	4
E-14	21	HZY3-90021-000	BOLT, FLANGE, 6X14	6	6
E-14	22	HZY3-90042-000	BOLT, FLANGE, 6X10	6	6
E-14	23	HZY3-90043-000	BOLT, STUD, 8X28	8	8
E-14	24	HZY3-90044-000	BOLT, STUD, 8X45	2	2
E-14	25	HZY3-90205-000	NUT, FLANGE, 8MM	8	8
E-14	26	HSB2-90650-003	CLIP, WIRE HARNESS, 10MM	4	4
E-14	27	HMJ0-91301-003	O-RING, 7.8X1.9(ARAI)	6	6
E-14	28	HPLC-91301-000	O-RING, 7.47X3.6	6	6
E-14	29	HPNA-91302-003	O-RING, 7.45X3.61(NOK)	6	6


FR. 

[illegible]




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
E-14-10	1	HZY3-17105-004	GASKET, INTAKE MANIFOLD	1	1	
E-14-10	2	HZY3-17109-004	PACKING, THROTTLE BODY	1	1	
E-14-10	3	HZY3-17110-003	MANIFOLD COMP., INTAKE	1	1	
E-14-10	4	HZY3-17113-003	PLATE, INTAKE MANIFOLD CENTER	1	1	
E-14-10	5	HZY3-17130-003ZA	COVER COMP., INTAKE MANIFOLD	1	1	*NH8* DARK GRAY
E-14-10	6	HZY3-17138-004	PACKING, INTAKE MANIFOLD UP	1	1	COVER
E-14-10	7	HMG9-17201-000	JOINT A, VACUUM TUBE	1	1	
E-14-10	8	HZY3-32128-000	BRACKET, SENSOR CORD	1	1	
E-14-10	9	HPM4-36145-004	VALVE, CHECK	1	1	
E-14-10	10	HZY3-36163-003	VALVE ASSY., AIR BYPASS	1	1	
E-14-10	11	HP8D-36165-J00	WASHER, CONICAL SPRING(5)	1	1	
E-14-10	12	HRNA-37830-A01	SENSOR ASSY., MAP	1	1	
E-14-10	13	HPGK-37835-A01	O-RING	1	1	
E-14-10	14	HZY3-90023-000	BOLT, FLANGE, 6X22	10	10	
E-14-10	15	HZY3-90029-000	BOLT-WASHER, 5X18	1	1	
E-14-10	16	HZY3-90031-000	BOLT, FLANGE, 6X32	1	1	
E-14-10	17	HZY3-90058-000	BOLT, FLANGE, 5X10	1	1	
E-14-10	18	HZW4-90156-000	BOLT, FLANGE, 8X50	7	7	
E-14-10	19	HZY3-90205-000	NUT, FLANGE, 8MM	2	2	
E-14-10	20	HCO-95001-35040-40	TUBE, FUEL, 3.5X40	1	1	(HC-95001-35001-60M)
E-14-10	21	HCO-95001-35130-40	TUBE, FUEL, 3.5X130	1	1	(HC-95001-35001-60M)
E-14-10	22	HCO-95001-35540-40	TUBE, FUEL, 3.5X540	1	1	(HC-95001-35001-60M)
E-14-10	23	HCO-95001-35590-60	TUBE, FUEL, 3.5X590	1	1	(HC-95001-35001-60M)
E-14-10	24	HCO-95001-35600-40	TUBE, FUEL, 3.5X600	1	1	(HC-95001-35001-60M)


Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
E-15	1	HZY3-16016-003	SCREW SET	1	1	
E-15	2	HZY3-16176-000	GASKET, THROTTLE BODY	1	1	
E-15	3	HZY3-16400-A01	THROTTLE BODY ASSY.	1	1	
E-15	4	HZY3-16404-000	SPACER, THROTTLE BODY	1	1	
E-15	5	HZY3-16405-000	GASKET, EAC VALVE	1	1	
E-15	6	HZY3-17203-000	TRAP, FLAME	1	1	
E-15	7	HZY3-17207-300	RUBBER, SEAL SILENCER	1	1	
E-15	8	HPY3-17249-000	SPRING, AIR FLOW TUBE	1	1	
E-15	9	HZY9-17315-000	BAND, AIR FLOW	1	1	
E-15	10	HZY3-17372-000	CASE A, SILENCER	1	1	
E-15	11	HZY3-17373-010	CASE B, SILENCER	1	1	
E-15	12	HZY3-17374-010	GROMMET, SILENCER	1	1	
E-15	13	HZY3-17910-013	CABLE COMP., THROTTLE	2	2	
E-15	14	HZW5-35665-003	SENSOR ASSY., AIR TEMP	1	1	
E-15	15	HZY3-36550-003	VALVE ASSY., EAC	1	1	
E-15	16	HZV5-40102-000	GROMMET, UNDER CASE	4	4	
E-15	17	HZW1-90013-000	BOLT-WASHER, 6X25	2	2	
E-15	18	HZY9-90017-000	BOLT-WASHER, 5X30	1	1	
E-15	19	HZY3-90030-000	BOLT, FLANGE, 6X22	2	2	
E-15	20	HZY3-90034-000	BOLT, FLANGE, 6X60	2	2	
E-15	21	HZY3-90037-000	BOLT, FLANGE, 8X65	4	4	
E-15	22	HZY3-90508-000	WASHER, PLAIN, 6MM	2	2	
E-15	23	HP0A-91303-A02	O-RING	1	1	
E-15	24	HZV5-91553-010	COLLAR, C.D.I. UNIT CASE	4	4	
E-15	25	HCO-93903-254G0	SCREW, TAPPING, 5X20	15	15	
E-15	26	HCO-94301-06100	DOWEL PIN, 6X10	2	2	




Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
E-18	1	HZY3-16011-A01	VALVE SET, FLOAT	1	1
E-18	2	HZY3-16013-000	FLOAT SET	1	1
E-18	3	HZY3-16015-000	BODY	1	1
E-18	4	HZX2-16020-003	COVER COMP.	1	1
E-18	5	HZY3-16024-000	SCREW SET, DRAIN	1	1
E-18	6	HZY3-16026-000	JOINT SET	1	1
E-18	7	HZX2-16030-003	PUMP UNIT SET A, FUEL	1	1
E-18	8	HZY3-16031-010	STAY, PLATE	1	1
E-18	9	HZY3-16036-003	PUMP UNIT SET B, FUEL	1	1
E-18	10	HZY3-16041-000	PLATE	1	1
E-18	11	HZY3-16042-000	HOLDER	1	1
E-18	12	HZY3-16061-000	COVER, WATER JACKET	1	1
E-18	13	HZY3-16072-000	O-RING	1	1
E-18	14	HZY3-16073-000	O-RING	1	1
E-18	15	HZY3-16074-000	O-RING	1	1
E-18	16	HZY3-16075-000	O-RING	1	1
E-18	17	HZY3-16076-000	O-RING	1	1
E-18	18	HZY3-16077-000	O-RING	2	2
E-18	19	HZY3-16078-000	O-RING	1	1
E-18	20	HZW5-16081-010	SCREW-WASHER	21	21
E-18	21	HZY3-16082-000	SCREW, PAN	2	2
E-18	22	HZY3-16083-000	SCREW, WASHER	1	1
E-18	23	HZW5-16086-000	COLLAR	8	8
E-18	24	HZW5-16087-000	WASHER, PLAIN	8	8
E-18	25	HZY3-16087-000	WASHER, PLAIN	1	1
E-18	26	HZY3-16088-000	COLLAR	1	1
E-18	27	HZX2-16701-003	CASE COMP., PUMP	1	1
E-18	28	HZY3-16708-000	COVER, PUMP	1	1
E-18	29	HZW5-16715-023	COVER, PUMP(A)	1	1



Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
E-18	30	HZY6-16718-013	INSULATOR COMP.	1	1
E-18	31	HZY3-16721-000	INSULATOR	1	1
E-18	32	HZY6-16723-003	RING	1	1
E-18	33	HZX2-16730-003	SEPARATOR ASSY., VAPOR	1	1
E-18	34	HZW5-16733-000	GROMMET, VAPOR SEPARATOR	1	1
E-18	35	HZY3-16733-000	GROMMET, VAPOR SEPARATOR	2	2
E-18	36	HZY3-16734-000	STAY, PLATE	1	1
E-18	37	HZY3-16735-004	PUMP UNIT, FUEL	1	1
E-18	38	HZY3-16752-000	JOINT, FUEL PIPE	1	1
E-18	39	HZY3-16911-010	SCREEN COMP., FUEL STRAINER	1	1
E-18	40	HZY3-16913-000	SPRING, SET	1	1
E-18	41	HZX2-32166-003	HARNESS COMP.	1	1
E-18	42	HPR7-36361-A01	TANK COMP., VACUUM	1	1
E-18	43	HZY3-36362-000	STAY, VACUUM TANK	1	1
E-18	44	HZY3-36620-000	PLATE	1	1
E-18	45	HPP4-90009-E01	BOLT, SEALING, 6MM	1	1
E-18	46	HZW1-90014-000	BOLT-WASHER, 8X35	1	1
E-18	47	HZW9-90016-000	BOLT, FLANGE, 6X25	4	4
E-18	48	HZY3-90017-000	BOLT, FLANGE, 6X16	2	2
E-18	49	HZY3-90021-000	BOLT, FLANGE, 6X14	2	2
E-18	50	HZY3-90050-000	BOLT, FLANGE, 6X12	1	1
E-18	52	HPD6-90430-003	WASHER, SEALING, 6MM	1	1
E-18	53	HZB7-90691-003	CLIP, HARNESS	2	2
E-18	54	HMJ0-91301-003	O-RING, 7.8X1.9(ARAI)	2	2
E-18	55	HZW1-91554-000	COLLAR, 8.5X14.5	3	3
E-18	56	HZW5-32168-003	BAND	1	1
E-18	57	HZY3-90054-000	BOLT, FLANGE, 8X35	2	2


FR. 

Ref.No.	Part No.	Description	Q'ty		Remarks
			BFT200A	BFT225A	
E-18-2	1	HZX2-16024-003	SCREW SET, DRAIN	1	1
E-18-2	2	HGHB-16163-600	CLIP, TUBE	1	1
E-18-2	3	HZX2-16736-003	STAY COMP.	1	1
E-18-2	4	HZY3-16753-000	STAY, FUEL PIPE A	1	1
E-18-2	5	HZY3-16754-000	STAY, FUEL PIPE B	2	2
E-18-2	6	HZX2-16800-003	SEPARATOR ASSY., WATER	1	1
E-18-2	7	HZX2-16805-003	CUP SET, WATER SEPARATOR	1	1
E-18-2	8	HZY3-16807-003	BUFFER, PLATE	1	1
E-18-2	9	HZX2-16814-000	STAY, WATER SEPARATOR	1	1
E-18-2	10	HZX2-16860-C00	TUBE COMP. B, FUEL	1	1
E-18-2	11	HZX2-16880-C00	TUBE COMP. D, FUEL	1	1
E-18-2	12	HZX2-16890-C00	TUBE COMP. E, FUEL	1	1
E-18-2	13	HZX2-16900-003	STRAINER ASSY., FUEL	1	1
E-18-2	14	HZZ5-16901-003	FILTER	1	1
E-18-2	15	HZY3-16904-003	SCREW, PAN, 5X12	3	3
E-18-2	16	HZZ5-16906-003	FLOAT	1	1
E-18-2	17	HZX2-16912-003	CUP	1	1
E-18-2	18	HZX2-16914-000	STAY, FUEL STRAINER	1	1
E-18-2	19	HZY3-16915-010	SUSPENSION, STRAINER	1	1
E-18-2	20	HZZ5-16915-000	SUSPENSION, STRAINER	1	1
E-18-2	21	HZY3-16918-003	O-RING	1	1
E-18-2	22	HZZ5-16918-003	O-RING	1	1
E-18-2	23	HZY3-16919-003	PLATE	1	1
E-18-2	24	HZZ5-16919-003	O-RING	1	1
E-18-2	25	HZX2-16940-003	COCK ASSY., FUEL DRAIN	1	1
E-18-2	26	HZW9-90014-000	BOLT, FLANGE, 6X10	2	2
E-18-2	27	HZY3-90056-000	BOLT, FLANGE, 6X12	3	3
E-18-2	28	H921-90602-000	CLIP, TUBE(B8)	1	1
E-18-2	29	HZV0-90604-000	CLIP, TUBE(B12)	3	3


FR. 

[illegible]



Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
E-18-10	1	HZY3-16193-A00	CLAMP, CHECK VALVE	1	1	
E-18-10	2	HZY3-16196-A00	TUBE, CHECK VALVE	1	1	
E-18-10	3	HZY3-16197-000	TUBE A, AIR VENT	1	1	
E-18-10	4	HZY3-16198-A00	TUBE B, AIR VENT	1	1	
E-18-10	5	HZY3-16199-A00	TUBE COMP., AIR VENT	1	1	
E-18-10	6	HZY3-16751-000	PIPE, FUEL	1	1	
E-18-10	7	H759-16911-003	STRAINER, FUEL PUMP	1	1	
E-18-10	8	HZW5-16915-000	SUSPENSION, STRAINER	1	1	
E-18-10	9	HVM0-16965-771	CLAMP, HOSE	2	2	
E-18-10	10	HKY7-17450-740	CLIP, TUBE	2	2	
E-18-10	11	HZY3-17721-000	JOINT, FUEL RETURN	1	1	
E-18-10	12	HZY3-17723-A01	HOSE A, PRESSURE REGULATOR	1	1	RETURN
E-18-10	13	HZY3-17724-010	HOSE B, PRESSURE REGULATOR	1	1	RETURN
E-18-10	14	HZY3-19258-010	TUBE, WATER IN.	1	1	
E-18-10	15	HZY3-19259-000	TUBE, WATER OUTLET	1	1	
E-18-10	16	HZY6-19269-000	T-JOINT	1	1	
E-18-10	17	HZY6-36135-003	VALVE, CHECK	1	1	
E-18-10	18	HZW5-90601-030	CLAMP, TUBE(D10.7)	4	4	
E-18-10	19	HZY3-90601-030	CLAMP, TUBE(D10.5)	4	4	
E-18-10	20	HMB1-90655-921	CLIP, WIRE	1	1	
E-18-10	21	HSL0-91592-A51	CLAMP, FUEL TUBE	1	1	
E-18-10	22	HCO-95001-35055-40	TUBE, FUEL, 3.5X55	1	1	(HC-95001-35001-60M)
E-18-10	23	HCO-95003-05060-31	TUBE, VINYL, 3.5X6.5X600	1	1	(HC-95003-05001-60M)

FR. 


Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
E-19	1	HPR7-31105-A01	HOLDER ASSY., BRUSH	1	1
E-19	2	HPT0-31111-003	BEARING, RR. GENERATOR	1	1
E-19	3	HPT0-31114-013	BEARING, FR. GENERATOR	1	1
E-19	4	HPT0-31118-003	BUSH, INSULATION	4	4
E-19	5	HPD1-31138-004	COVER, BEARING	1	1
E-19	6	HP13-31141-003	PULLEY	1	1
E-19	7	HPD1-31142-004	NUT, PULLEY LOCK	1	1
E-19	8	HPD1-31145-004	BOLT, STUD, 6X68	4	4
E-19	9	HPT0-31146-003	SCREW	4	4
E-19	10	HP13-31147-003	SCREW	1	1
E-19	11	HPT0-31147-003	SCREW-WASHER	3	3
E-19	12	HP13-31148-003	SCREW, WAVE WASHER	4	4
E-19	13	HPT0-31148-003	SCREW, WAVE WASHER	2	2
E-19	14	HZY3-31630-003	GENERATOR ASSY., A.C.	1	1
E-19	15	HZY3-31631-003	ROTOR ASSY.	1	1
E-19	16	HZY3-31637-000	STAY, A.C. GENERATOR	1	1
E-19	17	HZY3-31639-003	END COVER, RR.	1	1
E-19	18	HZY3-31694-003	BUSH, INSULATION	1	1
E-19	19	HZY3-31710-003	RECTIFIER ASSY.	1	1
E-19	20	HZY3-31750-003	REGULATOR ASSY.	1	1
E-19	21	HZX2-90002-000	BOLT, FLANGE, 10X90	1	1
E-19	22	HZW5-90011-010	BOLT, SPECIAL ADJUSTER	1	1
E-19	23	HZY3-90017-000	BOLT, FLANGE, 6X16	1	1
E-19	24	HZY3-90055-000	BOLT, TENSIONER	1	1
E-19	25	HZW5-90203-010	NUT, FLANGE, 8MM	1	1
E-19	26	HPD1-90231-014	NUT-WASHER, 5MM	7	7
E-19	27	HCO-94001-06080-0S	NUT, HEX., 6MM	1	1




[illegible]




[illegible]




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
E-21	1	HZY3-31200-003	MOTOR ASSY., STARTER	1	1	
E-21	2	HP5A-31201-005	ROTOR COMP.	1	1	
E-21	3	HZY3-31207-003	CLUTCH COMP., OVERRUNNING	1	1	
E-21	4	HPY3-31215-004	GEAR ASSY., PLANETARY	3	3	
E-21	5	HZY3-31216-003	YOKE COMP.	1	1	
E-21	6	HPY3-31218-004	BALL, STEEL	1	1	
E-21	7	HZW1-31226-004	BRUSH SET	1	1	
E-21	8	HZW1-31229-004	STOPPER SET, SLEEVE	1	1	
E-21	9	HZW1-31231-004	HOLDER COMP., BRUSH	1	1	
E-21	10	HZY3-31235-003	BRACKET, FR.	1	1	
E-21	11	HZY3-31236-003	BRACKET, RR.	1	1	
E-21	12	HZY3-31240-003	SWITCH ASSY., MAGNET	1	1	
E-21	13	HZY3-31242-003	SHAFT ASSY., CLUTCH	1	1	
E-21	14	HP5A-31243-005	BOLT A, THROUGH	2	2	
E-21	15	HZY3-31246-003	SHAFT ASSY., GEAR	1	1	
E-21	16	HZY3-31247-003	GEAR ASSY., INTERNAL	1	1	
E-21	17	HZY3-31249-003	PACKING	1	1	
E-21	18	HZY3-31250-003	LEVER SET	1	1	
E-21	19	HZY3-90002-000	BOLT, FLANGE, 10X90	1	1	
E-21	20	HZY3-90003-000	BOLT, FLANGE, 10X110	1	1	
E-21	21	HZW1-90106-004	SCREW, PAN, 6X22(SPECIAL)	2	2	
E-21	22	HZW1-90107-004	SCREW, PAN, 5X8	2	2	
E-21	23	HZY3-91303-000	O-RING, 59.4X3.1	1	1	




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
F-2	1	HKN5-17224-670	WASHER, AIR CLEANER COVER	1	1	SETTING
F-2	2	HZY3-17877-000	PLATE, REMOTE CONTROL CABLE	1	1	
F-2	3	HZY3-17931-000	ARM, THROTTLE	1	1	
F-2	4	H921-17936-000	WASHER, PIVOT	2	2	
F-2	5	HZW1-24210-010	SPRING COMP., CLICK	1	1	
F-2	6	HZY3-24221-000	SPRING, CLICK ASSIST	1	1	
F-2	7	HZW1-24327-000	RING, STOPPER	1	1	
F-2	8	HZY3-24610-A00	SHAFT COMP., SHIFT(A)	1	1	
F-2	9	HZY3-24612-010	ARM, SHIFT	1	1	
F-2	10	HZY3-24613-000	ROD, LINK	1	1	
F-2	11	HZY3-24617-000	COLLAR, SHIFT SLIDER	1	1	
F-2	12	HZY3-24618-000	PIVOT, SHIFT	2	2	
F-2	13	HZY3-24619-000	PLATE, LOCK	2	2	
F-2	14	HZY3-24620-000	SHAFT COMP., SHIFT(B)	1	1	
F-2	15	HZY3-24623-000	BUSH, SHIFT ARM	1	1	
F-2	16	HZY3-24628-000	BRACKET, SHIFT LINK	1	1	
F-2	17	HZW1-24629-000	HOLDER, SEAL	1	1	
F-2	19	HZY3-35476-010	BRACKET, NEUTRAL SWITCH	1	1	
F-2	20	HZY3-35477-000	COVER, NEUTRAL SWITCH	1	1	
F-2	21	HS0X-46392-A01	CLIP, BRAKE PIPE	1	1	
F-2	22	HZW9-90011-000	BOLT, FLANGE, 6X14(CT200)	2	2	
F-2	23	HZY3-90017-000	BOLT, FLANGE, 6X16	1	1	
F-2	24	HZW5-90023-000	BOLT, FLANGE, 6X11	2	2	
F-2	25	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	
F-2	26	HZV4-90127-000	BOLT, HEX., 6X16	1	1	
F-2	27	HZV5-90302-003	NUT, HEX., 20MM	1	1	
F-2	28	HHA0-90402-000	WASHER, THRUST, 14MM	1	1	
F-2	29	H958-90428-000	WASHER B, THRUST, 14MM	1	1	
F-2	30	HZV4-90506-000	WASHER, PLAIN, 6MM	1	1	





[illegible]





Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
F-3	1	HZY3-06125-C00		1	
F-3	2	HZW1-19286-B00	1	1	
F-3	4	HZY3-41101-C00ZC	1	1	*T107* BAY BLUE
F-3	5	HZW1-41102-B00	1	1	
F-3	6	HZX2-41102-E00ZC	1	1	*T107* BAY BLUE XCA
F-3	7	HZY3-41104-C01	1	1	
F-3	8	HZY3-41105-C01	1	1	
F-3	9	HZX2-41107-C00ZC	1	1	*T107* BAY BLUE LA,XA
F-3	10	HZW1-41109-B00	2	2	
F-3	11	HZW9-90101-003	1	1	
F-3	12	HZZ0-90101-000	1	1	
F-3	13	HZY6-90103-000	1	1	
F-3	14	HZY3-90120-000	1	1	
F-3	15	HZY3-90124-000	1	1	
F-3	19	HZY1-90205-000	1	1	
F-3	20	HZV4-90302-000	1	1	
F-3	22	HZW1-90308-003	1	1	
F-3	23	HZV5-90559-000	1	1	
F-3	25	HZV5-90756-000	2	2	
F-3	26	HZW1-90758-B00		1	
F-3	27	HZY3-91251-C01		2	
F-3	28	HZZ3-91252-003		2	
F-3	29	HZY3-91254-003		2	
F-3	30	HZW4-91301-003	2	2	
F-3	31	HZW4-91301-003		2	
F-3	32	HMJ0-91308-003		1	
F-3	33	HZY3-91351-C00		1	
F-3	34	HCO-92101-06055-4J	1	1	
F-3	35	HZX2-90107-C00	6	6	



←FR.




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-3-20	1	HZY3-19270-000	NUT, WATER MOUTH	1	1	
F-3-20	2	HZY3-19271-000	JOINT, WATER HOSE	1	1	
F-3-20	3	HZY3-19272-000	SEAT, WATER MOUTH	1	1	
F-3-20	4	HZY3-19289-000	CAP, WATER JOINT	1	1	
F-3-20	5	HZY3-35640-013	SWITCH ASSY., POWER TILT	1	1	
F-3-20	6	HZY3-35645-000	STAY, POWER TILT SWITCH	1	1	
F-3-20	7	HZV5-40107-000	GROMMET, UNDER CASE(C)	1	1	
F-3-20	8	HZY3-40114-010	GROMMET, POWER TILT SWITCH	1	1	
F-3-20	9	HZY3-40151-000ZC	COVER, FR. SEPARATE	1	1	*T107* BAY BLUE
F-3-20	10	HZY3-40201-020ZC	CASE, EXTENSION	1	1	*T107* BAY BLUE LA
F-3-20		HZY3-40201-612ZC	CASE, EXTENSION	1	1	*T107* BAY BLUE XA,XCA
F-3-20	11	HZW1-40209-000	RUBBER, DRAIN PLUG	1	1	
F-3-20	12	HZY3-40210-610	BUSH COMP., VERTICAL SHAFT	1	1	XA,XCA
F-3-20	13	HZY3-40212-010ZC	COVER, DRAIN PLUG(L)	1	1	*T107* BAY BLUE LA
F-3-20		HZY3-40212-611ZC	COVER, DRAIN PLUG(XL)	1	1	*T107* BAY BLUE XA,XCA
F-3-20	14	HZY3-40225-010	SEAL, R. IDOL PORT	1	1	
F-3-20	15	HZY3-40226-010	SEAL, L. IDOL PORT	1	1	
F-3-20	16	HZY3-50111-020	HOUSING, LOWER MOUNTING	2	2	
F-3-20	17	HZY3-50155-000	MOUNT COMP., LOWER RUBBER	2	2	
F-3-20	18	HZY3-50157-010	STOPPER, LOWER MOUNT	2	2	
F-3-20	19	HZY3-63347-C00	COVER, PLUG MAINTENANCE	1	1	
F-3-20	20	HZY3-63710-C00ZC	COVER COMP., R. UNDER ENGINE	1	1	*T107* BAY BLUE
F-3-20	21	HZY3-63715-C01ZC	COVER COMP., L. UNDER ENGINE	1	1	*T107* BAY BLUE
F-3-20	22	HZY3-63718-000	SEAL A, COVER UNDER	1	1	
F-3-20	23	HZX2-63719-C00	SEAL B, COVER UNDER	1	1	
F-3-20	24	HZY3-63722-010ZC	CAP, UNDER COVER	1	1	*T107* BAY BLUE
F-3-20	25	HZY3-63728-000	SEAL C, UNDER COVER	1	1	
F-3-20	26	HZY3-63731-A03ZC	COVER, R. LOWER MOUNTING	1	1	*T107* BAY BLUE LA
F-3-20		HZY3-63731-A12ZC	COVER, R. LOWER MOUNTING	1	1	*T107* BAY BLUE XA,XCA




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
F-3-20	27	HZY3-63736-A03ZC	COVER, L. LOWER MOUNTING	1	1	*T107* BAY BLUE LA
F-3-20		HZY3-63736-A12ZC	COVER, L. LOWER MOUNTING	1	1	*T107* BAY BLUE XA,XCA
F-3-20	28	HZY3-63751-C00	GROMMET, R. IDLE PORT	1	1	
F-3-20	29	HZY3-63756-C00	GROMMET, L. IDLE PORT	1	1	
F-3-20	30	HZV5-82873-003	GROMMET, WATER CHECK	1	1	
F-3-20	31	HZY3-90102-A00	BOLT, HEX., 10X35	6	6	
F-3-20	32	HZY3-90105-010	BOLT, HEX., 14X180	2	2	
F-3-20	33	HZV5-90110-000	SCREW, SPECIAL, 6X35	1	1	
F-3-20	34	HZY3-90111-000	BOLT, SPECIAL, 6X17	26	26	
F-3-20	36	HZY3-90113-C00	BOLT, SPECIAL, 6X22	1	1	
F-3-20	37	HZY3-90122-000	BOLT, HEX., 12X50	11	11	
F-3-20	38	HZY3-90129-A00	BOLT, SPECIAL, 6X12	2	2	
F-3-20	39	HZY3-90132-000	BOLT, SPECIAL, 6X37	2	2	
F-3-20	40	HZY3-90134-000	SCREW-WASHER, 6X40	1	1	LA
F-3-20		HCO-93500-06025-4J	SCREW, PAN, 6X25	1	1	XA,XCA
F-3-20	41	H921-90302-000	NUT, HEX., 16MM	1	1	
F-3-20	42	HZY3-90302-000	NUT, SELF-LOCK, 14MM	2	2	
F-3-20	43	HZY3-90503-610	WASHER, 30MM	1	1	XA,XCA
F-3-20	44	HZY3-90511-000	WASHER, PLAIN, 14MM	2	2	
F-3-20	46	HZV5-90559-000	WASHER, PLAIN, 12MM	11	11	
F-3-20	47	HZV5-90563-000	WASHER, PLAIN, 10MM	6	6	
F-3-20	48	HZV4-90605-000	CLIP, TUBE(B12.5)	1	1	
F-3-20	49	HZY3-90652-000	CIRCLIP, INTERNAL, 43	1	1	XA,XCA
F-3-20	50	HSA0-90683-003	CLIP, WIRE HARNESS, 25MM	1	1	
F-3-20	51	HZV5-90756-000	DOWEL PIN, 6X10	2	2	
F-3-20	52	HZY3-91451-000	TUBE, WATER JOINT	1	1	
F-3-20	53	HZY3-91552-000	COLLAR, 6.2X10X25.5	1	1	LA
F-3-20		HZY6-91553-000	COLLAR, DISTANCE, 6.5X9X5	1	1	XA,XCA
F-3-20	54	HZV5-91563-000	COLLAR, DISTANCE, 6X10.5X25	1	1	



[illegible]




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-4	1	HZY3-19210-003	IMPELLER, PUMP	1	1	
F-4	2	HZY3-19221-010	HOUSING, IMPELLER	1	1	
F-4	3	HZY3-19223-000	LINER, PUMP	1	1	
F-4	4	HZY3-19231-000	COVER, IMPELLER	1	1	
F-4	5	HZY3-19234-000	GASKET B, IMPELLER	1	1	
F-4	6	HZY3-19241-000	HOUSING, WATER PUMP	1	1	
F-4	7	HZY3-19251-000	TUBE, WATER(L)	1	1	LA
F-4		HZY3-19251-611	TUBE, WATER(XL)	1	1	XA,XCA
F-4	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	
F-4	9	HZY3-24310-C00	ROD COMP., SHIFT	1	1	LA,XA
F-4		HZY3-24310-E00	ROD COMP., SHIFT	1	1	(COUNTER ROTATION) XCA
F-4	10	HZY3-24318-000	SPRING, SHIFT ROD	1	1	
F-4	11	HZY6-24320-000	ROD COMP. A, SHIFT(L)	1	1	LA
F-4		HZY6-24320-610	ROD COMP. A, SHIFT(XL)	1	1	XA,XCA
F-4	12	HZW1-24343-B02	HOLDER, SHIFT ROD	1	1	
F-4	13	HZY3-40204-000	GROMMET, EXTENSION CASE	1	1	
F-4	14	HZY3-41112-010	SHAFT, VERTICAL(L)	1	1	LA
F-4		HZY3-41112-611	SHAFT, VERTICAL(XL)	1	1	XA,XCA
F-4	15	HZY3-41116-000	SLINGER, OIL	1	1	
F-4	16	HZX2-90105-C00	BOLT, WASHER, 8X60	4	4	
F-4	17	HHW1-90215-671	BOLT, FLANGE, 6X16	1	1	
F-4	18	HZW1-90242-000	NUT, LOCK, 64MM	1	1	
F-4	19	HZY3-90303-000	NUT, HEX., 18MM	1	1	
F-4	20	H723-90472-000	WASHER, PLAIN, 12MM	1	1	
F-4	21	HZW1-90518-B00	SHIM A, GEAR(0.10)	1	1	
F-4		HZW1-90519-B00	SHIM B, GEAR(0.15)	1	1	
F-4		HZW1-90520-B00	SHIM C, GEAR(0.30)	1	1	
F-4		HZW1-90521-B00	SHIM D, GEAR(0.50)	1	1	
F-4	22	HZY3-90752-003	KEY, WOODRUFF	1	1	




[illegible]


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-5	1	HZY3-24101-A01	SHIFTER, CLUTCH	1	1	LA,XA
F-5	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	LA,XA
F-5	3	HZY3-24103-000	RING, CROSS PIN	1	1	LA,XA
F-5	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	LA,XA
F-5	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	LA,XA
F-5	6	HZY3-24123-000	SPRING, SHIFT	2	2	LA,XA
F-5	7	HZY3-24124-310	PLATE, SHIFT	1	1	LA,XA
F-5	8	HZY3-41130-C00	GEAR SET	1	1	LA,XA
F-5	9	HZY3-41151-C00	GEAR, BEVEL(RVS. 28T)	1	1	LA,XA
F-5	10	HZY3-41161-A00	SHAFT, PROPELLER	1	1	LA,XA
F-5	11	HZY3-41201-C00ZC	HOLDER, PROPELLER SHAFT	1	1	*T107* BAY BLUE LA,XA
F-5	12	HZY3-41202-000	HOLDER, BEARING	1	1	LA,XA
F-5	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	LA,XA
F-5	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	LA,XA
F-5	15	HZY3-90506-000	WASHER, PROPELLER THRUST	1	1	LA,XA
F-5	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	LA,XA
F-5	17	HZY3-90512-000	WASHER, PROPELLER	1	1	LA,XA
F-5	18	HZY3-90528-000	SHIM A, BEVEL(0.10)	2	2	LA,XA
F-5		HZY3-90529-000	SHIM B, BEVEL(0.15)	2	2	LA,XA
F-5		HZY3-90530-000	SHIM C, BEVEL(0.30)	2	2	LA,XA
F-5		HZY3-90531-000	SHIM D, BEVEL(0.50)	2	2	LA,XA
F-5	19	HZY3-90548-000	SHIM A, THRUST(2.75)	1	1	LA,XA
F-5		HZY3-90549-000	SHIM B, THRUST(2.80)	1	1	LA,XA
F-5		HZY3-90550-000	SHIM C, THRUST(2.85)	1	1	LA,XA
F-5		HZY3-90551-000	SHIM D, THRUST(2.90)	1	1	LA,XA
F-5		HZY3-90552-000	SHIM E, THRUST(2.95)	1	1	LA,XA
F-5		HZY3-90553-000	SHIM F, THRUST(3.00)	1	1	LA,XA
F-5		HZY3-90554-000	SHIM G, THRUST(3.05)	1	1	LA,XA
F-5		HZY3-90555-000	SHIM H, THRUST(3.10)	1	1	LA,XA




[illegible]




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-5-1	1	HZY3-24101-A01	SHIFTER, CLUTCH	1	1	XCA
F-5-1	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	XCA
F-5-1	3	HZY3-24103-000	RING, CROSS PIN	1	1	XCA
F-5-1	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	XCA
F-5-1	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	XCA
F-5-1	6	HZY3-24123-000	SPRING, SHIFT	2	2	XCA
F-5-1	7	HZY3-24124-310	PLATE, SHIFT	1	1	XCA
F-5-1	8	HZY3-41130-E00	GEAR SET(COUNTER ROTATION)	1	1	XCA
F-5-1	9	HZY3-41150-E00	GEAR COMP., BEVEL(RVS. 28T)	1	1	(COUNTER ROTATION) XCA
F-5-1	10	HZY3-41161-B00	SHAFT, PROPELLER	1	1	(COUNTER ROTATION) XCA
F-5-1	11	HZY3-41201-C00ZC	HOLDER, PROPELLER SHAFT	1	1	*T107* BAY BLUE XCA
F-5-1	12	HZY3-41202-700	HOLDER, BEARING(C/R)	1	1	XCA
F-5-1	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	XCA
F-5-1	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	XCA
F-5-1	15	HZY3-90506-000	WASHER, PROPELLER THRUST	1	1	XCA
F-5-1	16	HZW5-90509-711	WASHER, THRUST BEARING	2	2	XCA
F-5-1	17	HZY3-90512-000	WASHER, PROPELLER	1	1	XCA
F-5-1	18	HZY3-90528-000	SHIM A, BEVEL(0.10)	2	2	XCA
F-5-1		HZY3-90529-000	SHIM B, BEVEL(0.15)	2	2	XCA
F-5-1		HZY3-90530-000	SHIM C, BEVEL(0.30)	2	2	XCA
F-5-1		HZY3-90531-000	SHIM D, BEVEL(0.50)	2	2	XCA
F-5-1	19	HZW5-90548-710	SHIM A, THRUST(0.10)	1	1	XCA
F-5-1		HZW5-90549-710	SHIM B, THRUST(0.15)	1	1	XCA
F-5-1		HZW5-90550-710	SHIM C, THRUST(0.30)	1	1	XCA
F-5-1		HZW5-90551-710	SHIM D, THRUST(0.50)	1	1	XCA
F-5-1	20	HZV5-90559-000	WASHER, PLAIN, 12MM	2	2	XCA
F-5-1	21	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	XCA
F-5-1	22	HPT2-91005-N01	BEARING, THRUST(F)	1	1	XCA
F-5-1	23	HZY3-91051-003	BEARING, TAPER, 50X90X21.5	1	1	XCA





[illegible]




[illegible]




[illegible]





Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-7-11	1	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	3	3	
F-7-11	2	HZY9-32103-000	BRACKET C, COUPLER	2	2	
F-7-11	3	HZX2-32410-000	CABLE ASSY., STARTER	1	1	
F-7-11	4	HZY3-32411-003	COVER, STARTER TERMINAL	1	1	
F-7-11	5	HZX2-32414-300	COVER B, TERMINAL(L)	2	2	
F-7-11	6	HZY6-32414-640	COVER B, TERMINAL	1	1	
F-7-11	7	HZX2-32415-000	CABLE ASSY., POWER TILT RELAY	1	1	
F-7-11	8	HZX2-32435-000	CORD, A.C. GENERATOR	1	1	
F-7-11	9	HZX2-38550-003	RELAY ASSY., POWER TILT	1	1	
F-7-11	10	HZW1-38551-000	GROMMET, RELAY	2	2	
F-7-11	11	HZX2-38552-000	CASE, POWER TILT RELAY	1	1	
F-7-11	12	HZW2-90003-000	BOLT-WASHER, 6X27(CT200)	3	3	
F-7-11	13	HZW1-90013-000	BOLT-WASHER, 6X25	2	2	
F-7-11	14	HZW9-90013-000	BOLT, FLANGE, 6X12	4	4	
F-7-11	15	HZW9-90014-000	BOLT, FLANGE, 6X10	2	2	
F-7-11	16	HZY3-90107-000	BOLT, FLANGE, 8X18	1	1	
F-7-11	17	HZW1-90203-000	NUT-WASHER, 8MM	2	2	
F-7-11	18	HZY3-90304-000	NUT-WASHER, 6MM	1	1	
F-7-11	19	HZY3-90405-000	WASHER, PLAIN, 8MM	1	1	
F-7-11	20	HSB2-90620-003	BAND, WIRE HARNESS	1	1	
F-7-11	21	H763-90681-A01	CLIP, WIRE HARNESS	1	1	
F-7-11	22	HZX2-90683-003	CLIP, WIRE HARNESS	2	2	
F-7-11	23	HZZ5-91501-000	COLLAR, MOUNTING(6MM)	2	2	
F-7-11	24	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	4	4	(145MM)
F-7-11	25	HZV5-91553-010	COLLAR, C.D.I. UNIT CASE	3	3	





[illegible]




[illegible]




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-8-10	1	HZY3-32419-A00	BRACKET, CABLE	1	1	
F-8-10	2	HZY3-32421-000	PLATE, STARTER CABLE	1	1	
F-8-10	3	HZY3-40105-C01	GROMMET A, UNDER CASE	1	1	
F-8-10	4	HZY3-40119-003	BAND, UNDER CASE GROMMET	1	1	
F-8-10	5	HZY3-40154-000ZA	BRACKET, FR. COVER	1	1	*NH8* DARK GRAY
F-8-10	6	HZY3-40155-000	BRACKET, R. SIDE COVER	1	1	
F-8-10	7	HZY3-40157-000	BRACKET, L. SIDE COVER	1	1	
F-8-10	8	HZY3-40158-000	BRACKET A, RR. COVER	1	1	
F-8-10	9	HZY3-40159-000	BRACKET B, RR. COVER	2	2	
F-8-10	10	H196-47117-000	RUBBER, STOPPER	4	4	
F-8-10	11	H121-51640-730	RUBBER, FR. CARRIER CUSHION	6	6	
F-8-10	12	HZY3-60180-C01	CABLE COMP. A, COVER LOCK	1	1	
F-8-10	13	HZY3-60185-C01	CABLE COMP. B, COVER LOCK	1	1	
F-8-10	14	HZY3-63201-000ZC	LEVER, COVER LOCK	1	1	*T107* BAY BLUE
F-8-10	15	HZY3-63205-000	BUSH A, COVER LOCK	10	10	
F-8-10	16	HZY3-63208-000	BUSH B, COVER LOCK	1	1	
F-8-10	17	HZY3-63212-000	SPRING, COVER LOCK HOOK	4	4	
F-8-10	18	HZY3-63223-000	SPRING, LOCK LEVER RETURN	1	1	
F-8-10	19	HZY3-63224-000	SHAFT, COVER OPEN	1	1	
F-8-10	20	HZY3-63225-000	SHAFT, FR. LOCK	1	1	
F-8-10	21	HZY3-63226-000	HOLDER, STRIKER	2	2	
F-8-10	22	HZY3-63230-C00	LOCK ASSY., FR.	1	1	
F-8-10	23	HZX2-63260-C00	LOCK COMP., SIDE	2	2	
F-8-10	24	HZC0-63515-700	CAP, L. SIDE COVER	1	1	
F-8-10	25	HZY3-63729-003	SEAL D, UNDER COVER	1	1	
F-8-10	26	HZV5-90009-000	BOLT, HEX., 8X35	6	6	
F-8-10	27	HZY3-90021-000	BOLT, FLANGE, 6X14	2	2	
F-8-10	28	HML0-90101-720	WASHER, PLAIN, 8MM	6	6	
F-8-10	29	HZW9-90102-000	BOLT, FLANGE, 6X12	6	6	




[illegible]




[illegible]




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
F-10	1	HZW1-06411-020	METAL KIT, ANODE	1	1	
F-10	2	HZY3-06412-000	TUBE KIT, SPEED SENSOR	1	1	
F-10	3	HZY3-06532-U00	ROD KIT, STEERING	1	1	
F-10	4	HZV1-24210-010	SPRING COMP., CLICK	1	1	
F-10	5	HZV4-24221-010	SPRING, CLICK ASSIST	1	1	
F-10	6	HKM3-32161-003	BAND, WIRE	2	2	
F-10	7	HZY3-35660-003	SENSOR ASSY., TRIM ANGLE	1	1	
F-10	8	H663-38562-920	JOINT B, WASHER TUBE(MITSUBA)	1	1	
F-10	9	HZY3-40219-013	WIRE, LEAD(1.5X116MM)	1	1	
F-10	10	HZV5-41171-000	END, NIPPLE	1	1	
F-10	11	HZV5-41172-000	NIPPLE, SENSOR	1	1	
F-10	12	HZY3-41179-A00	CLAMPER, SENSOR TUBE	2	2	
F-10	13	HZY3-50100-A01	FRAME COMP., MOUNTING(L)	1	1	LA
F-10		HZY3-50100-A11	FRAME COMP., MOUNTING(XL)	1	1	XA,XCA
F-10	14	HZY3-50109-000	HOUSING, UPPER MOUNTING	1	1	
F-10	15	HZY3-50151-000	MOUNT COMP., UPPER RUBBER	2	2	
F-10	16	HZY3-50153-000	RUBBER, UPPER MOUNT STOPPER	2	2	
F-10	17	HZY3-50161-000ZD	HOUSING, LOWER CENTER MOUNTING	1	1	*T107* BAY BLUE LA
F-10		HZY3-50161-610	HOUSING, LOWER CENTER MOUNTING	1	1	(XL)XA,XCA
F-10	18	HZY3-50166-000	COVER, UPPER MOUNT	1	1	
F-10	19	HZY3-50168-000	SEAL, UPPER MOUNT COVER	1	1	
F-10	20	HZY3-50201-C01ZD	CASE, SWIVEL	1	1	*T107* BAY BLUE LA
F-10		HZY3-50201-C11ZC	CASE, SWIVEL	1	1	*T107* BAY BLUE XA,XCA
F-10	21	HZY3-50209-A00	CLAMP, TUBE	2	2	
F-10	22	HZY3-50211-000	LINER, SWIVEL CASE	2	2	
F-10	23	HZY3-50214-000	BUSH, SWIVEL CASE	2	2	
F-10	24	HZY3-50301-030ZC	BRACKET, R. STERN	1	1	*T107* BAY BLUE
F-10	25	HZY3-50311-020ZC	BRACKET, L. STERN	1	1	*T107* BAY BLUE
F-10	26	HZY3-50381-000	SHAFT, TILTING	1	1	




Ref.No.	Part No.	Description	Q'ty		Remarks
			BFT200A	BFT225A	
F-10	27	HZY3-50522-000	BUSH, TILT ARM	2	2
F-10	28	HZY3-50527-000	BRACKET, TILTING	1	1
F-10	29	HZY3-50529-000	STOPPER, TILT	2	2
F-10	30	HZY3-56516-A00	RECEIVER, THRUST	2	2
F-10	31	HZY3-56518-A00	BUSH A, THRUST RECEIVE	2	2
F-10	32	HZY3-56519-A00	BUSH B, THRUST RECEIVE	2	2
F-10	33	HZW1-56539-000	COLLAR, LOWER CYLINDER	1	1
F-10	34	HZW9-90005-000	BOLT, FLANGE, 6X20	7	7
F-10	35	HZW9-90009-000	BOLT, FLANGE, 6X23	2	2
F-10	36	HZW1-90102-000	BOLT, 1/4-28UNF	2	2
F-10	37	HZW9-90103-010	BOLT, FLANGE, 6X12	1	1
F-10	38	HZY6-90103-000	BOLT-WASHER, 10X32	3	3
F-10	39	HZY3-90104-010	BOLT, HEX., 12X200	2	2
F-10	40	HZW9-90105-000	BOLT, FLANGE, 6X20	2	2
F-10	41	HZW1-90108-000	BOLT, HEX., 10X235	1	1
F-10	42	H881-90110-000	BOLT, HEX., 6X14	1	1
F-10	43	HZY3-90117-000	BOLT, 3/8-24UNF	1	1
F-10	44	HZV5-90119-000	SCREW, PAN, 6X8	1	1
F-10	45	HZV5-90127-003	SCREW, RIVET, 5X10	2	2
F-10	46	HZX2-90129-000	BOLT, HEX., 12X130	6	6
F-10	47	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2	2
F-10	48	HZW5-90302-003	NUT, FLANGE, 12MM	2	2
F-10	49	HZV5-90304-013	NUT, SELF-LOCK(7/8-14UNF)	1	1
F-10	50	HZW1-90304-013	NUT, SELF-LOCK(25X2.0)	1	1
F-10	51	HZW4-90306-003	NUT, FLANGE, 10MM	1	1
F-10	52	HZV5-90307-003	NUT, SELF-LOCK(3/8-24UNF)	2	2
F-10	53	HZV5-90501-000	WASHER, WAVE, 40MM	1	1
F-10	54	HZY3-90501-A00	WASHER, WAVE, 12MM	2	2
F-10	55	HZV5-90502-000	WASHER, WAVE, 26MM	2	2





Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
F-10	56	HZV5-90504-000	WASHER, THRUST, 34MM	1	1	
F-10	57	HZY3-90504-A00	WASHER, UPPER MOUNTING STOPPER	2	2	
F-10	58	HZY3-90509-000	WASHER, 7/8INCH	1	1	
F-10	59	HZY3-90510-000	WASHER, 25MM	1	1	
F-10	60	HZV4-90512-000	WASHER, PLAIN, 6MM	2	2	
F-10	61	HZV4-90514-000	WASHER, 10MM	3	3	
F-10	62	H921-90511-000	WASHER, PLAIN, 10MM	1	1	
F-10	63	HZV5-90552-000	WASHER, PLAIN, 12MM	6	6	
F-10	64	HZV5-90559-000	WASHER, PLAIN, 12MM	14	14	
F-10	65	H921-90602-000	CLIP, TUBE(B8)	1	1	
F-10	66	HZV5-90651-000	CIRCLIP, EXTERNAL, 39MM	1	1	
F-10	67	H763-90681-A01	CLIP, WIRE HARNESS	1	1	
F-10	68	HZV7-90951-010	NIPPLE, GREASE	6	6	
F-10	69	HZV5-91256-003	OIL SEAL, 39.5X52X6(ARAI)	1	1	
F-10	70	HZV5-91352-000	O-RING, 15.54X2.26	1	1	
F-10	71	HZY3-91560-000	COLLAR, STEERING ROD	1	1	
F-10	72	HCO-94001-12490-0S	NUT, HEX., 12MM	12	12	
F-10	73	HCO-94305-30203	PIN, SPRING, 3X20	2	2	
F-10	74	HCO-95005-5020030	TUBE, 5X200	1	1	(HC-95005-50001-30M)
F-10	75	HCO-95005-5095030	TUBE, 5X950	1	1	(HC-95005-50001-30M)
F-10	76	HKM3-32161-003	BAND, WIRE	1	1	
F-10	77	HZV5-90119-000	SCREW, PAN, 6X8	2	2	




Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
F-11	1	HZY3-30280-003	BREAKER ASSY.	1	1
F-11	2	HZY3-31106-003	BRUSH ASSY.	1	1
F-11	3	HMG9-35701-950	BAND(BLACK 3.5X140)	1	1
F-11	4	HZW1-36104-003	TUBE, SPIRAL(12X14.6)	1	1
F-11	5	HZX2-36120-003	MOTOR ASSY., POWER TILT	1	1
F-11	6	HZY3-36122-013	BRACKET ASSY.	1	1
F-11	7	HZY3-36123-013	ARMATURE COMP.	1	1
F-11	8	HZX2-36129-003	YOKE ASSY.	1	1
F-11	9	HZV5-36136-821	SPRING, MOTOR	2	2
F-11	10	HZW1-40107-700	GROMMET, UNDER CASE(C)	3	3
F-11	11	HZY3-40219-013	WIRE, LEAD(1.5X116MM)	1	1
F-11	12	HZV5-50214-003	BUSH, SWIVEL CASE	2	2
F-11	13	HZX2-56000-013	TRIM-TILT ASSY., POWER	1	1
F-11	14	HZY3-56100-013	PUMP ASSY.	1	1
F-11	15	HZW1-56110-701	ROD COMP., PISTON(B)	2	2
F-11	16	HZW1-56113-701	JOINT, DRIVE	1	1
F-11	17	HZY9-56115-003	GUIDE COMP., ROD	2	2
F-11	18	HZW1-56116-701	FILTER B	1	1
F-11	19	HZV5-56117-821	RING, BACK UP	1	1
F-11	20	HZV5-56118-820	BUSH, MOTOR CODE	1	1
F-11	21	HZY3-56120-013	ROD COMP., PISTON	1	1
F-11	22	HZW1-56130-702	PISTON COMP., FREE	1	1
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL	1	1
F-11	24	HZW1-56180-701	VALVE COMP., RESERVOIR	1	1
F-11	25	HZV5-56513-000	BUSH, LOWER CYLINDER	2	2
F-11	26	HZY3-56532-000	PIN, UPPER CYLINDER	1	1
F-11	27	HZW1-56851-703	TANK, OIL	1	1
F-11	28	HZW1-56860-701	CAP COMP., OIL TANK	1	1
F-11	29	HZW1-90113-702	BOLT, RECESSED	3	3




[illegible]



[illegible]




[illegible]




←FR.


[illegible]




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
FOP-3	1	HZZ3-06240-R30	BOX KIT, REMOTE CONTROL	1	1	(TOP MOUNT SINGLE)(R.)
FOP-3	2	HZW5-06241-U00	SPACER KIT, REMOTE CONTROL BOX	1	1	(TOP MOUNT SINGLE)
FOP-3	3	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	(TOP MOUNT)
FOP-3	4	HZW5-24811-U01	HANDLE, REMOTE CONTROL	1	1	
FOP-3	5	HZW5-24812-U01	COVER, L. GRIP	1	1	
FOP-3	6	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	1	1	
FOP-3	7	HZW5-24814-U01	CAP, GRIP	1	1	
FOP-3	8	HZW5-24815-U01	CAP, SWITCH	1	1	
FOP-3	9	HZW5-24816-U01	BUTTON, THROTTLE	1	1	
FOP-3	10	HZW5-24817-U01	PLATE, HANDLE	1	1	
FOP-3	11	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	
FOP-3	12	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	HOUSING
FOP-3	13	HZZ3-24820-R11	HOUSING COMP., REMOTE CONTROL	1	1	BOX
FOP-3	14	HZW5-24825-U01	HOUSING, LEAD	1	1	
FOP-3	15	HZW5-24826-U01	PLATE, DWELL	1	1	
FOP-3	16	HZW5-24831-U01	TERMINAL, CABLE	2	2	
FOP-3	17	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	
FOP-3	18	HZW5-24834-U01	PACKING, SINGLE	1	1	
FOP-3	19	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	TRIM-TILT(A)
FOP-3	20	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	(A)
FOP-3	21	HZZ3-87703-R81	MARK, REMOTE CONTROL(SINGLE)	1	1	
FOP-3	22	HZW5-90101-U00	SCREW, PAN, 5X16	2	2	
FOP-3	23	HZW5-90102-U00	SCREW, PAN, 5X10	1	1	
FOP-3	24	HZW5-90103-U01	SCREW, PAN, 5X20	2	2	
FOP-3	25	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	
FOP-3	26	HZW5-90105-U01	SCREW, PAN, 4X10	2	2	
FOP-3	27	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	
FOP-3	28	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	
FOP-3	29	HZW5-90301-U00	NUT, HEX., 5MM	4	4	




[illegible]



Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
FOP-3-2	1	HZZ3-06240-R60	BOX KIT, REMOTE CONTROL	1	1	(TOP MOUNT DUAL)(R.)
FOP-3-2	2	HZW5-06241-U10	SPACER KIT, REMOTE CONTROL BOX	1	1	(TOP MOUNT DUAL)
FOP-3-2	3	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	(TOP MOUNT)
FOP-3-2	4	HZW5-24810-U11	HOUSING ASSY., R. INNER	1	1	(TOP MOUNT)
FOP-3-2	5	HZW5-24811-U01	HANDLE, REMOTE CONTROL	2	2	
FOP-3-2	6	HZW5-24812-U01	COVER, L. GRIP	1	1	
FOP-3-2	7	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	2	2	
FOP-3-2	8	HZW5-24813-U21	COVER, DUAL GRIP	1	1	
FOP-3-2	9	HZW5-24814-U01	CAP, GRIP	2	2	
FOP-3-2	10	HZW5-24816-U01	BUTTON, THROTTLE	2	2	
FOP-3-2	11	HZW5-24817-U01	PLATE, HANDLE	2	2	
FOP-3-2	12	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	
FOP-3-2	13	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	HOUSING
FOP-3-2	14	HZZ3-24820-R21	HOUSING COMP., REMOTE CONTROL	1	1	BOX(DUAL)
FOP-3-2	15	HZW5-24825-U01	HOUSING, LEAD	2	2	
FOP-3-2	16	HZW5-24826-U01	PLATE, DWELL	2	2	
FOP-3-2	17	HZW5-24831-U01	TERMINAL, CABLE	4	4	
FOP-3-2	18	HZW5-24832-U01	SPACER, CABLE CLAMP	2	2	
FOP-3-2	19	HZW5-24834-U21	PACKING, DUAL	1	1	
FOP-3-2	20	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	TRIM-TILT(A)
FOP-3-2	21	HZW7-32530-U10	SUB HARNESS ASSY., POWER	1	1	TRIM-TILT(B)
FOP-3-2	22	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	(A)
FOP-3-2	23	HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT	1	1	(B)
FOP-3-2	24	HZZ3-87703-R01	MARK, REMOTE CONTROL(DUAL)	1	1	
FOP-3-2	25	HZW5-90101-U00	SCREW, PAN, 5X16	3	3	
FOP-3-2	26	HZW5-90102-U00	SCREW, PAN, 5X10	2	2	
FOP-3-2	27	HZW5-90103-U01	SCREW, PAN, 5X20	4	4	
FOP-3-2	28	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	
FOP-3-2	29	HZW5-90105-U01	SCREW, PAN, 4X10	4	4	



[illegible]



Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
FOP-3-4	1	HZZ3-06240-R40	BOX KIT, REMOTE CONTROL	1	1	(FLUSH MOUNT)(R.)
FOP-3-4	2	HZW7-24810-U01	HOUSING ASSY., R. INNER	1	1	(FLUSH MOUNT)
FOP-3-4	3	HZW7-24811-U01	HANDLE, REMOTE CONTROL	1	1	
FOP-3-4	4	HZW7-24812-U01	COVER, GRIP	1	1	
FOP-3-4	5	HZW7-24813-U01	ARM, NEUTRAL LOCK	1	1	
FOP-3-4	6	HZW7-24814-U01	COVER, LOCK ARM	1	1	
FOP-3-4	7	HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM	1	1	
FOP-3-4	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	
FOP-3-4	9	HZW7-24817-U01	SHAFT, THROTTLE BUTTON	1	1	
FOP-3-4	10	HZW5-24826-U01	PLATE, DWELL	1	1	
FOP-3-4	11	HZZ3-24830-R41	COVER ASSY.	1	1	
FOP-3-4	12	HZW5-24831-U01	TERMINAL, CABLE	2	2	
FOP-3-4	13	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	
FOP-3-4	14	HZW7-24832-U01	HOLDER, NEUTRAL LOCK	1	1	
FOP-3-4	15	HZW7-24833-U01	BASE	1	1	
FOP-3-4	16	HZW7-32530-U20	SUB HARNESS ASSY., POWER	1	1	TRIM-TILT(C)
FOP-3-4	17	HZW7-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	(C)
FOP-3-4	18	HZZ3-87701-R40	MARK, HANDLE FLUSH MOUNT	1	1	
FOP-3-4	19	HZW7-87703-U00	MARK, FLUSH MOUNT	1	1	
FOP-3-4	20	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	
FOP-3-4	21	HZW7-90101-U01	SCREW, TRUSS, 4X12	1	1	
FOP-3-4	22	HZW7-90102-U01	SCREW, PAN, 5X30	4	4	
FOP-3-4	23	HZW7-90103-U01	SCREW, PAN, 6X35	3	3	
FOP-3-4	24	HZW7-90104-U01	SCREW, TAPPING, 6X30	3	3	
FOP-3-4	25	HZW7-90301-U01	NUT, HEX., 6MM	3	3	
FOP-3-4	26	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	
FOP-3-4	27	HZW7-90502-U00	WASHER, PLAIN, 6MM	3	3	
FOP-3-4	28	HCO-94540-06029	E-RING, 6MM	2	2	




Ref.No.		Part No.	Description	Q' ty		Remarks
				BFT200A	BFT225A	
FOP-3-6	1	HZZ3-24800-R00	BOX ASSY., REMOTE CONTROL(EU)	1	1	
FOP-3-6	2	HZV5-24811-010	HANDLE, REMOTE CONTROL	1	1	
FOP-3-6	3	HZV5-24812-000	LEVER, HANDLE LOCK	1	1	
FOP-3-6	4	HZV5-24813-000	GRIP, REMOTE CONTROL HANDLE	1	1	
FOP-3-6	5	HZV5-24814-010	CAP, HANDLE	1	1	
FOP-3-6	6	HZV5-24815-010	BLOCK, NEUTRAL LOCK	1	1	
FOP-3-6	7	HZV5-24816-000	SPRING, REMOTE CONTROL HANDLE	1	1	
FOP-3-6	8	HZV5-24817-000	PLATE, LEVER SETTING	1	1	
FOP-3-6	9	HZV5-24818-003	CLAMP, HARNESS	1	1	
FOP-3-6	10	HZV5-24820-010	HOUSING COMP., REMOTE CONTROL	1	1	BOX(A)
FOP-3-6	11	HZV5-24830-010	HOUSING COMP., REMOTE CONTROL	1	1	BOX(B)
FOP-3-6	12	HZV5-24836-000	HOUSING, REMOTE CONTROL BOX(C)	1	1	
FOP-3-6	13	HZV5-24841-000	WHEEL, CONTROL	1	1	
FOP-3-6	14	HZV5-24845-000	ARM COMP., SHIFT LINK	1	1	
FOP-3-6	15	HZV5-24850-000	PLATE COMP., SLIDING	1	1	
FOP-3-6	16	HZV5-24854-000	COLLAR, SLIDING PLATE	1	1	
FOP-3-6	17	HZV5-24855-000	PIVOT, SHIFT	2	2	
FOP-3-6	18	HZV5-24860-000	ARM COMP., LINK JOINT	1	1	
FOP-3-6	19	HZV5-24865-000	BRACKET, LINK JOINT	1	1	
FOP-3-6	20	HZV5-24875-000	WHEEL, ACCELERATOR	1	1	
FOP-3-6	21	HZV5-24876-000	SPRING, ACCELERATOR WHEEL	1	1	
FOP-3-6	22	HZV5-24878-000	LEVER, IDLE	1	1	
FOP-3-6	23	HZV5-24881-000	PLATE, SPRING SETTING	2	2	
FOP-3-6	24	HZV5-24883-000	SPRING, SHIFT CLICK	1	1	
FOP-3-6	25	HZV5-24884-000	SPRING, CHOKE RETURN	1	1	
FOP-3-6	26	HZV5-24885-000	SPACER, REMOTE CONTROL BOX	1	1	
FOP-3-6	27	HZV5-24887-000	SPACER, CLICK SPRING	1	1	
FOP-3-6	28	HZV5-24891-000	BLOCK, THROTTLE FRICTION	1	1	
FOP-3-6	29	HZV5-24892-000	BOLT, FRICTION	1	1	




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
FOP-3-6	30	HZV5-24894-000	SPACER, NEUTRAL SWITCH	1	1	
FOP-3-6	31	HZV5-24895-000	CLAMP, POWER TILT CORD	1	1	
FOP-3-6	32	HZV5-24897-000	PIPE, HARNESS GUIDE	1	1	
FOP-3-6	33	HZV5-24898-000	SPACER, CABLE CLAMP	1	1	
FOP-3-6	34	HZZ5-32530-000	CABLE ASSY., REMOTE CONTROL(B)	1	1	
FOP-3-6	35	HZV5-32823-003	PLUG, INNER CONNECTOR	7	7	
FOP-3-6	36	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	1	
FOP-3-6	37	H952-32901-770	TIE, CABLE(NATURAL)(2.4X92)	1	1	
FOP-3-6	38	HZZ3-35100-R11	SWITCH ASSY., COMBINATION	1	1	
FOP-3-6	39	HZV5-35370-823	SWITCH ASSY., POWER TRIM-TILT	1	1	
FOP-3-6	40	HMG9-35701-950	BAND(BLACK 3.5X140)	1	1	
FOP-3-6	41	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	
FOP-3-6	42	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
FOP-3-6	43	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	
FOP-3-6	44	HZZ5-37210-013	LAMP ASSY., INDICATION	1	1	
FOP-3-6	45	H341-38403-672	PLATE, WINKER BUZZER	1	1	
FOP-3-6	46	HZV5-38410-003	BUZZER COMP., WARNING	1	1	
FOP-3-6	47	HZZ3-87701-R00	PLATE, REMOTE CONTROL	1	1	
FOP-3-6	48	HZW9-87702-800	MARK, FAST IDLE	1	1	
FOP-3-6	49	HZW9-90008-000	BOLT, FLANGE, 8X35	1	1	
FOP-3-6	50	HMM4-90105-000	SCREW, PAN, 6X10	1	1	
FOP-3-6	51	HZW4-90108-000	SCREW, FLAT, 5X12	2	2	
FOP-3-6	52	HZV5-90125-000	SCREW, 6X95	3	3	
FOP-3-6	53	H921-90302-000	NUT, HEX., 16MM	1	1	
FOP-3-6	54	HZV4-90304-000	NUT, HEX., 6MM	3	3	
FOP-3-6	55	HZW4-90401-000	WASHER, PLAIN, 4MM	2	2	
FOP-3-6	56	HZW4-90402-000	WASHER, PLAIN, 5MM	2	2	
FOP-3-6	57	HZV4-90502-000	WASHER, PLAIN, 5MM	1	1	
FOP-3-6	58	H921-90504-010	WASHER, PLAIN, 6MM	5	5	




Ref.No.	Part No.	Description	Q' ty		Remarks
			BFT200A	BFT225A	
FOP-3-6	59	H921-90512-010	WASHER, 6MM	6	6
FOP-3-6	60	H921-90518-000	WASHER, PLAIN, 8MM	1	1
FOP-3-6	61	HZV5-90557-000	WASHER, 28MM	1	1
FOP-3-6	62	HZV5-90751-000	PIN, LOCK, 6MM	2	2
FOP-3-6	63	HZV5-90772-000	PIN, 6X6	1	1
FOP-3-6	64	HZV5-91151-000	ROLLER, CLICK	1	1
FOP-3-6	65	HSB6-91475-000	CLIP, WIRE HARNESS(6.3MM)	1	1
FOP-3-6	66	HZV5-91567-000	COLLAR, LINK JOINT	2	2
FOP-3-6	67	HZV5-91570-000	COLLAR, DISTANCE, 6X10X43.5	3	3
FOP-3-6	68	HCO-92101-05016-4J	BOLT, HEX., 5X16	1	1
FOP-3-6	69	HCO-93500-05010-4J	SCREW, PAN, 5X10	2	2
FOP-3-6	70	HCO-93901-250J0	SCREW, TAPPING, 5X8	2	2
FOP-3-6	71	HCO-93901-251J0	SCREW, TAPPING, 5X10	3	3
FOP-3-6	72	HCO-93901-252J0	SCREW, TAPPING, 5X12	1	1
FOP-3-6	73	HCO-93903-262J0	SCREW, TAPPING, 6X16	2	2
FOP-3-6	74	HCO-93905-255J0	SCREW, TAPPING, 5X25	7	7
FOP-3-6	75	HCO-94001-06490-0S	NUT, HEX., 6MM	1	1
FOP-3-6	76	HCO-94002-05490-0S	NUT, HEX., 5MM	1	1
FOP-3-6	77	HCO-94540-03029	E-RING, 3MM	1	1
FOP-3-6	78	HCO-94540-04029	E-RING, 4MM	1	1
FOP-3-6	79	HCO-94540-07029	E-RING, 7MM	1	1






Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT200A	BFT225A	
FOP-4	1	HZZ3-06323-R20	PANEL KIT, SWITCH(B)(4-LED)	1	1	
FOP-4	2	HZZ5-06325-600	CABLE SET, PANEL INDICATOR	1	1	(20FT)
FOP-4		HZZ5-06325-700	CABLE SET, PANEL INDICATOR	1	1	(25FT)
FOP-4		HZZ5-06325-800	CABLE SET, PANEL INDICATOR	1	1	(30FT)
FOP-4	3	HZW5-06352-U01	SWITCH KIT, LIGHT	1	1	
FOP-4	4	HMT8-18334-770	NUT, FLANGE, 5MM	12	12	
FOP-4	5	HZZ5-32185-600	CORD ASSY., INDICATOR(20FT)	1	1	
FOP-4		HZZ5-32185-700	CORD ASSY., INDICATOR(25FT)	1	1	
FOP-4		HZZ5-32185-800	CORD ASSY., INDICATOR(30FT)	1	1	
FOP-4	6	HZZ3-32341-R31	PANEL ASSY., SWITCH	1	1	
FOP-4	7	HZZ3-32346-R21	PANEL, CONTROL	1	1	
FOP-4	8	HZZ3-32347-R01	PANEL, CONTROL	1	1	
FOP-4	9	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	
FOP-4	10	HZZ5-32580-600	CABLE ASSY., SWITCH PANEL	1	1	(20FT)
FOP-4		HZZ5-32580-700	CABLE ASSY., SWITCH PANEL	1	1	(25FT)
FOP-4		HZZ5-32580-800	CABLE ASSY., SWITCH PANEL	1	1	(30FT)
FOP-4	11	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	
FOP-4	12	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	
FOP-4	13	H952-32901-770	TIE, CABLE(NATURAL)(2.4X92)	5	5	
FOP-4	14	HZZ3-35100-R11	SWITCH ASSY., COMBINATION	1	1	
FOP-4	15	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	
FOP-4	16	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
FOP-4	17	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	
FOP-4	18	HZZ3-37205-R01	PANEL ASSY., INDICATOR(4-LED)	1	1	
FOP-4	19	HZZ5-37210-762	LAMP ASSY., INDICATION(4-LED)	1	1	
FOP-4	20	H341-38403-672	PLATE, WINKER BUZZER	1	1	
FOP-4	21	HZV5-38410-003	BUZZER COMP., WARNING	1	1	
FOP-4	22	HZZ5-38414-003	BRACKET, BUZZER	1	1	
FOP-4	23	HZW5-90109-000	SCREW, PAN, 5X40	12	12	




[illegible]





[illegible]




[illegible]




[illegible]



[illegible]





INDEX

<A>		
ARM ASSY., FR. INTAKE ROCKER	E-9-10-4	
ARM ASSY., INTAKE ROCKER	E-9-10-5	
ARM COMP. A, EX. ROCKER	E-9-10-6	
ARM COMP. B, EX. ROCKER	E-9-10-7	
ARM COMP., LINK JOINT	FOP-3-6-18	
ARM COMP., SHIFT LINK	FOP-3-6-14	
ARM, FUEL PUMP ROCKER	E-9-10-3	
ARM, NEUTRAL LOCK	FOP-3-4-5	
ARM, SHIFT	F-2-9	
ARM, THROTTLE	F-2-3	
ARMATURE COMP.	F-11-7	
		
BAG, TOOL, 200MM	F-13-13	
BALL, STEEL	E-21-6	
BALL, STEEL, #12(3/8)	F-5-31	
BALL, STEEL, #12(3/8)	F-5-1-32	
BALL, STEEL, #7(7/32)	F-5-30	
BALL, STEEL, #7(7/32)	F-5-1-31	
BAND	E-18-56	
BAND(BLACK 3.5X140)	F-11-3	
BAND(BLACK 3.5X140)	FOP-3-6-40	
BAND, AIR FLOW	E-15-9	
BAND, TUBE CLIP, 12.5MM	F-8-20-5	
BAND, UNDER CASE GROMMET	F-8-10-4	
BAND, WIRE	F-10-6	
BAND, WIRE	F-10-76	
BAND, WIRE HARNESS	F-7-11-20	
BAND, WIRE HARNESS(NATURAL)	FOP-4-25	
BAND, WIRE HARNESS(NATURAL)	FOP-4-1-17	
BASE	FOP-3-4-15	
BASE COMP., TIMING BELT	E-13-10	
BASE, L. INJECTOR	E-14-13	
BASE, R. INJECTOR	E-14-11	
BEARING A, CONNECTING ROD	E-7-7	
BEARING A, MAIN LOWER(BLACK)	E-7-11	
BEARING A, MAIN UPPER(BLACK)	E-7-9	
BEARING B, CONNECTING ROD	E-7-	
BEARING B, MAIN LOWER(BROWN)	E-7-	
BEARING B, MAIN UPPER(BROWN)	E-7-	
BEARING C, CONNECTING ROD	E-7-	
BEARING C, MAIN LOWER(GREEN)	E-7-	
BEARING C, MAIN UPPER(GREEN)	E-7-	
BEARING D, CONNECTING ROD	E-7-	
BEARING D, MAIN LOWER(YELLOW)	E-7-	
BEARING D, MAIN UPPER(YELLOW)	E-7-	
BEARING E, CONNECTING ROD	E-7-	
BEARING E, MAIN LOWER(PINK)	E-7-	
BEARING E, MAIN UPPER(PINK)	E-7-	
BEARING F, MAIN LOWER(RED)	E-7-	
BEARING F, MAIN UPPER(RED)	E-7-	
BEARING, ANGULAR, 50X90X30.2	F-5-24	
BEARING, ANGULAR, 50X90X30.2	F-5-1-24	
BEARING, FR. GENERATOR	E-19-3	
BEARING, NEEDLE, 20X28X13	E-6-10-43	
BEARING, NEEDLE, 28X39X30	F-5-1-25	
BEARING, NEEDLE, 32X42X30	F-5-25	
BEARING, NEEDLE, 32X42X30	F-5-1-26	
BEARING, NEEDLE, 32X46X37	F-4-24	
BEARING, RR. GENERATOR	E-19-2	
BEARING, TAPER ROLLER	F-4-25	
BEARING, TAPER, 50X90X21.5	F-5-23	
BEARING, TAPER, 50X90X21.5	F-5-1-23	
BEARING, THRUST(F)	F-5-22	
BEARING, THRUST(F)	F-5-1-22	
BELT, A.C. GENERATOR	E-13-16	
BELT, TIMING(197YU26 B-333)	E-13-6	
BLOCK ASSY., CYLINDER	E-3-3	
BLOCK, NEUTRAL LOCK	FOP-3-6-6	
BLOCK, THROTTLE FRICTION	FOP-3-6-28	
BODY	E-18-3	
BOLT A, THROUGH	E-21-14	
BOLT KIT, SIDE REMOTE CONTROL	FOP-7-1	
BOLT, 1/4-28UNF	F-10-36	
BOLT, 3/8-24UNF	F-10-43	
BOLT, CONNECTING ROD	E-7-5	
BOLT, COVER LOCK	F-8-11	
BOLT, DRAIN PLUG	E-6-11	
BOLT, DRAIN PLUG	F-3-14	
BOLT, FLANGE, 10X110	E-21-20	
BOLT, FLANGE, 10X120(SATO)	E-6-10-25	
BOLT, FLANGE, 10X40	E-13-24	
BOLT, FLANGE, 10X43	E-13-25	
BOLT, FLANGE, 10X55	E-3-10-10	
BOLT, FLANGE, 10X70	E-6-10-52	
BOLT, FLANGE, 10X90	E-19-21	
BOLT, FLANGE, 10X90	E-21-19	
BOLT, FLANGE, 12MM	E-5-14	
BOLT, FLANGE, 12X120	E-6-10-53	
BOLT, FLANGE, 12X95	E-3-26	
BOLT, FLANGE, 5X10	E-14-10-17	
BOLT, FLANGE, 5X14	E-13-10-9	
BOLT, FLANGE, 6X10	E-14-22	
BOLT, FLANGE, 6X10	E-18-2-26	
BOLT, FLANGE, 6X10	E-20-11-8	
BOLT, FLANGE, 6X10	F-7-11-15	
BOLT, FLANGE, 6X11	F-2-24	
BOLT, FLANGE, 6X12	E-18-50	
BOLT, FLANGE, 6X12	E-18-2-27	
BOLT, FLANGE, 6X12	F-2-25	
BOLT, FLANGE, 6X12	F-7-3	
BOLT, FLANGE, 6X12	F-7-11-14	
BOLT, FLANGE, 6X12	F-8-10-29	
BOLT, FLANGE, 6X12	F-10-37	
BOLT, FLANGE, 6X14	E-3-33	
BOLT, FLANGE, 6X14	E-5-22	
BOLT, FLANGE, 6X14	E-14-21	
BOLT, FLANGE, 6X14	E-18-49	
BOLT, FLANGE, 6X14	F-8-10-27	
BOLT, FLANGE, 6X14(CT200)	E-1-20	
BOLT, FLANGE, 6X14(CT200)	E-13-19	
BOLT, FLANGE, 6X14(CT200)	F-2-22	
BOLT, FLANGE, 6X16	E-3-31	
BOLT, FLANGE, 6X16	E-18-48	
BOLT, FLANGE, 6X16	E-19-23	
BOLT, FLANGE, 6X16	F-2-23	
BOLT, FLANGE, 6X16	F-4-17	
BOLT, FLANGE, 6X18	E-3-34	
BOLT, FLANGE, 6X18	E-5-23	
BOLT, FLANGE, 6X20	E-20-11-9	
BOLT, FLANGE, 6X20	F-7-30-7	
BOLT, FLANGE, 6X20	F-8-10	
BOLT, FLANGE, 6X20	F-8-10-30	
BOLT, FLANGE, 6X20	F-10-34	
BOLT, FLANGE, 6X20	F-10-40	
BOLT, FLANGE, 6X22	E-3-35	
BOLT, FLANGE, 6X22	E-3-10-8	
BOLT, FLANGE, 6X22	E-6-10-30	
BOLT, FLANGE, 6X22	E-13-22	
BOLT, FLANGE, 6X22	E-14-10-14	
BOLT, FLANGE, 6X22	E-15-19	
BOLT, FLANGE, 6X23	F-10-35	
BOLT, FLANGE, 6X25	E-14-19	
BOLT, FLANGE, 6X25	E-18-47	
BOLT, FLANGE, 6X32	E-3-10-9	
BOLT, FLANGE, 6X32	E-6-10-31	
BOLT, FLANGE, 6X32	E-14-10-16	
BOLT, FLANGE, 6X35	E-1-21	
BOLT, FLANGE, 6X35	E-3-32	
BOLT, FLANGE, 6X35	E-4-16	
BOLT, FLANGE, 6X35	E-14-20	
BOLT, FLANGE, 6X37	E-3-10-11	
BOLT, FLANGE, 6X40	E-6-10-37	
BOLT, FLANGE, 6X50	E-4-19	
BOLT, FLANGE, 6X55	E-3-10-14	
BOLT, FLANGE, 6X60	E-4-18	
BOLT, FLANGE, 6X60	E-15-20	
BOLT, FLANGE, 8X100	E-6-10-33	
BOLT, FLANGE, 8X18	F-7-11-16	
BOLT, FLANGE, 8X20	E-3-10-7	
BOLT, FLANGE, 8X20	E-9-14	
BOLT, FLANGE, 8X22	F-8-10-31	
BOLT, FLANGE, 8X28	E-9-15	
BOLT, FLANGE, 8X30	E-5-24	
BOLT, FLANGE, 8X30	E-6-10-35	
BOLT, FLANGE, 8X30	E-9-10-21	
BOLT, FLANGE, 8X32	E-1-22	
BOLT, FLANGE, 8X35	E-18-57	
BOLT, FLANGE, 8X35	FOP-3-6-49	
BOLT, FLANGE, 8X40	E-4-20	
BOLT, FLANGE, 8X40	E-9-10-22	
BOLT, FLANGE, 8X45	E-1-35	
BOLT, FLANGE, 8X50	E-3-38	
BOLT, FLANGE, 8X50	E-14-10-18	
BOLT, FLANGE, 8X60	E-4-17	
BOLT, FLANGE, 8X65	E-15-21	
BOLT, FLANGE, 8X75	E-3-36	
BOLT, FRICTION	FOP-3-6-29	
BOLT, HEX	F-11-32	
BOLT, HEX, 10X235	F-10-41	
BOLT, HEX, 10X35	F-3-20-31	
BOLT, HEX, 10X60	E-6-10-29	
BOLT, HEX, 10X85	E-6-10-28	
BOLT, HEX, 12X120	E-6-10-26	
BOLT, HEX, 12X130	F-10-46	
BOLT, HEX, 12X200	F-10-39	
BOLT, HEX, 12X45	F-5-13	
BOLT, HEX, 12X45	F-5-1-13	
BOLT, HEX, 12X50	F-3-20-37	
BOLT, HEX, 12X65	E-6-10-27	
BOLT, HEX, 14X180	F-3-20-32	
BOLT, HEX, 5X16	FOP-3-6-68	
BOLT, HEX, 6X14	F-10-42	
BOLT, HEX, 6X16	E-6-10	
BOLT, HEX, 6X16	F-2-26	
BOLT, HEX, 6X55	F-3-34	
BOLT, HEX, 8X28	E-6-9	
BOLT, HEX, 8X35	E-6-8	
BOLT, HEX, 8X35	F-8-10-26	
BOLT, HEX, 8X60	FOP-2-9	
BOLT, IDLER	E-13-13	
BOLT, OIL CHECK	F-3-11	
BOLT, RECESSED	F-11-29	
BOLT, SEALING, 18MM	E-5-10	
BOLT, SEALING, 22MM	E-3-6	
BOLT, SEALING, 22MM	E-3-37	
BOLT, SEALING, 22MM	E-5-15	
BOLT, SEALING, 6MM	E-18-45	
BOLT, SOCKET(A)	F-11-30	
BOLT, SOCKET(B)	F-11-31	
BOLT, SOCKET, 6X16	F-8-12	
BOLT, SPECIAL ADJUSTER	E-19-22	
BOLT, SPECIAL, 6X12	F-3-20-38	
BOLT, SPECIAL, 6X17	F-3-20-34	
BOLT, SPECIAL, 6X22	F-3-20-36	
BOLT, SPECIAL, 6X220	FOP-7-2	
BOLT, SPECIAL, 6X37	F-3-20-39	
BOLT, SPECIAL, 8MM	E-5-13	
BOLT, SPECIAL, 8X29	E-13-10-8	
BOLT, STUD, 10X45	E-6-10-32	
BOLT, STUD, 12X40	F-3-15	
BOLT, STUD, 6X68	E-19-8	
BOLT, STUD, 8X28	E-14-23	
BOLT, STUD, 8X45	E-14-24	
BOLT, TENSIONER	E-19-24	
BOLT, TIMING BELT ADJUSTING	E-13-20	
BOLT, TIMING BELT COVER	E-13-10-7	
BOLT, TIMING BELT IDLER A	E-13-14	
BOLT, WASHER, 6X121	E-6-10-34	
BOLT, WASHER, 8X60	F-4-16	
BOLT-WASHER, 10X109	E-3-27	
BOLT-WASHER, 10X32	F-3-13	
BOLT-WASHER, 10X32	F-10-38	
BOLT-WASHER, 10X47	F-3-35	
BOLT-WASHER, 10X60	E-3-28	
BOLT-WASHER, 10X80	E-3-29	
BOLT-WASHER, 11X105	E-3-30	
BOLT-WASHER, 12X163	E-9-13	
BOLT-WASHER, 12X35	E-13-23	
BOLT-WASHER, 16X49	E-13-21	
BOLT-WASHER, 5X18	E-14-10-15	
BOLT-WASHER, 5X30	E-15-18	
BOLT-WASHER, 6X16	F-2-42	
BOLT-WASHER, 6X25	E-15-17	
BOLT-WASHER, 6X25	F-3-20-57	
BOLT-WASHER, 6X25	F-7-11-13	
BOLT-WASHER, 6X27	E-20-3	

BOLT-WASHER, 6X27(CT200).....	E-20-11-7	CAP, GRIP	FOP-3-7	CLIP, WIRE HARNESS	F-7-4
BOLT-WASHER, 6X27(CT200).....	F-7-11-12	CAP, GRIP	FOP-3-2-9	CLIP, WIRE HARNESS	F-7-11-21
BOLT-WASHER, 6X29	E-6-10-36	CAP, HANDLE	FOP-3-6-5	CLIP, WIRE HARNESS	F-7-11-22
BOLT-WASHER, 8X35	E-18-46	CAP, L. SIDE COVER	F-8-10-24	CLIP, WIRE HARNESS	F-10-67
BOSS, FLYWHEEL	E-5-12	CAP, OIL(YELLOW)	E-3-10-4	CLIP, WIRE HARNESS(6.3MM).....	FOP-3-6-65
BOX ASSY., JUNCTION	F-7-30-1	CAP, SWITCH	FOP-3-8	CLIP, WIRE HARNESS, 10MM	E-14-26
BOX ASSY., REMOTE CONTROL(EU)	FOP-3-6-1	CAP, TIMING BELT TENSIONER	E-13-8	CLIP, WIRE HARNESS, 25MM	E-18-2-32
BOX KIT, REMOTE CONTROL	FOP-3-1	CAP, UNDER COVER	F-3-20-24	CLIP, WIRE HARNESS, 25MM	E-20-11-10
BOX KIT, REMOTE CONTROL	FOP-3-2-1	CAP, WATER JOINT	F-3-20-4	CLIP, WIRE HARNESS, 25MM	F-3-20-50
BOX KIT, REMOTE CONTROL	FOP-3-4-1	CARTRIDGE, OIL FILTER	E-3-10-3	CLUTCH COMP., OVERRUNNING	E-21-3
BRACKET A, RR. COVER	F-8-10-8	CASE A, SILENCER	E-15-10	COCK ASSY., FUEL DRAIN	E-18-2-25
BRACKET ASSY.	F-11-6	CASE ASSY., GEAR(L)	F-3-10-1	COIL COMP., PLUG HOLE	E-20-1
BRACKET B, HARNESS CLIP	E-3-20	CASE ASSY., GEAR(XL)	F-3-10	COLLAR	E-18-23
BRACKET B, RR. COVER	F-8-10-9	CASE ASSY., GEAR(XL)(C/R).....	F-3-10-	COLLAR	E-18-26
BRACKET C, COUPLER	F-7-11-2	CASE ASSY., OIL SEAL	E-3-2	COLLAR, 6.2X10X25.5	F-3-20-53
BRACKET C, HARNESS CLIP	E-1-16	CASE B, SILENCER	E-15-11	COLLAR, 8.5X14.5	E-18-55
BRACKET, A.C. GENERATOR FUSE	E-20-11-3	CASE COMP., MOUNT	E-6-10-22	COLLAR, 8.5X14.5	F-8-10-37
BRACKET, BUZZER	FOP-4-22	CASE COMP., PUMP	E-18-27	COLLAR, C.D.I. UNIT CASE	E-15-24
BRACKET, BUZZER	FOP-4-1-14	CASE KIT, GEAR	F-3-1	COLLAR, C.D.I. UNIT CASE	E-20-5
BRACKET, CABLE	F-8-10-1	CASE, ELECTRONIC PARTS	E-20-11-1	COLLAR, C.D.I. UNIT CASE	E-20-11-11
BRACKET, CLIP B	E-1-15	CASE, EXTENSION	F-3-20-10	COLLAR, C.D.I. UNIT CASE	F-7-11-25
BRACKET, CLIP B	E-3-19	CASE, EXTENSION	F-3-20-	COLLAR, DISTANCE	F-4-32
BRACKET, COUPLER D	E-13-17	CASE, FLUSH VALVE	E-6-10-7	COLLAR, DISTANCE	FOP-2-15
BRACKET, ECU	E-20-11-5	CASE, GEAR	F-3-4	COLLAR, DISTANCE(A)	FOP-7-3
BRACKET, FR	E-21-10	CASE, POWER TILT RELAY	F-7-11-11	COLLAR, DISTANCE(B)	FOP-7-4
BRACKET, FR. COVER	F-8-10-5	CASE, SWIVEL	F-10-20	COLLAR, DISTANCE, 6.5X9X3	F-8-15
BRACKET, HARNESS CLIP A	E-14-17	CASE, SWIVEL	F-10-	COLLAR, DISTANCE, 6.5X9X5	F-3-20-
BRACKET, HOOK	F-8-5	CIRCLIP, EXTERNAL, 15MM	F-5-29	COLLAR, DISTANCE, 6X10.5X25	F-3-20-54
BRACKET, L. SIDE COVER	F-8-10-7	CIRCLIP, EXTERNAL, 15MM	F-5-1-30	COLLAR, DISTANCE, 6X10X43.5	FOP-3-6-67
BRACKET, L. STERN	F-10-25	CIRCLIP, EXTERNAL, 39MM	F-10-66	COLLAR, LINK JOINT	FOP-3-6-66
BRACKET, LINK JOINT	FOP-3-6-19	CIRCLIP, INTERNAL	F-11-36	COLLAR, LOWER CYLINDER	F-10-33
BRACKET, NEUTRAL SWITCH	F-2-19	CIRCLIP, INTERNAL, 43	F-3-20-49	COLLAR, MOUNTING(6MM)	F-7-11-23
BRACKET, R. SIDE COVER	F-8-10-6	CLAMP	F-6-5	COLLAR, ORIFICE	F-11-48
BRACKET, R. STERN	F-10-24	CLAMP	F-6-8	COLLAR, SHIFT SLIDER	F-2-11
BRACKET, REMOTE CONTROL	FOP-3-12	CLAMP, CHECK VALVE	E-18-10-1	COLLAR, SLIDING PLATE	FOP-3-6-16
BRACKET, REMOTE CONTROL	FOP-3-2-13	CLAMP, FUEL TUBE	E-18-10-21	COLLAR, STEERING ROD	F-10-71
BRACKET, RR	E-21-11	CLAMP, HARNESS	FOP-3-6-9	COLLAR, TIMING BELT COVER	E-13-10-10
BRACKET, SENSOR CORD	E-14-10-8	CLAMP, HOSE	E-18-10-9	CONTROL UNIT, ELECTRONIC	E-20-11-4
BRACKET, SHIFT LINK	F-2-16	CLAMP, POWER TILT CORD	FOP-3-6-31	CONTROL UNIT, ELECTRONIC	E-20-11-
BRACKET, SOLENOID VALVE	E-1-7	CLAMP, TUBE	F-10-21	CORD ASSY., INDICATOR(20FT)	FOP-4-5
BRACKET, TILTING	F-10-28	CLAMP, TUBE(D10.5)	E-4-21	CORD ASSY., INDICATOR(25FT)	FOP-4-
BREAKER ASSY.	F-11-1	CLAMP, TUBE(D10.5)	E-18-10-19	CORD ASSY., INDICATOR(30FT)	FOP-4-
BRUSH ASSY.	F-11-2	CLAMP, TUBE(D10.7)	E-18-10-18	CORD COMP., EMERGENCY	FOP-3-6-42
BRUSH SET	E-21-7	CLAMP, TUBE(D21)	E-4-23	CORD COMP., EMERGENCY	FOP-4-16
BUFFER, PLATE	E-18-2-8	CLAMP, TUBE(D29)	E-4-22	CORD COMP., EMERGENCY	FOP-4-1-9
BUSH A, COVER LOCK	F-8-10-15	CLAMP, TUBE(D32.5)	E-1-25	CORD, A.C. GENERATOR	F-7-11-8
BUSH A, THRUST RECEIVE	F-10-31	CLAMP, WIRE, 8MM	E-18-2-31	CORD, SWITCH	E-3-21
BUSH B, COVER LOCK	F-8-10-16	CLAMPER, SENSOR TUBE	F-10-12	COTTER, VALVE(FUJI VALVE)	E-9-10-20
BUSH B, THRUST RECEIVE	F-10-32	CLIP A, WIRE	E-1-17	COVER ASSY.	FOP-3-4-11
BUSH COMP., VERTICAL SHAFT	F-3-20-12	CLIP D, SPEEDOMETER CABLE	E-14-18	COVER ASSY., CRANKCASE UPPER	E-3-1
BUSH, INSULATION	E-19-4	CLIP D, WASHER TUBE	E-1-33	COVER ASSY., ENGINE	F-8-3
BUSH, INSULATION	E-19-18	CLIP, 10.7MM	F-11-35	COVER ASSY., L. TIMING BELT	E-13-10-3
BUSH, LOWER CYLINDER	F-11-25	CLIP, BRAKE PIPE	F-2-21	COVER ASSY., R. TIMING BELT	E-13-10-2
BUSH, MOTOR CODE	F-11-20	CLIP, EMERGENCY LOCK	FOP-3-6-43	COVER B, TERMINAL	F-7-11-6
BUSH, SHIFT ARM	F-2-15	CLIP, EMERGENCY LOCK	FOP-4-17	COVER B, TERMINAL(L)	F-7-11-5
BUSH, SWIVEL CASE	F-10-23	CLIP, EMERGENCY LOCK	FOP-4-1-10	COVER COMP.	E-18-4
BUSH, SWIVEL CASE	F-11-12	CLIP, HARNESS	E-1-28	COVER COMP., FUSE	F-7-30-2
BUSH, TILT ARM	F-10-27	CLIP, HARNESS	E-18-53	COVER COMP., INTAKE MANIFOLD	E-14-10-5
BUTTON, THROTTLE	FOP-3-9	CLIP, HARNESS	F-8-10-35	COVER COMP., L. UNDER ENGINE	F-3-20-21
BUTTON, THROTTLE	FOP-3-2-10	CLIP, HARNESS BAND(BLACK)	E-3-48	COVER COMP., R. UNDER ENGINE	F-3-20-20
BUTTON, THROTTLE	FOP-3-4-8	CLIP, HARNESS BAND(BLACK)	E-13-10-11	COVER, BEARING	E-19-5
BUZZER COMP., WARNING	FOP-3-6-46	CLIP, HARNESS BAND(BLACK)	F-2-44	COVER, DRAIN PLUG(L)	F-3-20-13
BUZZER COMP., WARNING	FOP-4-21	CLIP, HARNESS BAND(BLACK)	F-7-6	COVER, DRAIN PLUG(XL)	F-3-20-
BUZZER COMP., WARNING	FOP-4-1-13	CLIP, HARNESS BAND(BLACK)	F-7-11-24	COVER, DUAL GRIP	FOP-3-2-8
<C>		CLIP, HARNESS BAND(BLACK)	F-8-10-36	COVER, FLUSH VALVE	E-6-10-6
CABLE ASSY., POWER TILT RELAY	F-7-11-7	CLIP, HARNESS BAND(BLACK)	FOP-12-3	COVER, FR.	F-8-7
CABLE ASSY., REMOTE CONTROL(B)	FOP-3-6-34	CLIP, INJECTOR	E-14-2	COVER, FR. SEPARATE	F-3-20-9
CABLE ASSY., STARTER	F-7-11-3	CLIP, PISTON PIN	E-7-4	COVER, GEAR CASE	F-3-6
CABLE ASSY., SWITCH PANEL	FOP-4-10	CLIP, SENSOR HOSE	E-1-18	COVER, GRIP	FOP-3-4-4
CABLE ASSY., SWITCH PANEL	FOP-4-	CLIP, SHIFT WIRE	E-1-19	COVER, IMPELLER	F-4-4
CABLE ASSY., SWITCH PANEL	FOP-4-	CLIP, TUBE	E-6-10-1	COVER, IMPELLER	FOP-2-6
CABLE COMP. A, COVER LOCK	F-8-10-12	CLIP, TUBE	E-18-2-2	COVER, L. CAMSHAFT THRUST	E-9-8
CABLE COMP. B, COVER LOCK	F-8-10-13	CLIP, TUBE	E-18-10-10	COVER, L. CYLINDER HEAD	E-1-3
CABLE COMP., THROTTLE	E-15-13	CLIP, TUBE(B10)	E-6-10-40	COVER, L. GRIP	FOP-3-5
CABLE SET, PANEL INDICATOR	FOP-4-2	CLIP, TUBE(B12)	E-1-27	COVER, L. GRIP	FOP-3-2-6
CABLE SET, PANEL INDICATOR	FOP-4-	CLIP, TUBE(B12)	E-18-2-29	COVER, L. LOWER MOUNTING	F-3-20-27
CABLE SET, PANEL INDICATOR	FOP-4-	CLIP, TUBE(B12.5)	E-6-10-41	COVER, L. LOWER MOUNTING	F-3-20-
CAMSHAFT, L.	E-9-10-2	CLIP, TUBE(B12.5)	E-18-2-30	COVER, L. RELIEF VALVE	E-6-10-17
CAMSHAFT, L.	E-9-10-	CLIP, TUBE(B12.5)	F-3-20-48	COVER, L. WATER JACKET	E-6-10-21
CAMSHAFT, R.	E-9-10-1	CLIP, TUBE(B8)	E-18-2-28	COVER, LOCK ARM	FOP-3-4-6
CAMSHAFT, R.	E-9-10-	CLIP, TUBE(B8)	F-10-65	COVER, NEUTRAL SWITCH	F-2-20
CAP COMP., OIL TANK	F-11-28	CLIP, WIRE	E-18-10-20	COVER, OIL LEVEL GAUGE	E-3-14
CAP, BOLT, 10MM	E-3-10-12	CLIP, WIRE HARNESS	E-18-2-33	COVER, OIL PUMP	E-5-4

COVER, PLUG MAINTENANCE	F-3-20-19
COVER, PUMP	E-18-28
COVER, PUMP(A)	E-18-29
COVER, R. CAMSHAFT THRUST	E-9-7
COVER, R. CYLINDER HEAD	E-1-1
COVER, R. LOWER MOUNTING	F-3-20-26
COVER, R. LOWER MOUNTING	F-3-20-
COVER, R. RELIEF VALVE	E-6-10-13
COVER, R. WATER JACKET	E-6-10-19
COVER, STARTER TERMINAL	F-7-11-4
COVER, THERMOSTAT	E-4-11
COVER, UPPER MOUNT	F-10-18
COVER, WATER JACKET	E-18-12
CRANKCASE COMP.	E-3-10-1
CRANKSHAFT COMP.	E-7-8
CUP	E-18-2-17
CUP SET, WATER SEPARATOR	E-18-2-7
<D>	
DAMPER, HOOK	F-8-6
DOWEL PIN, 10X12	E-14-30
DOWEL PIN, 13X37	E-3-39
DOWEL PIN, 14X15	E-5-16
DOWEL PIN, 14X15	E-6-10-42
DOWEL PIN, 16X22	E-9-18
DOWEL PIN, 5X8	E-3-52
DOWEL PIN, 6X10	E-3-51
DOWEL PIN, 6X10	E-9-17
DOWEL PIN, 6X10	E-9-21
DOWEL PIN, 6X10	E-13-28
DOWEL PIN, 6X10	E-15-26
DOWEL PIN, 6X10	F-3-25
DOWEL PIN, 6X10	F-3-20-51
DOWEL PIN, 6X10	F-4-23
DOWEL PIN, 8X14	E-3-10-17
DRIVER 3, MINUS SCREW(NO.2)	F-13-8
DUCT, ENGINE COVER	F-8-9
<E>	
END COVER, RR	E-19-17
END, NIPPLE	F-10-10
E-RING, 10MM	F-4-33
E-RING, 12MM	F-2-41
E-RING, 15MM	F-11-49
E-RING, 3MM	FOP-3-6-77
E-RING, 4MM	F-2-40
E-RING, 4MM	FOP-3-6-78
E-RING, 6MM	F-8-10-38
E-RING, 6MM	FOP-3-36
E-RING, 6MM	FOP-3-2-41
E-RING, 6MM	FOP-3-4-28
E-RING, 7MM	FOP-3-6-79
EXTENSION, OIL FILLER	E-3-10-5
<F>	
FILTER	E-18-2-14
FILTER ASSY., SPOOL VALVE	E-3-17
FILTER ASSY., SPOOL VALVE	E-3-
FILTER B	F-11-18
FLOAT	E-18-2-16
FLOAT SET	E-18-2
FLYWHEEL COMP.	E-5-11
FRAME COMP., MOUNTING(L)	F-10-13
FRAME COMP., MOUNTING(XL)	F-10-
FUSE, BLOCK(150A)	F-7-30-3
FUSE, MINI(10A)	F-7-30-9
FUSE, MINI(15A)	F-7-30-10
FUSE, MINI(30A)	F-7-30-11
<G>	
GASKET B, IMPELLER	F-4-5
GASKET B, IMPELLER	FOP-2-7
GASKET COMP., CYLINDER HEAD	E-9-9
GASKET, EAC VALVE	E-15-5
GASKET, EX. PIPE	E-6-4
GASKET, FR. INJECTOR BASE	E-14-12
GASKET, INTAKE MANIFOLD	E-14-15
GASKET, INTAKE MANIFOLD	E-14-10-1
GASKET, L. EX. MANIFOLD	E-4-5
GASKET, MOUNT CASE	E-6-10-23
GASKET, R. EX. MANIFOLD	E-4-3
GASKET, RR. INJECTOR BASE	E-14-14
GASKET, THROTTLE BODY	E-15-2
GAUGE COMP., OIL LEVEL	E-3-53
GEAR ASSY., INTERNAL	E-21-16
GEAR ASSY., PLANETARY	E-21-4
GEAR COMP., BEVEL(RVS. 28T)	F-5-1-9

GEAR SET	F-5-8
GEAR SET(COUNTER ROTATION)	F-5-1-8
GEAR, BEVEL(RVS. 28T)	F-5-9
GENERATOR ASSY., A.C.	E-19-14
GRIP, REMOTE CONTROL HANDLE	FOP-3-6
GRIP, REMOTE CONTROL HANDLE	FOP-3-2-7
GRIP, REMOTE CONTROL HANDLE	FOP-3-6-4
GRIP, SCREW DRIVER	F-13-3
GROMMET A, UNDER CASE	F-8-10-3
GROMMET, AIR CLEANER CASE	F-8-1
GROMMET, ELECTRONIC PARTS CASE ...	E-20-4
GROMMET, ELECTRONIC PARTS CASE ...	E-20-11-2
GROMMET, ELECTRONIC PARTS CASE ...	F-7-11-1
GROMMET, EXTENSION CASE	F-4-13
GROMMET, GEAR CASE	F-3-5
GROMMET, L. IDLE PORT	F-3-20-29
GROMMET, POWER TILT SWITCH	F-3-20-8
GROMMET, R. IDLE PORT	F-3-20-28
GROMMET, RELAY	F-7-11-10
GROMMET, RELAY BRACKET	E-20-11-6
GROMMET, SILENCER	E-15-12
GROMMET, TIMING BELT COVER	E-13-10-1
GROMMET, UNDER CASE	E-15-16
GROMMET, UNDER CASE(C)	F-3-20-7
GROMMET, UNDER CASE(C)	F-11-10
GROMMET, VAPOR SEPARATOR	E-18-34
GROMMET, VAPOR SEPARATOR	E-18-35
GROMMET, WATER CHECK	F-3-20-30
GROMMET, WATER TUBE	E-6-6
GUIDE COMP., ROD	F-11-17
GUIDE, EX. VALVE(OS)	E-9-3
GUIDE, IN. VALVE(OS)	E-9-2
GUIDE, L. EX.	E-6-10-5
GUIDE, R. EX.	E-6-10-2
<H>	
HANDLE, REMOTE CONTROL	FOP-3-4
HANDLE, REMOTE CONTROL	FOP-3-2-5
HANDLE, REMOTE CONTROL	FOP-3-4-3
HANDLE, REMOTE CONTROL	FOP-3-6-2
HANGER, ENGINE	E-3-10-2
HANGER, ENGINE	E-9-1
HARNESS ASSY., MAIN WIRE	F-7-1
HARNESS ASSY., MAIN WIRE	F-7-
HARNESS ASSY., SWITCH PANEL	FOP-4-9
HARNESS ASSY., SWITCH PANEL	FOP-4-1-4
HARNESS COMP.	E-18-41
HEAD COMP., CYLINDER	E-9-5
HOLDER	E-18-11
HOLDER ASSY., BRUSH	E-19-1
HOLDER COMP., BRUSH	E-21-9
HOLDER, BEARING	F-5-12
HOLDER, BEARING(C/R)	F-5-1-12
HOLDER, NEUTRAL LOCK	FOP-3-4-14
HOLDER, OIL FILTER	E-3-10-6
HOLDER, PROPELLER SHAFT	F-5-11
HOLDER, PROPELLER SHAFT	F-5-1-11
HOLDER, ROD(A)	F-8-20-3
HOLDER, SEAL	F-2-17
HOLDER, SHIFT ROD	F-4-12
HOLDER, STRIKER	F-8-10-21
HOSE A, PRESSURE REGULATOR	E-18-10-12
HOSE B, PRESSURE REGULATOR	E-18-10-13
HOSE COMP., FUEL	E-14-9
HOSE COMP., FUEL JOINT	E-14-10
HOUSING ASSY., L. INNER	FOP-3-3
HOUSING ASSY., L. INNER	FOP-3-2-3
HOUSING ASSY., R. INNER	FOP-3-2-4
HOUSING ASSY., R. INNER	FOP-3-4-2
HOUSING COMP., REMOTE CONTROL	FOP-3-13
HOUSING COMP., REMOTE CONTROL	FOP-3-2-14
HOUSING COMP., REMOTE CONTROL	FOP-3-6-10
HOUSING COMP., REMOTE CONTROL	FOP-3-6-11
HOUSING, IMPELLER	F-4-2
HOUSING, IMPELLER	FOP-2-4
HOUSING, LEAD	FOP-3-14
HOUSING, LEAD	FOP-3-2-15
HOUSING, LOWER CENTER MOUNTING ..	F-10-17
HOUSING, LOWER CENTER MOUNTING ..	F-10-
HOUSING, LOWER MOUNTING	F-3-20-16
HOUSING, REMOTE CONTROL BOX(C) ...	FOP-3-6-12
HOUSING, UPPER MOUNTING	F-10-14
HOUSING, WATER PUMP	F-4-6

<I>	
IDLER B, TIMING BELT	E-13-15
IDLER, TIMING BELT(KOYO SEIKO)	E-13-12
IMPELLER, PUMP	F-4-1
IMPELLER, PUMP	FOP-2-3
INJECTOR ASSY., FUEL	E-14-1
INSULATOR	E-18-31
INSULATOR COMP.	E-18-30
<J>	
JOINT A, VACUUM TUBE	E-14-10-7
JOINT ASSY (INLET)	F-6-2
JOINT ASSY (OUTLET)	F-6-3
JOINT ASSY., OIL PIPE	E-3-12
JOINT B, WASHER TUBE(MITSUBA)	F-10-8
JOINT SET	E-18-6
JOINT, DRIVE	F-11-16
JOINT, FUEL PIPE	E-14-8
JOINT, FUEL PIPE	E-18-38
JOINT, FUEL RETURN	E-18-10-11
JOINT, WATER HOSE	F-3-20-2
JOINT,FUEL TUBE	F-8-20-6
<K>	
KEY, 4.5X24	E-13-26
KEY, SPECIAL	E-13-27
KEY, WOODRUFF	F-4-22
KEY, WOODRUFF	FOP-2-11
KIT, CABLE(NMEA)(6FT)	FOP-12-1
<L>	
LABEL, FUSE & OIL CAUTION	F-12-16
LABEL, WARNING OPERATOR	F-12-14
LAMP ASSY., INDICATION	FOP-3-6-44
LAMP ASSY., INDICATION(4-LED)	FOP-4-19
LAMP ASSY., INDICATION(4-LED)	FOP-4-1-11
LEVER SET	E-21-18
LEVER, COVER LOCK	F-8-10-14
LEVER, HANDLE LOCK	FOP-3-6-3
LEVER, IDLE	FOP-3-6-22
LINER, PUMP	F-4-3
LINER, PUMP	FOP-2-5
LINER, SWIVEL CASE	F-10-22
LOCK ASSY., FR.	F-8-10-22
LOCK COMP., SIDE	F-8-10-23
LOW PERMEATION HOSE L=1600	F-6-7
LOW PERMEATION HOSE L=700	F-6-6
<M>	
MANIFOLD COMP., INTAKE	E-14-10-3
MANIFOLD COMP., L. EX.	E-4-4
MANIFOLD COMP., R. EX.	E-4-2
MARK, FAST IDLE	FOP-3-6-48
MARK, FLUSH MOUNT	FOP-3-4-19
MARK, FR. EMBLEM(TOYOTA)	F-12-19
MARK, HANDLE FLUSH MOUNT	FOP-3-4-18
MARK, L. SIDE STRIPE	F-12-18
MARK, R. SIDE STRIPE	F-12-6
MARK, REMOTE CONTROL(DUAL)	FOP-3-2-24
MARK, REMOTE CONTROL(SINGLE)	FOP-3-21
MARK, RR.(BFT200)	F-12-3
MARK, RR.(BFT225)	F-12-4
MESH, FUEL FILTER	E-14-4
METAL COMP., ANODE	F-3-10
METAL KIT, ANODE	F-10-1
METAL, ANODE	E-3-4
METAL, ANODE	E-3-5
METAL, ANODE	E-4-1
METER LEAD WIRE	FOP-5-1-8
MOTION COMP., LOST	E-9-10
MOTION COMP., LOST	E-9-
MOTOR ASSY., POWER TILT	F-11-5
MOTOR ASSY., STARTER	E-21-1
MOUNT COMP., LOWER RUBBER	F-3-20-17
MOUNT COMP., UPPER RUBBER	F-10-15
<N>	
NIPPLE, GREASE	F-10-68
NIPPLE, SENSOR	F-10-11
NUT, CASTLE, 18MM	F-5-14
NUT, CASTLE, 18MM	F-5-1-14
NUT, FLANGE CAP, 10MM	E-3-10-15
NUT, FLANGE, 10MM	F-10-51
NUT, FLANGE, 12MM	F-10-48
NUT, FLANGE, 5MM	FOP-4-4
NUT, FLANGE, 5MM	FOP-4-1-2
NUT, FLANGE, 8MM	E-14-25
NUT, FLANGE, 8MM	E-14-10-19

NUT, FLANGE, 8MM.....	E-19-25	O-RING, 37X2.4(ARAI).....	E-1-29	PLATE, HANDLE	FOP-3-10
NUT, HEX., 12MM.....	F-10-72	O-RING, 48.5X2.4.....	E-9-20	PLATE, HANDLE	FOP-3-2-11
NUT, HEX., 16MM.....	F-3-20-41	O-RING, 49.4X3.1.....	E-6-10-46	PLATE, INTAKE MANIFOLD CENTER.....	E-14-10-4
NUT, HEX., 16MM.....	FOP-3-6-53	O-RING, 59.4X3.1.....	E-21-23	PLATE, L. TIMING BELT COVER.....	E-13-10-4
NUT, HEX., 16MM.....	FOP-4-24	O-RING, 6.9X1.45.....	F-3-30	PLATE, LEVER SETTING.....	FOP-3-6-8
NUT, HEX., 16MM.....	FOP-4-1-16	O-RING, 6.9X1.45.....	F-3-31	PLATE, LOCK.....	F-2-13
NUT, HEX., 18MM.....	F-4-19	O-RING, 66.4X3.1.....	E-4-24	PLATE, R. TIMING BELT COVER.....	E-13-10-5
NUT, HEX., 20MM.....	F-2-27	O-RING, 69.1X2.4.....	F-4-31	PLATE, REMOTE CONTROL.....	FOP-3-6-47
NUT, HEX., 5MM.....	FOP-3-29	O-RING, 69.1X2.4.....	FOP-2-14	PLATE, REMOTE CONTROL CABLE.....	F-2-2
NUT, HEX., 5MM.....	FOP-3-35	O-RING, 7.45X3.61(NOK).....	E-14-29	PLATE, RUBBER SETTING.....	F-3-2
NUT, HEX., 5MM.....	FOP-3-2-33	O-RING, 7.47X3.6.....	E-14-28	PLATE, SHIFT.....	F-5-7
NUT, HEX., 5MM.....	FOP-3-2-34	O-RING, 7.8X1.9(ARAI).....	E-14-27	PLATE, SHIFT.....	F-5-1-7
NUT, HEX., 5MM.....	FOP-3-2-40	O-RING, 7.8X1.9(ARAI).....	E-18-54	PLATE, SPRING SETTING.....	FOP-3-6-23
NUT, HEX., 5MM.....	FOP-3-6-76	O-RING, 8.8X2.4.....	E-3-11	PLATE, STARTER CABLE.....	F-8-10-2
NUT, HEX., 6MM.....	E-19-27	O-RING, 9.5X1.9.....	E-3-42	PLATE, TIMING BELT GUIDE.....	E-13-2
NUT, HEX., 6MM.....	F-8-18	O-RING, 9.5X1.9.....	E-4-25	PLATE, WATER TUBE.....	E-6-7
NUT, HEX., 6MM.....	FOP-3-4-25	O-RING, PRESSURE REGULATOR.....	E-14-7	PLATE, WINKER BUZZER.....	FOP-3-6-45
NUT, HEX., 6MM.....	FOP-3-6-54	O-RING, TIMING BELT TENSIONER.....	E-13-11	PLATE, WINKER BUZZER.....	FOP-4-20
NUT, HEX., 6MM.....	FOP-3-6-75	O-RING, WATER PUMP.....	F-4-29	PLATE, WINKER BUZZER.....	FOP-4-1-12
NUT, LOCK, 64MM.....	F-4-18	O-RING, WATER PUMP.....	FOP-2-12	PLUG, BLIND, 20MM.....	F-8-2
NUT, PULLEY LOCK.....	E-19-7	O-RING, WATER PUMP HOUSING.....	F-4-30	PLUG, FUEL TUBE.....	F-8-20-2
NUT, SELF-LOCK(25X2.0).....	F-10-50	O-RING, WATER PUMP HOUSING.....	FOP-2-13	PLUG, HOLE, 5MM.....	F-3-20-55
NUT, SELF-LOCK(3/8-24UNF).....	F-10-52	<P>.....		PLUG, INNER CONNECTOR.....	FOP-3-6-35
NUT, SELF-LOCK(7/8-14UNF).....	F-10-49	PACKING.....	E-21-17	PLUG, INNER CONNECTOR.....	FOP-4-11
NUT, SELF-LOCK, 12MM.....	F-3-22	PACKING.....	F-11-47	PLUG, INNER CONNECTOR.....	FOP-4-1-5
NUT, SELF-LOCK, 14MM.....	F-3-20-42	PACKING, DUAL.....	FOP-3-2-19	PLUG, OUTER CONNECTOR.....	FOP-3-6-36
NUT, SELF-LOCK, 5MM.....	F-3-20	PACKING, FLASH VALVE.....	E-6-10-16	PLUG, OUTER CONNECTOR.....	FOP-4-12
NUT, SELF-LOCK, 6MM.....	F-3-19	PACKING, HEAD COVER.....	E-1-2	PLUG, OUTER CONNECTOR.....	FOP-4-1-6
NUT, SELF-LOCK, 6MM.....	F-10-47	PACKING, INTAKE MANIFOLD UP.....	E-14-10-6	PLUG, SPARK(IZFR6K-11E)(NGK).....	E-20-2
NUT, TAPPET ADJUSTING.....	E-9-10-23	PACKING, OIL HOLE.....	E-3-9	PRIMER BULB.....	F-6-4
NUT, TAPPET ADJUSTING.....	E-9-10-24	PACKING, OIL LEVEL GAUGE.....	E-3-15	PRIMER BULB ASSY.....	F-6-1
NUT, WATER MOUTH.....	F-3-20-1	PACKING, OIL PAN.....	E-6-2	PROPELLER COMP., THREE BLADES.....	FOP-10-1
NUT-WASHER, 5MM.....	E-19-26	PACKING, OIL PUMP BODY.....	E-5-2	PROPELLER COMP., THREE BLADES.....	FOP-10-
NUT-WASHER, 6MM.....	F-7-11-18	PACKING, RELIEF VALVE.....	E-6-10-15	PROPELLER COMP., THREE BLADES.....	FOP-10-
NUT-WASHER, 8MM.....	F-7-11-17	PACKING, RELIEF VALVE COVER.....	E-6-10-14	PROPELLER COMP., THREE BLADES.....	FOP-10-
<O>.....		PACKING, SINGLE.....	FOP-3-18	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL.....	F-11-37	PACKING, THROTTLE BODY.....	E-14-10-2	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 14X26X6.....	F-2-37	PACKING, WATER JACKET COVER.....	E-6-10-20	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 31X46X7(NOK).....	E-5-18	PAN, OIL.....	E-6-1	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 39.5X52X6(ARAI).....	F-10-69	PANEL ASSY., INDICATOR(4-LED).....	FOP-4-18	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 39X53X8(NOK).....	E-9-19	PANEL ASSY., SWITCH.....	FOP-4-6	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 41X66X8.....	E-3-40	PANEL KIT, SWITCH(4-LED).....	FOP-4-1-1	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 46X60X9.....	E-5-17	PANEL KIT, SWITCH(B)(4-LED).....	FOP-4-1	PROPELLER COMP., THREE BLADES.....	FOP-10-
OIL SEAL, 80X98X10(ARAI).....	E-3-41	PANEL, CONTROL.....	FOP-4-7	PROPELLER COMP., THREE BLADES.....	FOP-10-
ORIFICE ASSY., OIL CONTROL.....	E-3-10	PANEL, CONTROL.....	FOP-4-8	PROPELLER COMP., THREE BLADES.....	FOP-10-
O-RING.....	E-14-10-13	PANEL, CONTROL.....	FOP-4-1-3	PROPELLER COMP., THREE BLADES.....	FOP-10-
O-RING.....	E-15-23	PIN B, DOWEL, 10X16.....	E-5-21	PROPELLER COMP., THREE BLADES.....	FOP-10-
O-RING.....	E-18-13	PIN B, DOWEL, 10X16.....	E-6-10-51	PROPELLER COMP., THREE BLADES.....	FOP-10-
O-RING.....	E-18-14	PIN, 6X6.....	FOP-3-6-63	PULLER, MINI FUSE.....	F-7-30-4
O-RING.....	E-18-15	PIN, LINK.....	F-2-35	PULLEY.....	E-19-6
O-RING.....	E-18-16	PIN, LOCK, 6MM.....	FOP-3-6-62	PULLEY COMP., L. TIMING BELT.....	E-13-5
O-RING.....	E-18-17	PIN, PISTON.....	E-7-3	PULLEY COMP., R. TIMING BELT.....	E-13-4
O-RING.....	E-18-18	PIN, SHIFTER, 8X50.....	F-5-2	PULLEY, CRANKSHAFT.....	E-13-3
O-RING.....	E-18-19	PIN, SHIFTER, 8X50.....	F-5-1-2	PULLEY, TIMING BELT DRIVE.....	E-13-1
O-RING.....	E-18-2-21	PIN, SNAP, 6MM.....	F-2-34	PUMP ASSY.....	F-11-14
O-RING.....	E-18-2-22	PIN, SPLIT, 4.0.....	F-3-26	PUMP ASSY., FUEL.....	E-1-9
O-RING.....	E-18-2-24	PIN, SPLIT, 4.0.....	F-5-21	PUMP ASSY., OIL.....	E-5-1
O-RING.....	F-3-32	PIN, SPLIT, 4.0.....	F-5-1-21	PUMP KIT, IMPELLER.....	FOP-2-1
O-RING.....	F-4-28	PIN, SPRING, 3X20.....	F-10-73	PUMP KIT, IMPELLER.....	FOP-2-2
O-RING SET, 3.5X31.7.....	F-11-45	PIN, UPPER CYLINDER.....	F-11-26	PUMP UNIT SET A, FUEL.....	E-18-7
O-RING, 1.8X69.6.....	F-11-39	PIN, VERTICAL SHAFT.....	E-13-18	PUMP UNIT SET B, FUEL.....	E-18-9
O-RING, 1.8X7.7.....	F-11-41	PIPE COMP., L. EX.....	E-6-5	PUMP UNIT, FUEL.....	E-18-37
O-RING, 1.9X11.....	F-11-42	PIPE COMP., L. FUEL.....	E-14-5	<R>.....	
O-RING, 110X3.1.....	F-3-33	PIPE COMP., R. EX.....	E-6-3	RECEIVER, THRUST.....	F-10-30
O-RING, 110X3.1.....	F-5-28	PIPE, FUEL.....	E-18-10-6	RECTIFIER ASSY.....	E-19-19
O-RING, 110X3.1.....	F-5-1-29	PIPE, HARNESS GUIDE.....	FOP-3-6-32	REGULATOR ASSY.....	E-19-20
O-RING, 13X1.5(ARAI).....	E-3-46	PIPE, R. FUEL.....	E-14-3	REGULATOR ASSY., PRESSURE.....	E-14-6
O-RING, 15.54X2.26.....	F-10-70	PISTON.....	E-7-2	RELAY ASSY., FUEL PUMP(DENSO).....	F-7-30-5
O-RING, 16.3X3.5.....	E-3-45	PISTON COMP., FREE.....	F-11-22	RELAY ASSY., POWER TILT.....	F-7-11-9
O-RING, 16MM.....	E-6-10-45	PISTON(0.25).....	E-7-	RELAY ASSY., POWER(12V-20A).....	F-7-30-6
O-RING, 18.3X3.5.....	E-3-43	PIVOT, SHIFT.....	F-2-12	RETAINER, SPRING.....	E-7-13
O-RING, 2.0X70.5.....	F-11-38	PIVOT, SHIFT.....	FOP-3-6-17	RETAINER, SPRING.....	E-7-
O-RING, 20.6X2.6.....	E-5-19	PLATE.....	E-18-10	RETAINER, VALVE SPRING.....	E-9-10-18
O-RING, 23.5X2.....	E-6-10-48	PLATE.....	E-18-44	RING.....	E-18-32
O-RING, 25X2.4(NOK).....	E-3-47	PLATE.....	E-18-2-23	RING SET, PISTON(0.25).....	E-7-
O-RING, 26.2X2.4(NOK).....	E-3-44	PLATE COMP., SLIDING.....	FOP-3-6-15	RING SET, PISTON(STD.).....	E-7-1
O-RING, 26.9X2.4(NOK).....	F-2-39	PLATE SET, TRANSOM(5.5MM FLAT).....	FOP-9-2	RING, BACK UP.....	F-11-19
O-RING, 26X2.7.....	E-3-10-16	PLATE SET, TRIM ADJUST.....	FOP-9-1	RING, CROSS PIN.....	F-5-3
O-RING, 3.5X35.7.....	F-11-43	PLATE, CABLE CLAMP.....	FOP-3-11	RING, CROSS PIN.....	F-5-1-3
O-RING, 3.5X38.7.....	F-11-40	PLATE, CABLE CLAMP.....	FOP-3-2-12	RING, INNER(15X20X23).....	F-2-36
O-RING, 3.5X41.7.....	F-11-44	PLATE, DWELL.....	FOP-3-15	RING, STOPPER.....	F-2-7
O-RING, 31.5X2.4(ARAI).....	E-4-26	PLATE, DWELL.....	FOP-3-2-16	RING, WATER TUBE SEAL.....	F-4-8
O-RING, 33.5X2.....	E-6-10-47	PLATE, DWELL.....	FOP-3-4-10	RING, WATER TUBE SEAL.....	FOP-2-8

ROD COMP. A, SHIFT(L)	F-4-11	SCREW, TAPPING, 5X25	FOP-3-6-74	SHIM D, BEVEL(0.50)	F-5-1-
ROD COMP. A, SHIFT(XL)	F-4-	SCREW, TAPPING, 5X8	FOP-3-6-70	SHIM D, GEAR(0.50)	F-4-
ROD COMP., CONNECTING	E-7-6	SCREW, TAPPING, 6X16	FOP-3-6-73	SHIM D, THRUST(0.50)	F-5-1-
ROD COMP., PISTON	F-11-21	SCREW, TAPPING, 6X30	FOP-3-4-24	SHIM D, THRUST(2.90)	F-5-
ROD COMP., PISTON(B)	F-11-15	SCREW, TRUSS, 4X12	FOP-3-4-21	SHIM E, THRUST(2.95)	F-5-
ROD COMP., SHIFT	F-4-9	SCREW, WASHER	E-18-22	SHIM F, THRUST(3.00)	F-5-
ROD COMP., SHIFT	F-4-	SCREW, WAVE WASHER	E-19-12	SHIM G, THRUST(3.05)	F-5-
ROD KIT, STEERING	F-10-3	SCREW, WAVE WASHER	E-19-13	SHIM H, THRUST(3.10)	F-5-
ROD, LINK	F-2-10	SCREW-WASHER	E-18-20	SHIM I, THRUST(2.70)	F-5-
ROLLER, 3X13.8	F-5-26	SCREW-WASHER	E-19-11	SHIM J, THRUST(2.65)	F-5-
ROLLER, 3X13.8	F-5-1-27	SCREW-WASHER, 5X15	F-7-30-8	SHIM K, THRUST(2.60)	F-5-
ROLLER, 5X8	E-5-25	SCREW-WASHER, 6X40	F-3-20-40	SHIM L, THRUST(2.55)	F-5-
ROLLER, CLICK	FOP-3-6-64	SEAL A, COVER UNDER	F-3-20-22	SHIM M, THRUST(2.50)	F-5-
ROTOR ASSY	E-19-15	SEAL A, VALVE STEM(NOK)	E-9-4	SLIDER COMP., SHIFT	F-5-4
ROTOR COMP.	E-21-2	SEAL B, COVER UNDER	F-3-20-23	SLIDER COMP., SHIFT	F-5-1-4
ROTOR, OIL PUMP INNER	E-5-5	SEAL B, EX. GUIDE	E-6-10-4	SLIDER, SHIFT	F-5-5
ROTOR, OIL PUMP OUTER	E-5-6	SEAL B, VALVE STEM(NOK)	E-9-6	SLIDER, SHIFT	F-5-1-5
RUBBER C, STAND STOPPER	F-3-20-56	SEAL C, UNDER COVER	F-3-20-25	SLINGER, OIL	F-4-15
RUBBER, DRAIN PLUG	F-3-20-11	SEAL D, UNDER COVER	F-8-10-25	SPACER KIT, REMOTE CONTROL BOX ..	FOP-3-2
RUBBER, FR. CARRIER CUSHION	F-8-10-11	SEAL, ENGINE COVER	F-8-4	SPACER KIT, REMOTE CONTROL BOX ..	FOP-3-2-2
RUBBER, MOUNT CASE SEAL	E-6-10-24	SEAL, EXHAUST GUIDE	E-6-10-3	SPACER, CABLE CLAMP	FOP-3-17
RUBBER, OIL PUMP	E-5-3	SEAL, L. IDOL PORT	F-3-20-15	SPACER, CABLE CLAMP	FOP-3-2-18
RUBBER, SEAL SILENCER	E-15-7	SEAL, R. IDOL PORT	F-3-20-14	SPACER, CABLE CLAMP	FOP-3-4-13
RUBBER, STOPPER	F-8-10-10	SEAL, SPARK PLUG TUBE(NOK)	E-1-4	SPACER, CABLE CLAMP	FOP-3-6-33
RUBBER, UPPER MOUNT STOPPER	F-10-16	SEAL, UPPER MOUNT COVER	F-10-19	SPACER, CLICK SPRING	FOP-3-6-27
<S>		SEAL, WATER	F-11-46	SPACER, INTAKE MANIFOLD	E-14-16
SCREEN COMP., FUEL STRAINER	E-18-39	SEAL, WATER(14X26X8)	F-2-38	SPACER, L. RELIEF VALVE	E-6-10-18
SCREEN, L. WATER	F-3-8	SEAL, WATER, 12X21X6	F-3-29	SPACER, NEUTRAL SWITCH	FOP-3-6-30
SCREEN, R. WATER	F-3-7	SEAL, WATER, 12X21X6	F-4-27	SPACER, R. RELIEF VALVE	E-6-10-12
SCREW	E-19-9	SEAL, WATER, 22X35X7	E-6-10-44	SPACER, REMOTE CONTROL BOX	FOP-3-6-26
SCREW	E-19-10	SEAL, WATER, 26X42X7	F-3-27	SPACER, THERMOSTAT	E-4-12
SCREW SET	E-15-1	SEAL, WATER, 26X42X7	F-4-26	SPACER, THROTTLE BODY	E-15-4
SCREW SET, DRAIN	E-18-5	SEAL, WATER, 30X45X7	F-3-28	SPRING COMP., CLICK	F-2-5
SCREW SET, DRAIN	E-18-2-1	SEAL, WATER, 30X45X7	F-5-27	SPRING COMP., CLICK	F-10-4
SCREW, 6X95	FOP-3-6-52	SEAL, WATER, 30X45X7	F-5-1-28	SPRING COMP., TIMING BELT	E-13-9
SCREW, FLAT, 5X12	FOP-3-6-51	SEAT, SPRING(225)	E-7-14	SPRING, ACCELERATOR WHEEL	FOP-3-6-21
SCREW, FLAT, 5X55	F-3-12	SEAT, SPRING(225)	E-7-	SPRING, AIR FLOW TUBE	E-15-8
SCREW, FLAT, 6X16	E-5-20	SEAT, VALVE SPRING	E-9-10-19	SPRING, CHOKE RETURN	FOP-3-6-25
SCREW, PAN	E-18-21	SEAT, WATER MOUTH	F-3-20-3	SPRING, CLICK ASSIST	F-2-6
SCREW, PAN, 4X10	FOP-3-26	SENSOR ASSY., AIR TEMP	E-15-14	SPRING, CLICK ASSIST	F-10-5
SCREW, PAN, 4X10	FOP-3-2-29	SENSOR ASSY., CRANK	E-3-25	SPRING, COVER LOCK HOOK	F-8-10-17
SCREW, PAN, 5X10	FOP-3-23	SENSOR ASSY., MAP	E-14-10-12	SPRING, EX. VALVE	E-9-10-17
SCREW, PAN, 5X10	FOP-3-2-26	SENSOR ASSY., TRIM ANGLE	F-10-7	SPRING, FLUSH VALVE	E-6-10-8
SCREW, PAN, 5X10	FOP-3-6-69	SENSOR ASSY., WATER	E-3-24	SPRING, IN. VALVE(GRAY)	E-9-10-16
SCREW, PAN, 5X12	E-18-2-15	SENSOR ASSY., WATER	E-4-14	SPRING, LOCK ADJUSTER	F-8-8
SCREW, PAN, 5X16	E-3-49	SENSOR COMP., KNOCK	E-3-18	SPRING, LOCK LEVER RETURN	F-8-10-18
SCREW, PAN, 5X16	FOP-3-22	SENSOR COMP., TDC1-TDC2	E-13-10-6	SPRING, MOTOR	F-11-9
SCREW, PAN, 5X16	FOP-3-2-25	SENSOR, OXYGEN	E-4-13	SPRING, NEUTRAL LOCK ARM	FOP-3-4-7
SCREW, PAN, 5X16	FOP-3-4-20	SEPARATOR ASSY., VAPOR	E-18-33	SPRING, RELIEF VALVE	E-5-9
SCREW, PAN, 5X18	FOP-3-25	SEPARATOR ASSY., WATER	E-18-2-6	SPRING, RELIEF VALVE	E-6-10-11
SCREW, PAN, 5X18	FOP-3-2-28	SHAFT ASSY., CLUTCH	E-21-13	SPRING, REMOTE CONTROL HANDLE ..	FOP-3-6-7
SCREW, PAN, 5X20	E-3-50	SHAFT ASSY., GEAR	E-21-15	SPRING, ROCKER ARM	E-9-10-10
SCREW, PAN, 5X20	FOP-3-24	SHAFT COMP., EX. ROCKER ARM	E-9-10-9	SPRING, SET	E-18-40
SCREW, PAN, 5X20	FOP-3-2-27	SHAFT COMP., FR. INTAKE ROCKER ..	E-9-10-8	SPRING, SHIFT	F-5-6
SCREW, PAN, 5X30	FOP-3-4-22	SHAFT COMP., INTAKE ROCKER ARM ..	E-9-10-	SPRING, SHIFT	F-5-1-6
SCREW, PAN, 5X40	FOP-3-28	SHAFT COMP., SHIFT(A)	F-2-8	SPRING, SHIFT CLICK	FOP-3-6-24
SCREW, PAN, 5X40	FOP-3-2-31	SHAFT COMP., SHIFT(B)	F-2-14	SPRING, SHIFT ROD	F-4-10
SCREW, PAN, 5X40	FOP-4-23	SHAFT, COVER OPEN	F-8-10-19	SPRING, SUPPORT	E-7-15
SCREW, PAN, 5X40	FOP-4-1-15	SHAFT, FR. LOCK	F-8-10-20	SPRING, SUPPORT	E-7-
SCREW, PAN, 5X55	FOP-3-2-32	SHAFT, PROPELLER	F-5-10	STAY COMP.	E-18-2-3
SCREW, PAN, 5X65	FOP-3-34	SHAFT, PROPELLER	F-5-1-10	STAY, A.C. GENERATOR	E-19-16
SCREW, PAN, 5X65	FOP-3-2-39	SHAFT, THROTTLE BUTTON	FOP-3-4-9	STAY, FUEL PIPE A	E-18-2-4
SCREW, PAN, 5X8	E-21-22	SHAFT, TILTING	F-10-26	STAY, FUEL PIPE B	E-18-2-5
SCREW, PAN, 6X10	FOP-3-6-50	SHAFT, VERTICAL(L)	F-4-14	STAY, FUEL STRAINER	E-18-2-18
SCREW, PAN, 6X18	E-4-27	SHAFT, VERTICAL(XL)	F-4-	STAY, PLATE	E-18-8
SCREW, PAN, 6X18	FOP-3-27	SHIFTER, CLUTCH	F-5-1	STAY, PLATE	E-18-36
SCREW, PAN, 6X18	FOP-3-2-30	SHIFTER, CLUTCH	F-5-1-1	STAY, POWER TILT SWITCH	F-3-20-6
SCREW, PAN, 6X22(SPECIAL)	E-21-21	SHIM A, BEVEL(0.10)	F-5-18	STAY, VACUUM TANK	E-18-43
SCREW, PAN, 6X25	F-3-20-	SHIM A, BEVEL(0.10)	F-5-1-18	STAY, WATER SEPARATOR	E-18-2-9
SCREW, PAN, 6X35	FOP-3-4-23	SHIM A, GEAR(0.10)	F-4-21	STOPPER SET, SLEEVE	E-21-8
SCREW, PAN, 6X8	F-10-44	SHIM A, THRUST(0.10)	F-5-1-19	STOPPER, LOWER MOUNT	F-3-20-18
SCREW, PAN, 6X8	F-10-77	SHIM A, THRUST(2.75)	F-5-19	STOPPER, TILT	F-10-29
SCREW, PAN, 6X8	F-11-33	SHIM B, BEVEL(0.15)	F-5-	STRAINER ASSY., FUEL	E-18-2-13
SCREW, RIVET, 5X10	F-10-45	SHIM B, BEVEL(0.15)	F-5-1-	STRAINER COMP., OIL	E-5-7
SCREW, RIVET, 5X10	F-11-34	SHIM B, GEAR(0.15)	F-4-	STRAINER, FUEL PUMP	E-18-10-7
SCREW, SPECIAL, 6X35	F-3-20-33	SHIM B, THRUST(0.15)	F-5-1-	SUB HARNESS ASSY., POWER	FOP-3-19
SCREW, TAPPET ADJUSTING	E-9-10-14	SHIM B, THRUST(2.80)	F-5-	SUB HARNESS ASSY., POWER	FOP-3-2-20
SCREW, TAPPET ADJUSTING	E-9-10-15	SHIM C, BEVEL(0.30)	F-5-	SUB HARNESS ASSY., POWER	FOP-3-2-21
SCREW, TAPPING, 4X10	F-8-16	SHIM C, BEVEL(0.30)	F-5-1-	SUB HARNESS ASSY., POWER	FOP-3-4-16
SCREW, TAPPING, 4X10	F-8-17	SHIM C, GEAR(0.30)	F-4-	SUSPENSION, COUPLER	F-7-2
SCREW, TAPPING, 5X10	FOP-3-6-71	SHIM C, THRUST(0.30)	F-5-1-	SUSPENSION, STRAINER	E-18-2-19
SCREW, TAPPING, 5X12	FOP-3-6-72	SHIM C, THRUST(2.85)	F-5-	SUSPENSION, STRAINER	E-18-2-20
SCREW, TAPPING, 5X20	E-15-25	SHIM D, BEVEL(0.50)	F-5-	SUSPENSION, STRAINER	E-18-10-8

SWITCH ASSY., COMBINATION	FOP-3-6-38	VALVE, CHECK	E-18-10-17	WASHER, UPPER MOUNTING STOPPER ..	F-10-57
SWITCH ASSY., COMBINATION	FOP-4-14	VALVE, EX.	E-9-10-13	WASHER, WAVE, 10MM	F-8-10-33
SWITCH ASSY., COMBINATION	FOP-4-1-7	VALVE, FLASH	E-6-10-10	WASHER, WAVE, 12MM	F-10-54
SWITCH ASSY., EMERGENCY STOP	FOP-3-6-41	VALVE, IN.	E-9-10-12	WASHER, WAVE, 26MM	F-10-55
SWITCH ASSY., EMERGENCY STOP	FOP-4-15	VALVE, RELIEF	E-5-8	WASHER, WAVE, 40MM	F-10-53
SWITCH ASSY., EMERGENCY STOP	FOP-4-1-8	VALVE, RELIEF	E-6-10-9	WASHER, WAVE, 8MM	F-8-10-39
SWITCH ASSY., MAGNET	E-21-12	<W>		WHEEL, ACCELERATOR	FOP-3-6-20
SWITCH ASSY., NEUTRAL	F-2-43	WASHER	F-2-31	WHEEL, CONTROL	FOP-3-6-13
SWITCH ASSY., OIL PRESSURE	E-3-22	WASHER B, THRUST, 14MM	F-2-29	WIRE, LEAD(1.5X116MM)	F-10-9
SWITCH ASSY., OIL PRESSURE	E-3-23	WASHER KIT, THRUST(175/200/225) ..	E-7-16	WIRE, LEAD(1.5X116MM)	F-11-11
SWITCH ASSY., POWER TILT	F-3-20-5	WASHER KIT, THRUST(175/200/225) ..	E-7-	WRENCH, BOX(10MM)	F-13-11
SWITCH ASSY., POWER TRIM-TILT	FOP-3-20	WASHER, 10MM	F-10-61	WRENCH, EYE, 19MM	F-13-12
SWITCH ASSY., POWER TRIM-TILT	FOP-3-2-22	WASHER, 25MM	F-10-59	WRENCH, HEX., 6MM	F-13-7
SWITCH ASSY., POWER TRIM-TILT	FOP-3-2-23	WASHER, 28MM	FOP-3-6-61	WRENCH, PLUG.	F-13-6
SWITCH ASSY., POWER TRIM-TILT	FOP-3-4-17	WASHER, 30MM	F-3-20-43	<Y>	
SWITCH ASSY., POWER TRIM-TILT	FOP-3-6-39	WASHER, 6MM	FOP-3-6-59	YOKE ASSY.	F-11-8
SWITCH KIT, LIGHT.	FOP-4-3	WASHER, 7/8INCH	F-10-58	YOKE COMP.	E-21-5
<T>		WASHER, 8MM	FOP-2-10		
TAB, TRIM	F-3-9	WASHER, AIR CLEANER COVER	F-2-1		
TACHOMETER HOUR METER (BLACK) ..	FOP-5-1-4	WASHER, CONICAL SPRING(5)	E-14-10-11		
TANK COMP., VACUUM	E-18-42	WASHER, DRAIN PLUG, 12MM.	E-6-13		
TANK, OIL	F-11-27	WASHER, LOCK, 5MM	FOP-3-30		
TENSIONER COMP., TIMING BELT	E-13-7	WASHER, LOCK, 5MM	FOP-3-2-35		
TERMINAL, CABLE	FOP-3-16	WASHER, LOCK, 5MM	FOP-3-4-26		
TERMINAL, CABLE	FOP-3-2-17	WASHER, LOCK, 6MM	FOP-3-32		
TERMINAL, CABLE	FOP-3-4-12	WASHER, LOCK, 6MM	FOP-3-2-37		
THERMOSTAT ASSY.	E-4-10	WASHER, PIVOT	F-2-4		
THROTTLE BODY ASSY.	E-15-3	WASHER, PLAIN	E-18-24		
TIE, CABLE	FOP-12-2	WASHER, PLAIN	E-18-25		
TIE, CABLE(NATURAL)(2.4X92)	FOP-3-6-37	WASHER, PLAIN, 10MM	E-6-10-39		
TIE, CABLE(NATURAL)(2.4X92)	FOP-4-13	WASHER, PLAIN, 10MM	F-3-20-47		
T-JOINT	E-1-14	WASHER, PLAIN, 10MM	F-8-10-32		
T-JOINT	E-18-10-16	WASHER, PLAIN, 10MM	F-10-62		
TRAP, FLAME	E-15-6	WASHER, PLAIN, 12MM	E-6-10-38		
TRIM METER ASSY (BLACK)	FOP-5-1-1	WASHER, PLAIN, 12MM	F-3-23		
TRIM-TILT ASSY., POWER	F-11-13	WASHER, PLAIN, 12MM	F-3-20-46		
TUBE A, AIR VENT.	E-18-10-3	WASHER, PLAIN, 12MM	F-4-20		
TUBE B, AIR VENT.	E-18-10-4	WASHER, PLAIN, 12MM	F-5-20		
TUBE B, BREATHER.	E-1-31	WASHER, PLAIN, 12MM	F-5-1-20		
TUBE C, BREATHER.	E-1-32	WASHER, PLAIN, 12MM	F-8-14		
TUBE COMP. A, BREATHER	E-1-30	WASHER, PLAIN, 12MM	F-10-63		
TUBE COMP. A, FUEL.	F-8-20-4	WASHER, PLAIN, 12MM	F-10-64		
TUBE COMP. B, FUEL.	E-18-2-10	WASHER, PLAIN, 14MM	F-3-20-44		
TUBE COMP. D, FUEL.	E-18-2-11	WASHER, PLAIN, 4MM	FOP-3-6-55		
TUBE COMP. E, FUEL	E-18-2-12	WASHER, PLAIN, 5MM	FOP-3-31		
TUBE COMP. G, FUEL.	E-1-12	WASHER, PLAIN, 5MM	FOP-3-33		
TUBE COMP., AIR VENT.	E-18-10-5	WASHER, PLAIN, 5MM	FOP-3-2-36		
TUBE COMP., FUEL(C)	E-1-34	WASHER, PLAIN, 5MM	FOP-3-2-38		
TUBE KIT, SPEED SENSOR	F-10-2	WASHER, PLAIN, 5MM	FOP-3-6-56		
TUBE, 5X200	F-10-74	WASHER, PLAIN, 5MM	FOP-3-6-57		
TUBE, 5X950	F-10-75	WASHER, PLAIN, 5MM	FOP-4-26		
TUBE, CHECK VALVE	E-18-10-2	WASHER, PLAIN, 5MM	FOP-4-1-18		
TUBE, FLUSH VALVE	E-6-10-50	WASHER, PLAIN, 6MM	E-15-22		
TUBE, FUEL, 3.5X130	E-14-10-21	WASHER, PLAIN, 6MM	F-2-30		
TUBE, FUEL, 3.5X40	E-14-10-20	WASHER, PLAIN, 6MM	F-2-32		
TUBE, FUEL, 3.5X50	E-14-31	WASHER, PLAIN, 6MM	F-2-33		
TUBE, FUEL, 3.5X540	E-14-10-22	WASHER, PLAIN, 6MM	F-8-13		
TUBE, FUEL, 3.5X55	E-18-10-22	WASHER, PLAIN, 6MM	F-10-60		
TUBE, FUEL, 3.5X590	E-14-10-23	WASHER, PLAIN, 6MM	FOP-3-4-27		
TUBE, FUEL, 3.5X600	E-14-10-24	WASHER, PLAIN, 6MM	FOP-3-6-58		
TUBE, L. WATER RETURN	E-4-9	WASHER, PLAIN, 8MM	E-1-23		
TUBE, OIL.	E-1-5	WASHER, PLAIN, 8MM	E-6-12		
TUBE, R. WATER RETURN	E-4-6	WASHER, PLAIN, 8MM	F-7-11-19		
TUBE, SPIRAL(12X14.6)	F-11-4	WASHER, PLAIN, 8MM	F-8-10-28		
TUBE, VINYL, 3.5X6.5X350	E-18-2-34	WASHER, PLAIN, 8MM	F-8-10-34		
TUBE, VINYL, 3.5X6.5X600	E-18-10-23	WASHER, PLAIN, 8MM	FOP-3-6-60		
TUBE, WATER	E-4-8	WASHER, PROPELLER	F-5-17		
TUBE, WATER CHECK	E-6-10-49	WASHER, PROPELLER	F-5-1-17		
TUBE, WATER IN.	E-18-10-14	WASHER, PROPELLER THRUST	F-5-15		
TUBE, WATER JOINT	F-3-20-52	WASHER, PROPELLER THRUST	F-5-1-15		
TUBE, WATER OUTLET	E-18-10-15	WASHER, SEALING(22MM)	E-3-8		
TUBE, WATER RELIEF	E-4-7	WASHER, SEALING, 22MM	E-3-7		
TUBE, WATER(L)	F-4-7	WASHER, SEALING, 6MM	E-18-52		
TUBE, WATER(XL)	F-4-	WASHER, SPRING, 5MM	FOP-4-27		
<V>		WASHER, SPRING, 5MM	FOP-4-1-19		
VALVE ASSY., AIR BYPASS	E-14-10-10	WASHER, THRUST	E-7-10		
VALVE ASSY., EAC.	E-15-15	WASHER, THRUST	E-7-		
VALVE ASSY., SPOOL	E-3-16	WASHER, THRUST	E-7-		
VALVE ASSY., SPOOL	E-3-	WASHER, THRUST	E-9-10-11		
VALVE COMP., MANUAL	F-11-23	WASHER, THRUST BEARING	F-5-16		
VALVE COMP., RESERVOIR	F-11-24	WASHER, THRUST BEARING	F-5-1-16		
VALVE SET, FLOAT	E-18-1	WASHER, THRUST, 14MM	F-2-28		
VALVE, CHECK	E-14-10-9	WASHER, THRUST, 34MM	F-10-56		

INDEX (Parts Number)

332-70201-0	F-6-8	HCO-94302-06100	E-9-21	HP08-12342-004	E-1-4	HPNA-91307-003	E-3-42
3C7-70217-0	F-6-5	HCO-94302-10160	E-5-21	HP0A-91303-A02	E-15-23	HPNA-91307-003	E-4-25
3C7-70220-1	F-6-2	HCO-94302-10160	E-6-10-51	HP0X-91321-003	E-3-47	HPN4-90009-E01	E-18-45
3C7-70224-1	F-6-3	HCO-94303-05080	E-3-52	HP13-31141-003	E-19-6	HPR3-91319-003	E-3-46
3FF-70200-4	F-6-1	HCO-94305-30203	F-10-73	HP13-31147-003	E-19-10	HPR7-31105-A01	E-19-1
3GF-70211-1	F-6-4	HCO-94510-15000	F-5-29	HP13-31148-003	E-19-12	HPR7-36361-A01	E-18-42
3GF-70240-1	F-6-7	HCO-94510-15000	F-5-1-30	HP5A-13115-000	E-7-4	HPT0-14744-004	E-9-10-15
3GF-70241-1	F-6-6	HCO-94540-03029	FOP-3-6-77	HP5A-31201-005	E-21-2	HPT0-31111-003	E-19-2
3PU-72537-0	FOP-5-1-8	HCO-94540-04029	F-2-40	HP5A-31243-005	E-21-14	HPT0-31114-013	E-19-3
3PV-72571-0	FOP-5-1-1	HCO-94540-04029	FOP-3-6-78	HP5G-16614-003	E-14-4	HPT0-31118-003	E-19-4
3PV-72637-0	FOP-5-1-4	HCO-94540-06029	F-8-10-38	HP8A-11812-A00	E-13-10-1	HPT0-31146-003	E-19-9
H121-51640-730	F-8-10-11	HCO-94540-06029	FOP-3-36	HP8A-13204-A01	E-7-5	HPT0-31147-003	E-19-11
H196-47117-000	F-8-10-10	HCO-94540-06029	FOP-3-2-41	HP8A-13321-A01	E-7-9	HPT0-31148-003	E-19-13
H341-38403-672	FOP-3-6-45	HCO-94540-06029	FOP-3-4-28	HP8A-13322-A01	E-7-7	HPT0-90005-003	E-9-13
H341-38403-672	FOP-4-20	HCO-94540-07029	FOP-3-6-79	HP8A-13323-A01	E-7-7	HPT0-90206-004	E-9-10-24
H341-38403-672	FOP-4-1-12	HCO-94540-10019	F-4-33	HP8A-13324-A01	E-7-7	HPT0-90705-000	E-9-18
H355-89217-000	F-13-11	HCO-94540-12029	F-2-41	HP8A-13325-A01	E-7-7	HPT2-91005-N01	F-5-22
H371-89221-000	F-13-7	HCO-94540-15029	F-11-49	HP8A-13326-A01	E-7-7	HPT2-91005-N01	F-5-1-22
H371-90009-015	E-6-10-25	HCO-95001-35040-40	E-14-10-20	HP8A-13341-A01	E-7-11	HPW5-90701-000	E-5-16
H663-38562-920	F-10-8	HCO-95001-35050-40	E-14-31	HP8A-13342-A01	E-7-7	HPW5-90701-000	E-6-10-42
H723-90472-000	F-4-20	HCO-95001-35055-40	E-18-10-22	HP8A-13343-A01	E-7-7	HPXK-14711-000	E-9-10-12
H759-16911-003	E-18-10-7	HCO-95001-35130-40	E-14-10-21	HP8A-13344-A01	E-7-7	HPY3-17249-000	E-15-8
H763-90681-A01	F-7-11-21	HCO-95001-35540-40	E-14-10-22	HP8A-13345-A01	E-7-7	HPY3-31215-004	E-21-4
H763-90681-A01	F-10-67	HCO-95001-35590-60	E-14-10-23	HP8A-13346-A01	E-7-7	HPY3-31218-004	E-21-6
H800-91303-000	E-6-10-45	HCO-95001-35600-40	E-14-10-24	HP8A-14400-A01	E-13-6	HPZ1-12210-004	E-9-4
H805-91301-000	E-3-10-16	HCO-95003-05035-31	E-18-2-34	HP8A-14551-A01	E-13-13	HPZ1-12211-004	E-9-6
H881-90110-000	F-10-42	HCO-95003-05060-31	E-18-10-23	HP8A-14620-A01	E-9-10-5	HR70-13210-A10	E-7-6
H921-15611-000	E-3-10-4	HCO-95005-5020030	F-10-74	HP8A-14626-A00	E-9-10-6	HRCA-14632-A00	E-9-10-9
H921-17936-000	F-2-4	HCO-95005-5095030	F-10-75	HP8A-14627-A00	E-9-10-7	HRCA-17055-A01	E-14-12
H921-90302-000	F-3-20-41	HCO-95011-63000	F-3-20-56	HP8A-14631-A00	E-9-10-7	HRCA-17065-A01	E-14-14
H921-90302-000	FOP-3-6-53	HCO-95551-20000	F-8-2	HP8A-14645-A01	E-9-10-10	HRCA-90014-A01	E-3-30
H921-90302-000	FOP-4-24	HCO-95701-06014-09	E-5-22	HP8A-15115-A01	E-3-9	HRCA-90704-A00	E-13-26
H921-90302-000	FOP-4-1-16	HCO-95701-06018-09	E-5-23	HP8A-15140-A00	E-3-10	HRDV-14610-J00	E-9-10-4
H921-90504-010	F-8-13	HCO-95701-08030-09	E-5-24	HP8A-15142-A00	E-3-11	HRDV-14631-J00	E-9-10-8
H921-90504-010	FOP-3-6-58	HCO-95701-10070-09	E-6-10-52	HP8A-15150-A00	E-3-12	HRDV-14646-J00	E-9-10-11
H921-90511-000	F-10-62	HCO-95701-12120-09	E-6-10-53	HP8A-90003-A00	E-9-10-21	HRDV-14765-J00	E-9-10-18
H921-90512-010	FOP-3-6-59	HCO-96211-07000	F-5-30	HP8A-90004-A00	E-9-10-22	HRGL-13310-A00	E-7-8
H921-90514-000	FOP-2-10	HCO-96211-07000	F-5-1-31	HP8A-90017-A01	E-13-10-8	HRGM-14781-A01	E-9-10-20
H921-90518-000	F-8-10-34	HCO-96211-12000	F-5-31	HP8A-90031-A01	E-13-23	HRJA-14721-E00	E-9-10-13
H921-90518-000	FOP-3-6-60	HCO-96211-12000	F-5-1-32	HP8A-90701-A00	E-9-17	HRJA-90017-003	E-13-21
H921-90602-000	E-18-2-28	HCO-96220-50080	E-5-25	HP8A-91301-A00	E-9-20	HRKG-91213-003	E-9-19
H921-90602-000	F-10-65	HCO-9807B-5617C	E-20-2	HP8A-91308-A01	E-3-43	HRNA-30530-A01	E-3-18
HP52-32901-770	FOP-3-6-37	HCO-98200-41000	F-7-30-9	HP8A-91309-A01	E-3-45	HRNA-37830-A01	E-14-10-12
HP52-32901-770	FOP-4-13	HCO-98200-41500	F-7-30-10	HP8D-36165-J00	E-14-10-11	HRTA-15400-A04	E-3-10-3
HP58-90428-000	F-2-29	HCO-98200-43000	F-7-30-11	HP8E-14761-A01	E-9-10-16	HS0A-91541-003	E-3-48
HCO-92101-05016-4J	FOP-3-6-68	HCO-99003-30000	F-13-8	HP8E-14762-A01	E-9-10-17	HS0A-91541-003	E-13-10-11
HCO-92101-06055-4J	F-3-34	HCO-99003-30000	F-13-13	HP8E-17105-A01	E-14-15	HS0A-91541-003	F-2-44
HCO-93500-05010-4J	FOP-3-6-69	HCO-99003-50000	F-13-3	HP8F-13211-A11	E-7-7	HS0A-91541-003	F-7-6
HCO-93500-05016-4J	E-3-49	HCO-99006-19000	F-13-12	HP8F-13212-A11	E-7-7	HS0A-91541-003	F-7-11-24
HCO-93500-05020-4J	E-3-50	HGCF-80106-670	F-8-20-3	HP8F-13213-A11	E-7-7	HS0A-91541-003	F-8-10-36
HCO-93500-05065-4J	FOP-3-34	HGHB-16163-600	E-18-2-2	HP8F-13214-A11	E-7-7	HS0X-46392-A01	F-2-21
HCO-93500-05065-4J	FOP-3-2-39	HGHB-16163-610	E-6-10-1	HP8F-13215-A11	E-7-7	HS0A-90683-003	E-18-2-32
HCO-93500-06018-4J	E-4-27	HHA0-90402-000	F-2-28	HP8F-14820-A01	E-9-7	HS0A-90683-003	E-20-11-10
HCO-93500-06025-4J	F-3-20	HHE0-50310-003	E-1-17	HP66-15233-000	E-5-10	HS0A-90683-003	F-3-20-50
HCO-93600-06016-0A	E-5-20	HHW1-90207-671	E-6-10-37	HP66-91324-000	E-5-19	HSB0-90602-003	F-11-35
HCO-93901-250J0	FOP-3-6-70	HHW1-90215-671	F-4-17	HPD1-31138-004	E-19-5	HSB2-90620-003	F-7-11-20
HCO-93901-251J0	FOP-3-6-71	HKE8-17251-690	F-8-1	HPD1-31142-004	E-19-7	HSB2-90650-003	E-14-26
HCO-93901-252J0	FOP-3-6-72	HKG4-90659-000	E-18-2-31	HPD1-31145-004	E-19-8	HSB6-91475-000	FOP-3-6-65
HCO-93903-254G0	E-15-25	HKM3-32161-003	F-10-6	HPD1-90231-014	E-19-26	HSC2-90649-003	FOP-4-25
HCO-93903-262J0	FOP-3-6-73	HKM3-32161-003	F-10-76	HPD6-90430-003	E-18-52	HSC2-90649-003	FOP-4-1-17
HCO-93905-255J0	FOP-3-6-74	HKN5-17224-670	F-2-1	HPE0-15231-000	E-5-8	HSD2-90705-931	F-2-34
HCO-93911-141J0	F-8-16	HKT7-91305-003	E-1-29	HPEA-13111-000	E-7-3	HSD4-91356-952	E-4-26
HCO-93913-141J0	F-8-17	HKY7-17450-740	E-18-10-10	HPF0-91302-003	F-2-39	HSDF-54316-013	E-1-19
HCO-94001-05490-05	FOP-3-35	HMB1-90655-921	E-18-10-20	HPG6-15232-000	E-5-9	HSDA-39794-004	F-7-30-5
HCO-94001-05490-05	FOP-3-2-40	HMG9-17201-000	E-14-10-7	HPG7-16741-005	E-14-7	HSE0-53740-953	E-1-18
HCO-94001-06080-05	E-19-27	HMG9-35701-950	F-11-3	HPGK-37835-A01	E-14-10-13	HSF4-89216-000	F-13-6
HCO-94001-06490-05	FOP-3-6-75	HMG9-35701-950	FOP-3-6-40	HPH1-90015-013	E-3-10-6	HSJ6-78419-003	E-14-18
HCO-94001-12490-05	F-10-72	HMJ0-91301-003	E-14-27	HPH3-90011-000	E-5-14	HSK7-91566-003	E-1-33
HCO-94002-05490-05	FOP-3-6-76	HMJ0-91301-003	E-18-54	HPH7-90715-000	E-3-39	HSLO-91592-A51	E-18-10-21
HCO-94002-06490-05	F-8-18	HMJ0-91308-003	F-3-32	HPJ7-12204-305	E-9-2	HSK-91540-003	FOP-12-3
HCO-94103-05400	FOP-4-26	HMJ0-91308-003	F-4-28	HPJ7-12205-305	E-9-3	HVM0-16965-771	E-18-10-9
HCO-94103-05400	FOP-4-1-18	HML0-90101-720	F-8-10-28	HPK1-91308-003	E-3-44	HZA0-90684-601	F-8-10-35
HCO-94111-05400	FOP-4-27	HMM4-90105-000	FOP-3-6-50	HPLC-91301-000	E-14-28	HZB7-90691-003	E-1-28
HCO-94111-05400	FOP-4-1-19	HMM8-90502-610	F-8-10-32	HPM3-14744-000	E-9-10-14	HZB7-90691-003	E-18-53
HCO-94301-06100	E-3-51	HMR5-16966-000	F-8-20-6	HPM3-14775-000	E-9-10-19	HZC0-63515-700	F-8-10-24
HCO-94301-06100	E-13-28	HMT2-17193-000	E-1-14	HPM3-90206-004	E-9-10-23	HZE2-90601-000	E-6-13
HCO-94301-06100	E-15-26	HMT8-18334-770	FOP-4-4	HPM4-36145-004	E-14-10-9	HZV0-41122-000	E-13-18
HCO-94301-08140	E-3-10-17	HMT8-18334-770	FOP-4-1-2	HPNA-91214-014	E-3-41	HZV0-90604-000	E-1-27
HCO-94301-10120	E-14-30	HP01-91212-003	E-5-18	HPNA-91302-003	E-14-29	HZV0-90604-000	E-18-2-29

HZV1-24210-010	F-10-4	HZV5-90009-000	E-6-8	HZW1-90115-702	F-11-31	HZW5-24831-U01	FOP-3-16
HZV1-87538-C23	F-12-14	HZV5-90009-000	F-8-10-26	HZW1-90116-702	F-11-32	HZW5-24831-U01	FOP-3-2-17
HZV4-12155-A00	E-3-4	HZV5-90012-013	E-13-20	HZW1-90203-000	F-7-11-17	HZW5-24831-U01	FOP-3-4-12
HZV4-17704-010	F-8-20-5	HZV5-90081-010	E-3-37	HZW1-90242-000	F-4-18	HZW5-24832-U01	FOP-3-17
HZV4-24221-010	F-10-5	HZV5-90081-010	E-5-15	HZW1-90301-800	F-5-14	HZW5-24832-U01	FOP-3-2-18
HZV4-36182-651	FOP-3-6-42	HZV5-90110-000	F-3-20-33	HZW1-90301-800	F-5-1-14	HZW5-24832-U01	FOP-3-4-13
HZV4-36182-651	FOP-4-16	HZV5-90119-000	F-10-44	HZW1-90304-013	F-10-50	HZW5-24834-U01	FOP-3-18
HZV4-36182-651	FOP-4-1-9	HZV5-90119-000	F-10-77	HZW1-90308-003	F-3-22	HZW5-24834-U21	FOP-3-2-19
HZV4-36187-652	FOP-3-6-43	HZV5-90119-000	F-11-33	HZW1-90401-000	E-6-12	HZW5-32168-003	E-18-56
HZV4-36187-652	FOP-4-17	HZV5-90125-000	FOP-3-6-52	HZW1-90518-800	F-4-21	HZW5-35370-U02	FOP-3-20
HZV4-36187-652	FOP-4-1-10	HZV5-90127-003	F-10-45	HZW1-90519-800	F-4-4	HZW5-35370-U02	FOP-3-2-22
HZV4-90127-000	E-6-10	HZV5-90127-003	F-11-34	HZW1-90520-800	F-4-4	HZW5-35370-U12	FOP-3-2-23
HZV4-90127-000	F-2-26	HZV5-90131-000	E-6-11	HZW1-90521-800	F-4-4	HZW5-35665-003	E-15-14
HZV4-90302-000	F-3-20	HZV5-90302-003	F-2-27	HZW1-90652-702	F-11-36	HZW5-90002-013	E-5-13
HZV4-90304-000	FOP-3-6-54	HZV5-90304-013	F-10-49	HZW1-90758-800	F-3-26	HZW5-90011-010	E-19-22
HZV4-90502-000	FOP-3-31	HZV5-90307-003	F-10-52	HZW1-90758-800	F-5-21	HZW5-90018-000	F-20-11-9
HZV4-90502-000	FOP-3-2-36	HZV5-90501-000	F-10-53	HZW1-90758-800	F-5-1-21	HZW5-90018-000	F-7-30-7
HZV4-90502-000	FOP-3-6-57	HZV5-90502-000	F-10-55	HZW1-91054-B31	F-4-25	HZW5-90021-U00	FOP-7-2
HZV4-90506-000	F-2-30	HZV5-90504-000	F-10-56	HZW1-91207-013	F-11-38	HZW5-90023-000	F-2-24
HZV4-90512-000	F-2-33	HZV5-90552-000	F-10-63	HZW1-91352-702	F-11-41	HZW5-90101-U00	FOP-3-22
HZV4-90512-000	F-10-60	HZV5-90557-000	FOP-3-6-61	HZW1-91353-703	F-11-42	HZW5-90101-U00	FOP-3-2-25
HZV4-90514-000	F-10-61	HZV5-90559-000	E-6-10-38	HZW1-91354-701	F-11-43	HZW5-90101-U00	FOP-3-4-20
HZV4-90603-000	E-6-10-40	HZV5-90559-000	F-3-23	HZW1-91355-701	F-11-44	HZW5-90102-U00	FOP-3-23
HZV4-90605-000	E-6-10-41	HZV5-90559-000	F-3-20-46	HZW1-91357-701	F-11-45	HZW5-90102-U00	FOP-3-2-26
HZV4-90605-000	E-18-2-30	HZV5-90559-000	F-5-20	HZW1-91358-701	F-11-46	HZW5-90103-U01	FOP-3-24
HZV4-90605-000	F-3-20-48	HZV5-90559-000	F-5-1-20	HZW1-91361-701	F-11-47	HZW5-90103-U01	FOP-3-2-27
HZV5-12155-000	E-4-1	HZV5-90559-000	F-10-64	HZW1-91554-000	E-18-55	HZW5-90104-U00	FOP-3-25
HZV5-12214-000	E-3-8	HZV5-90563-000	E-6-10-39	HZW1-91554-000	F-8-10-37	HZW5-90104-U00	FOP-3-2-28
HZV5-24811-010	FOP-3-6-2	HZV5-90563-000	F-3-20-47	HZW1-91557-701	F-11-48	HZW5-90105-U01	FOP-3-26
HZV5-24812-000	FOP-3-6-3	HZV5-90651-000	F-10-66	HZW2-90003-000	E-20-11-7	HZW5-90105-U01	FOP-3-2-29
HZV5-24813-000	FOP-3-6-4	HZV5-90751-000	FOP-3-6-62	HZW2-90003-000	F-7-11-12	HZW5-90106-U00	FOP-3-27
HZV5-24814-010	FOP-3-6-5	HZV5-90756-000	F-3-25	HZW4-90108-000	FOP-3-6-51	HZW5-90106-U00	FOP-3-2-30
HZV5-24815-010	FOP-3-6-6	HZV5-90756-000	F-3-20-51	HZW4-90126-000	E-1-35	HZW5-90107-U00	FOP-3-28
HZV5-24816-000	FOP-3-6-7	HZV5-90756-000	F-4-23	HZW4-90146-000	E-4-19	HZW5-90107-U00	FOP-3-2-31
HZV5-24817-000	FOP-3-6-8	HZV5-90772-000	FOP-3-6-63	HZW4-90147-000	E-3-10-14	HZW5-90108-U00	FOP-3-2-32
HZV5-24818-003	FOP-3-6-9	HZV5-91151-000	FOP-3-6-64	HZW4-90155-000	E-4-20	HZW5-90109-000	FOP-4-23
HZV5-24820-010	FOP-3-6-10	HZV5-91203-821	F-11-37	HZW4-90156-000	E-3-38	HZW5-90109-000	FOP-4-1-15
HZV5-24830-010	FOP-3-6-11	HZV5-91256-003	F-10-69	HZW4-90156-000	E-14-10-18	HZW5-90203-010	E-19-25
HZV5-24836-000	FOP-3-6-12	HZV5-91302-821	F-11-39	HZW4-90306-003	F-10-51	HZW5-90301-U00	FOP-3-29
HZV5-24841-000	FOP-3-6-13	HZV5-91316-821	F-11-40	HZW4-90401-000	FOP-3-6-55	HZW5-90301-U00	FOP-3-2-33
HZV5-24845-000	FOP-3-6-14	HZV5-91352-000	F-10-70	HZW4-90402-000	FOP-3-6-56	HZW5-90302-003	F-10-48
HZV5-24850-000	FOP-3-6-15	HZV5-91553-010	E-15-24	HZW4-91301-003	F-3-30	HZW5-90302-U21	FOP-3-2-34
HZV5-24854-000	FOP-3-6-16	HZV5-91553-010	E-20-5	HZW4-91301-003	F-3-31	HZW5-90501-U00	FOP-3-30
HZV5-24855-000	FOP-3-6-17	HZV5-91553-010	E-20-11-11	HZW5-06241-U00	FOP-3-2	HZW5-90501-U00	FOP-3-2-35
HZV5-24860-000	FOP-3-6-18	HZV5-91553-010	F-7-11-25	HZW5-06241-U10	FOP-3-2-2	HZW5-90501-U00	FOP-3-4-26
HZV5-24865-000	FOP-3-6-19	HZV5-91563-000	F-3-20-54	HZW5-06352-U01	FOP-4-3	HZW5-90502-U00	FOP-3-32
HZV5-24875-000	FOP-3-6-20	HZV5-91567-000	FOP-3-6-66	HZW5-06900-U00	FOP-7-1	HZW5-90502-U00	FOP-3-2-37
HZV5-24876-000	FOP-3-6-21	HZV5-91570-000	FOP-3-6-67	HZW5-16081-010	E-18-20	HZW5-90503-U00	FOP-3-33
HZV5-24878-000	FOP-3-6-22	HZV7-90508-000	F-2-31	HZW5-16086-000	E-18-23	HZW5-90503-U00	FOP-3-2-38
HZV5-24881-000	FOP-3-6-23	HZV7-90951-010	F-10-68	HZW5-16087-000	E-18-24	HZW5-90509-711	F-5-16
HZV5-24883-000	FOP-3-6-24	HZW1-06411-020	F-10-1	HZW5-16715-023	E-18-29	HZW5-90509-711	F-5-1-16
HZV5-24884-000	FOP-3-6-25	HZW1-15631-000	E-3-10-5	HZW5-16733-000	E-18-34	HZW5-90511-U00	FOP-7-3
HZV5-24885-000	FOP-3-6-26	HZW1-19286-800	F-3-2	HZW5-16915-000	E-18-10-8	HZW5-90512-U00	FOP-7-4
HZV5-24887-000	FOP-3-6-27	HZW1-24210-010	F-2-5	HZW5-19291-000	E-6-10-9	HZW5-90548-710	F-5-1-19
HZV5-24891-000	FOP-3-6-28	HZW1-24327-000	F-2-7	HZW5-19292-000	E-6-10-11	HZW5-90549-710	F-5-1-1
HZV5-24892-000	FOP-3-6-29	HZW1-24343-802	F-4-12	HZW5-19297-000	E-6-10-15	HZW5-90550-710	F-5-1-1
HZV5-24894-000	FOP-3-6-30	HZW1-24629-000	F-2-17	HZW5-24810-U01	FOP-3-3	HZW5-90551-710	F-5-1-1
HZV5-24895-000	FOP-3-6-31	HZW1-31226-004	E-21-7	HZW5-24810-U01	FOP-3-2-3	HZW5-90601-030	E-18-10-18
HZV5-24897-000	FOP-3-6-32	HZW1-31229-004	E-21-8	HZW5-24810-U11	FOP-3-2-4	HZW5-91201-003	E-5-17
HZV5-24898-000	FOP-3-6-33	HZW1-31231-004	E-21-9	HZW5-24811-U01	FOP-3-4	HZW5-91202-003	E-6-10-44
HZV5-32823-003	FOP-3-6-35	HZW1-36104-003	F-11-4	HZW5-24811-U01	FOP-3-2-5	HZW5-91251-003	F-2-37
HZV5-32823-003	FOP-4-11	HZW1-38551-000	F-7-11-10	HZW5-24812-U01	FOP-3-5	HZW7-24810-U01	FOP-3-4-2
HZV5-32823-003	FOP-4-1-5	HZW1-40107-700	F-11-10	HZW5-24812-U01	FOP-3-2-6	HZW7-24811-U01	FOP-3-4-3
HZV5-32824-003	FOP-3-6-36	HZW1-40209-000	F-3-20-11	HZW5-24813-U01	FOP-3-6	HZW7-24812-U01	FOP-3-4-4
HZV5-32824-003	FOP-4-12	HZW1-41102-800	F-3-5	HZW5-24813-U01	FOP-3-2-7	HZW7-24813-U01	FOP-3-4-5
HZV5-32824-003	FOP-4-1-6	HZW1-41109-800	F-3-10	HZW5-24813-U21	FOP-3-2-8	HZW7-24814-U01	FOP-3-4-6
HZV5-35370-823	FOP-3-6-39	HZW1-56110-701	F-11-15	HZW5-24814-U01	FOP-3-7	HZW7-24815-U01	FOP-3-4-7
HZV5-36136-821	F-11-9	HZW1-56113-701	F-11-16	HZW5-24814-U01	FOP-3-2-9	HZW7-24817-U01	FOP-3-4-9
HZV5-36180-033	FOP-3-6-41	HZW1-56116-701	F-11-18	HZW5-24815-U01	FOP-3-8	HZW7-24832-U01	FOP-3-4-14
HZV5-36180-033	FOP-4-15	HZW1-56130-702	F-11-22	HZW5-24816-U01	FOP-3-9	HZW7-24833-U01	FOP-3-4-15
HZV5-36180-033	FOP-4-1-8	HZW1-56180-701	F-11-24	HZW5-24816-U01	FOP-3-2-10	HZW7-32530-U00	FOP-3-19
HZV5-38410-003	FOP-3-6-46	HZW1-56539-000	F-10-33	HZW5-24816-U01	FOP-3-11	HZW7-32530-U00	FOP-3-2-20
HZV5-38410-003	FOP-4-21	HZW1-56851-703	F-11-27	HZW5-24817-U01	FOP-3-10	HZW7-32530-U10	FOP-3-2-21
HZV5-38410-003	FOP-4-1-13	HZW1-56860-701	F-11-28	HZW5-24817-U01	FOP-3-2-11	HZW7-32530-U20	FOP-3-4-16
HZV5-40102-000	E-15-16	HZW1-90013-000	E-15-17	HZW5-24818-U01	FOP-3-11	HZW7-35370-U02	FOP-3-4-17
HZV5-40107-000	F-3-20-7	HZW1-90013-000	F-7-11-13	HZW5-24818-U01	FOP-3-2-12	HZW7-87703-U00	FOP-3-4-19
HZV5-41171-000	F-10-10	HZW1-90014-000	E-18-46	HZW5-24819-U01	FOP-3-12	HZW7-90101-U01	FOP-3-4-21
HZV5-41172-000	F-10-11	HZW1-90102-000	F-10-36	HZW5-24819-U01	FOP-3-2-13	HZW7-90102-U01	FOP-3-4-22
HZV5-50214-003	F-11-12	HZW1-90106-004	E-21-21	HZW5-24825-U01	FOP-3-14	HZW7-90103-U01	FOP-3-4-23
HZV5-56117-821	F-11-19	HZW1-90107-004	E-21-22	HZW5-24825-U01	FOP-3-2-15	HZW7-90104-U01	FOP-3-4-24
HZV5-56118-820	F-11-20	HZW1-90108-000	F-10-41	HZW5-24826-U01	FOP-3-15	HZW7-90301-U01	FOP-3-4-25
HZV5-56513-000	F-11-25	HZW1-90113-702	F-11-29	HZW5-24826-U01	FOP-3-2-16	HZW7-90502-U00	FOP-3-4-27
HZV5-82873-003	F-3-20-30	HZW1-90114-702	F-11-30	HZW5-24826-U01	FOP-3-4-10	HZW9-19279-000	E-6-10-8

HZW9-19291-000	E-6-10-10	HZY1-90205-000.	F-10-47	HZY3-16011-A01	E-18-1	HZY3-18149-A01	E-6-10-4
HZW9-19297-000	E-6-10-16	HZY1-90650-003.	FOP-12-2	HZY3-16013-000.	E-18-2	HZY3-18151-A00ZA.	E-6-10-5
HZW9-32114-730	E-1-15	HZY2-14111-A00	E-9-10-1	HZY3-16015-000.	E-18-3	HZY3-18330-020.	E-6-3
HZW9-32114-730	E-3-19	HZY2-14211-A00	E-9-10-2	HZY3-16016-003.	E-15-1	HZY3-18333-003.	E-6-4
HZW9-35490-003	E-3-22	HZY2-15810-000ZA.	E-3-16	HZY3-16024-000.	E-18-5	HZY3-18340-020.	E-6-5
HZW9-87702-800	FOP-3-6-48	HZY2-15825-000.	E-3-17	HZY3-16026-000.	E-18-6	HZY3-19210-003.	F-4-1
HZW9-90005-000	F-10-34	HZY2-32100-H01	F-7-1	HZY3-16031-010.	E-18-8	HZY3-19210-003.	FOP-2-3
HZW9-90008-000	FOP-3-6-49	HZY2-34750-E01.	E-20-11-4	HZY3-16036-003.	E-18-9	HZY3-19221-010.	F-4-2
HZW9-90009-000	F-10-35	HZY2-63100-R00ZA.	F-8-3	HZY3-16041-000.	E-18-10	HZY3-19221-010.	FOP-2-4
HZW9-90011-000	E-1-20	HZY2-87121-R00	F-12-3	HZY3-16042-000.	E-18-11	HZY3-19223-000.	F-4-3
HZW9-90011-000	E-13-19	HZY2-87132-R00	F-12-6	HZY3-16061-000.	E-18-12	HZY3-19223-000.	FOP-2-5
HZW9-90011-000	F-2-22	HZY2-87133-R00	F-12-18	HZY3-16072-000.	E-18-13	HZY3-19231-000.	F-4-4
HZW9-90013-000	F-7-3	HZY3-06125-C00	F-3-1	HZY3-16073-000.	E-18-14	HZY3-19231-000.	FOP-2-6
HZW9-90013-000	F-7-11-14	HZY3-06131-000.	E-7-16	HZY3-16074-000.	E-18-15	HZY3-19234-000.	F-4-5
HZW9-90014-000	E-18-2-26	HZY3-06131-000.	E-7-	HZY3-16075-000.	E-18-16	HZY3-19234-000.	FOP-2-7
HZW9-90014-000	E-20-11-8	HZY3-06192-000.	FOP-2-1	HZY3-16076-000.	E-18-17	HZY3-19241-000.	F-4-6
HZW9-90014-000	F-7-11-15	HZY3-06193-010.	FOP-2-2	HZY3-16077-000.	E-18-18	HZY3-19251-000.	F-4-7
HZW9-90016-000	E-14-19	HZY3-06412-000.	F-10-2	HZY3-16078-000.	E-18-19	HZY3-19251-611.	F-4-
HZW9-90016-000	E-18-47	HZY3-06532-U00	F-10-3	HZY3-16082-000.	E-18-21	HZY3-19252-000.	E-6-6
HZW9-90019-000	E-1-21	HZY3-11100-415.	E-3-10-1	HZY3-16083-000.	E-18-22	HZY3-19253-000.	F-4-8
HZW9-90019-000	E-3-32	HZY3-11200-010ZA.	E-3-1	HZY3-16087-000.	E-18-25	HZY3-19253-000.	FOP-2-8
HZW9-90019-000	E-4-16	HZY3-11300-C00	E-3-2	HZY3-16088-000.	E-18-26	HZY3-19254-000.	E-6-7
HZW9-90019-000	E-14-20	HZY3-11311-010ZA.	E-6-1	HZY3-16176-000.	E-15-2	HZY3-19255-000.	E-4-6
HZW9-90101-003	F-3-11	HZY3-11381-013.	E-6-2	HZY3-16193-A00	E-18-10-1	HZY3-19256-010.	E-4-7
HZW9-90102-000	F-2-25	HZY3-11820-000.	E-13-10-2	HZY3-16196-A00	E-18-10-2	HZY3-19257-000.	E-4-8
HZW9-90102-000	F-8-10-29	HZY3-11840-010.	E-13-10-3	HZY3-16197-000.	E-18-10-3	HZY3-19258-010.	E-18-10-14
HZW9-90103-010	F-10-37	HZY3-11861-000.	E-13-10-4	HZY3-16198-A00	E-18-10-4	HZY3-19259-000.	E-18-10-15
HZW9-90105-000	F-8-10	HZY3-11871-000.	E-13-10-5	HZY3-16199-A00	E-18-10-5	HZY3-19261-000.	E-4-9
HZW9-90105-000	F-8-10-30	HZY3-11911-010.	E-3-10-2	HZY3-16203-000.	E-1-7	HZY3-19270-000.	F-3-20-1
HZW9-90105-000	F-10-40	HZY3-11911-010.	E-9-1	HZY3-16400-A01	E-15-3	HZY3-19271-000.	F-3-20-2
HZW9-90506-000	F-8-10-33	HZY3-12000-436ZA.	E-3-3	HZY3-16404-000.	E-15-4	HZY3-19272-000.	F-3-20-3
HZX1-90133-R00	F-8-12	HZY3-12155-000.	E-3-5	HZY3-16405-000.	E-15-5	HZY3-19277-000ZA.	E-6-10-6
HZX2-15655-000	E-3-53	HZY3-12164-000.	E-3-6	HZY3-16451-000.	E-14-2	HZY3-19278-000.	E-6-10-7
HZX2-16020-003	E-18-4	HZY3-12171-305.	E-3-7	HZY3-16611-A00	E-14-3	HZY3-19289-000.	F-3-20-4
HZX2-16024-003	E-18-2-1	HZY3-12210-010ZA.	E-9-5	HZY3-16620-A00	E-14-5	HZY3-19294-000ZB.	E-6-10-12
HZX2-16030-003	E-18-7	HZY3-12231-000.	E-9-7	HZY3-16708-000.	E-18-28	HZY3-19295-000.	E-6-10-13
HZX2-16700-003	E-1-9	HZY3-12241-000.	E-9-8	HZY3-16721-000.	E-18-31	HZY3-19296-000.	E-6-10-14
HZX2-16701-003	E-18-27	HZY3-12251-A01	E-9-9	HZY3-16733-000.	E-18-35	HZY3-19297-000.	E-6-10-17
HZX2-16730-003	E-18-33	HZY3-12310-405ZA.	E-1-1	HZY3-16734-000.	E-18-36	HZY3-19298-000ZB.	E-6-10-18
HZX2-16736-003	E-18-2-3	HZY3-12312-000.	E-1-2	HZY3-16735-004.	E-18-37	HZY3-19300-023.	E-4-10
HZX2-16800-003	E-18-2-6	HZY3-12320-405ZA.	E-1-3	HZY3-16740-A01	E-14-6	HZY3-19315-020ZA.	E-4-11
HZX2-16805-003	E-18-2-7	HZY3-13010-A00	E-7-1	HZY3-16751-000.	E-18-10-6	HZY3-19319-A00ZA.	E-4-12
HZX2-16814-000	E-18-2-9	HZY3-13011-A00	E-7-	HZY3-16752-000.	E-18-38	HZY3-19361-000.	E-6-10-19
HZX2-16850-C00	F-8-20-4	HZY3-13101-A00	E-7-2	HZY3-16752-A00	E-14-8	HZY3-19362-000.	E-6-10-20
HZX2-16860-C00	E-18-2-10	HZY3-13102-A00	E-7-	HZY3-16753-000.	E-18-2-4	HZY3-19366-000.	E-6-10-21
HZX2-16870-C00	E-1-34	HZY3-13331-A03	E-7-10	HZY3-16754-000.	E-18-2-5	HZY3-23170-030ZA.	E-6-10-22
HZX2-16880-C00	E-18-2-11	HZY3-13331-A04	E-7-	HZY3-16755-003.	E-14-9	HZY3-23172-003.	E-6-10-23
HZX2-16890-C00	E-18-2-12	HZY3-13331-A04	E-7-	HZY3-16757-003.	E-14-10	HZY3-23173-010.	E-6-10-24
HZX2-16900-003	E-18-2-13	HZY3-13391-000.	E-7-13	HZY3-16807-003.	E-18-2-8	HZY3-24101-A01	F-5-1
HZX2-16912-003	E-18-2-17	HZY3-13391-000.	E-7-	HZY3-16895-C00	E-1-12	HZY3-24101-A01	F-5-1-1
HZX2-16914-000	E-18-2-18	HZY3-13392-000.	E-7-14	HZY3-16904-003.	E-18-2-15	HZY3-24102-000.	F-5-2
HZX2-16940-003	E-18-2-25	HZY3-13392-000.	E-7-	HZY3-16911-010.	E-18-39	HZY3-24102-000.	F-5-1-2
HZX2-30416-000	E-20-11-1	HZY3-13398-003.	E-7-15	HZY3-16913-000.	E-18-40	HZY3-24103-000.	F-5-3
HZX2-30520-003	E-20-1	HZY3-13398-003.	E-7-	HZY3-16915-010.	E-18-2-19	HZY3-24103-000.	F-5-1-3
HZX2-32100-010	F-7-	HZY3-13621-C01	E-13-1	HZY3-16918-003.	E-18-2-21	HZY3-24113-A01	F-5-4
HZX2-32166-003	E-18-41	HZY3-13622-C00	E-13-2	HZY3-16919-003.	E-18-2-23	HZY3-24113-A01	F-5-1-4
HZX2-32410-000	F-7-11-3	HZY3-13811-A00	E-13-3	HZY3-17051-A00	E-14-11	HZY3-24122-A01	F-5-5
HZX2-32414-300	F-7-11-5	HZY3-14111-A00	E-9-10-1	HZY3-17061-A00	E-14-13	HZY3-24122-A01	F-5-1-5
HZX2-32415-000	F-7-11-7	HZY3-14211-A00	E-9-10-2	HZY3-17105-004.	E-14-10-1	HZY3-24123-000.	F-5-6
HZX2-32435-000	F-7-11-8	HZY3-14261-C00	E-13-4	HZY3-17108-000.	E-14-16	HZY3-24123-000.	F-5-1-6
HZX2-35470-013	F-2-43	HZY3-14270-C00	E-13-5	HZY3-17109-004.	E-14-10-2	HZY3-24124-310.	F-5-7
HZX2-36120-003	F-11-5	HZY3-14436-000.	E-9-10-3	HZY3-17110-003.	E-14-10-3	HZY3-24124-310.	F-5-1-7
HZX2-36129-003	F-11-8	HZY3-14510-003.	E-13-7	HZY3-17113-003.	E-14-10-4	HZY3-24221-000.	F-2-6
HZX2-38228-003	F-7-30-3	HZY3-14515-000.	E-13-8	HZY3-17130-003ZA.	E-14-10-5	HZY3-24310-C00	F-4-9
HZX2-38550-003	F-7-11-9	HZY3-14520-000.	E-13-9	HZY3-17138-004.	E-14-10-6	HZY3-24310-E00.	F-4-
HZX2-38552-000	F-7-11-11	HZY3-14526-405ZA.	E-13-10	HZY3-17203-000.	E-15-6	HZY3-24318-000.	F-4-10
HZX2-41102-E00ZC.	F-3-6	HZY3-14529-000.	E-13-11	HZY3-17207-300.	E-15-7	HZY3-24610-A00	F-2-8
HZX2-41107-C00ZC.	F-3-9	HZY3-14550-003.	E-13-12	HZY3-17372-000.	E-15-10	HZY3-24612-010.	F-2-9
HZX2-56000-013	F-11-13	HZY3-14553-003.	E-13-14	HZY3-17373-010.	E-15-11	HZY3-24613-000.	F-2-10
HZX2-63119-C00	F-8-8	HZY3-14555-003.	E-13-15	HZY3-17374-010.	E-15-12	HZY3-24617-000.	F-2-11
HZX2-63260-C00	F-8-10-23	HZY3-14820-405.	E-9-10	HZY3-17721-000.	E-18-10-11	HZY3-24618-000.	F-2-12
HZX2-63719-C00	F-3-20-23	HZY3-15100-000ZA.	E-5-1	HZY3-17723-A01	E-18-10-12	HZY3-24619-000.	F-2-13
HZX2-87117-C00	F-12-16	HZY3-15112-013.	E-5-2	HZY3-17724-010.	E-18-10-13	HZY3-24620-000.	F-2-14
HZX2-90002-000	E-19-21	HZY3-15113-000.	E-5-3	HZY3-17738-000.	F-8-20-2	HZY3-24623-000.	F-2-15
HZX2-90101-C00	F-2-42	HZY3-15121-000.	E-5-4	HZY3-17877-000.	F-2-2	HZY3-24628-000.	F-2-16
HZX2-90102-C00	F-3-20-57	HZY3-15131-405.	E-5-5	HZY3-17910-013.	E-15-13	HZY3-30280-003.	F-11-1
HZX2-90105-C00	F-4-16	HZY3-15132-405.	E-5-6	HZY3-17931-000.	F-2-3	HZY3-31106-003.	F-11-2
HZX2-90107-C00	F-3-35	HZY3-15220-020.	E-5-7	HZY3-18110-010ZA.	E-4-2	HZY3-31110-000ZA.	E-5-11
HZX2-90129-000	F-10-46	HZY3-15425-010.	E-1-5	HZY3-18115-003.	E-4-3	HZY3-31116-000.	E-5-12
HZX2-90502-003	F-8-10-39	HZY3-15656-000.	E-3-14	HZY3-18120-C01ZA.	E-4-4	HZY3-31200-003.	E-21-1
HZX2-90683-003	E-18-2-33	HZY3-15657-000.	E-3-15	HZY3-18125-003.	E-4-5	HZY3-31207-003.	E-21-3
HZX2-90683-003	F-7-11-22	HZY3-15810-003ZA.	E-3-	HZY3-18141-A00ZA.	E-6-10-2	HZY3-31216-003.	E-21-5
HZY1-90205-000.	F-3-19	HZY3-15825-003.	E-3-	HZY3-18148-003.	E-6-10-3	HZY3-31235-003.	E-21-10

HZY3-31236-003.	E-21-11	HZY3-41202-700.	F-5-1-12	HZY3-90006-003.	E-3-27	HZY3-90503-610.	F-3-20-43
HZY3-31240-003.	E-21-12	HZY3-50100-A01	F-10-13	HZY3-90007-000.	E-13-10-7	HZY3-90504-A00	F-10-57
HZY3-31242-003.	E-21-13	HZY3-50100-A11	F-10-	HZY3-90008-003.	E-3-28	HZY3-90506-000.	F-5-15
HZY3-31246-003.	E-21-15	HZY3-50109-000.	F-10-14	HZY3-90009-003.	E-3-29	HZY3-90506-000.	F-5-1-15
HZY3-31247-003.	E-21-16	HZY3-50111-020.	F-3-20-16	HZY3-90010-000.	E-6-10-26	HZY3-90507-000.	F-8-14
HZY3-31249-003.	E-21-17	HZY3-50151-000.	F-10-15	HZY3-90011-000.	E-6-10-27	HZY3-90508-000.	E-15-22
HZY3-31250-003.	E-21-18	HZY3-50153-000.	F-10-16	HZY3-90013-000.	E-6-10-28	HZY3-90508-000.	F-2-32
HZY3-31630-003.	E-19-14	HZY3-50155-000.	F-3-20-17	HZY3-90015-000.	E-6-10-29	HZY3-90509-000.	F-10-58
HZY3-31631-003.	E-19-15	HZY3-50157-010.	F-3-20-18	HZY3-90017-000.	E-3-31	HZY3-90510-000.	F-10-59
HZY3-31637-000.	E-19-16	HZY3-50161-000ZD.	F-10-17	HZY3-90017-000.	E-18-48	HZY3-90511-000.	F-3-20-44
HZY3-31638-003.	E-13-16	HZY3-50161-610.	F-10-	HZY3-90017-000.	E-19-23	HZY3-90512-000.	F-5-17
HZY3-31639-003.	E-19-17	HZY3-50166-000.	F-10-18	HZY3-90017-000.	F-2-23	HZY3-90512-000.	F-5-1-17
HZY3-31694-003.	E-19-18	HZY3-50168-000.	F-10-19	HZY3-90018-000.	E-13-10-9	HZY3-90528-000.	F-5-18
HZY3-31710-003.	E-19-19	HZY3-50201-C01ZD.	F-10-20	HZY3-90021-000.	E-3-33	HZY3-90528-000.	F-5-1-18
HZY3-31750-003.	E-19-20	HZY3-50201-C11ZC.	F-10-	HZY3-90021-000.	E-14-21	HZY3-90529-000.	F-5-
HZY3-32111-010.	E-13-17	HZY3-50209-A00	F-10-21	HZY3-90021-000.	E-18-49	HZY3-90529-000.	F-5-1-
HZY3-32112-000.	E-14-17	HZY3-50211-000.	F-10-22	HZY3-90021-000.	F-8-10-27	HZY3-90530-000.	F-5-
HZY3-32116-000.	E-3-20	HZY3-50214-000.	F-10-23	HZY3-90023-000.	E-14-10-14	HZY3-90530-000.	F-5-1-
HZY3-32128-000.	E-14-10-8	HZY3-50301-030ZC.	F-10-24	HZY3-90026-000.	E-3-10-7	HZY3-90531-000.	F-5-
HZY3-32129-000.	E-1-16	HZY3-50311-020ZC.	F-10-25	HZY3-90026-000.	E-9-14	HZY3-90531-000.	F-5-1-
HZY3-32193-C00	E-3-21	HZY3-50381-000.	F-10-26	HZY3-90027-000.	E-4-17	HZY3-90548-000.	F-5-19
HZY3-32370-H01	F-7-30-1	HZY3-50388-U00	FOP-9-1	HZY3-90028-000.	E-3-34	HZY3-90549-000.	F-5-
HZY3-32371-H01	F-7-30-2	HZY3-50388-U10	FOP-9-2	HZY3-90029-000.	E-14-10-15	HZY3-90550-000.	F-5-
HZY3-32411-003.	F-7-11-4	HZY3-50522-000.	F-10-27	HZY3-90030-000.	E-3-35	HZY3-90551-000.	F-5-
HZY3-32419-A00	F-8-10-1	HZY3-50527-000.	F-10-28	HZY3-90030-000.	E-3-10-8	HZY3-90552-000.	F-5-
HZY3-32421-000.	F-8-10-2	HZY3-50529-000.	F-10-29	HZY3-90030-000.	E-6-10-30	HZY3-90553-000.	F-5-
HZY3-34750-E01.	E-20-11	HZY3-56100-013.	F-11-14	HZY3-90030-000.	E-13-22	HZY3-90554-000.	F-5-
HZY3-34754-C00	E-20-11-5	HZY3-56120-013.	F-11-21	HZY3-90030-000.	E-15-19	HZY3-90555-000.	F-5-
HZY3-35476-010.	F-2-19	HZY3-56170-013.	F-11-23	HZY3-90031-000.	E-3-10-9	HZY3-90556-000.	F-5-
HZY3-35477-000.	F-2-20	HZY3-56516-A00	F-10-30	HZY3-90031-000.	E-6-10-31	HZY3-90557-000.	F-5-
HZY3-35490-004.	E-3-23	HZY3-56518-A00	F-10-31	HZY3-90031-000.	E-14-10-16	HZY3-90558-000.	F-5-
HZY3-35640-013.	F-3-20-5	HZY3-56519-A00	F-10-32	HZY3-90034-000.	E-4-18	HZY3-90559-000.	F-5-
HZY3-35645-000.	F-3-20-6	HZY3-56532-000.	F-11-26	HZY3-90034-000.	E-15-20	HZY3-90560-000.	F-5-
HZY3-35655-C01	E-4-13	HZY3-58130-T00.	FOP-10-1	HZY3-90035-000.	E-9-15	HZY3-90601-030.	E-4-21
HZY3-35660-003.	F-10-7	HZY3-58130-T10.	FOP-10-	HZY3-90036-000.	E-1-22	HZY3-90601-030.	E-18-10-19
HZY3-35673-003.	E-3-24	HZY3-58130-T20.	FOP-10-	HZY3-90037-000.	E-15-21	HZY3-90602-020.	E-1-25
HZY3-35673-003.	E-4-14	HZY3-58130-T30.	FOP-10-	HZY3-90038-000.	E-3-36	HZY3-90603-020.	E-4-22
HZY3-35695-003.	E-13-10-6	HZY3-58130-T40.	FOP-10-	HZY3-90039-000.	E-13-24	HZY3-90604-020.	E-4-23
HZY3-35700-003.	E-3-25	HZY3-58130-T50.	FOP-10-	HZY3-90040-000.	E-13-25	HZY3-90652-000.	F-3-20-49
HZY3-36122-013.	F-11-6	HZY3-58130-V01ZA.	FOP-10-	HZY3-90041-000.	E-3-10-10	HZY3-90653-003.	F-7-4
HZY3-36123-013.	F-11-7	HZY3-58130-V11ZA.	FOP-10-	HZY3-90042-000.	E-14-22	HZY3-90741-000.	E-13-27
HZY3-36163-003.	E-14-10-10	HZY3-58130-V21ZA.	FOP-10-	HZY3-90043-000.	E-14-23	HZY3-90751-000.	F-2-35
HZY3-36362-000.	E-18-43	HZY3-58130-V31ZA.	FOP-10-	HZY3-90044-000.	E-14-24	HZY3-90752-003.	F-4-22
HZY3-36550-003.	E-15-15	HZY3-58130-V41ZA.	FOP-10-	HZY3-90045-000.	E-6-10-32	HZY3-90752-003.	FOP-2-11
HZY3-36620-000.	E-18-44	HZY3-58130-V51ZA.	FOP-10-	HZY3-90046-000.	E-6-10-33	HZY3-91001-003.	E-6-10-43
HZY3-40105-C01	F-8-10-3	HZY3-58180-T00.	FOP-10-	HZY3-90047-000.	E-6-10-34	HZY3-91051-003.	F-5-23
HZY3-40114-010.	F-3-20-8	HZY3-58180-T10.	FOP-10-	HZY3-90049-000.	E-6-10-35	HZY3-91051-003.	F-5-1-23
HZY3-40119-003.	F-8-10-4	HZY3-58180-T20.	FOP-10-	HZY3-90050-000.	E-18-50	HZY3-91053-003.	F-4-24
HZY3-40151-000ZC.	F-3-20-9	HZY3-58180-T30.	FOP-10-	HZY3-90053-010.	E-6-9	HZY3-91055-003.	F-5-24
HZY3-40154-000ZA.	F-8-10-5	HZY3-58180-T40.	FOP-10-	HZY3-90054-000.	E-18-57	HZY3-91055-003.	F-5-1-24
HZY3-40155-000.	F-8-10-6	HZY3-60180-C01	F-8-10-12	HZY3-90055-000.	E-19-24	HZY3-91056-711.	F-5-1-25
HZY3-40157-000.	F-8-10-7	HZY3-60185-C01	F-8-10-13	HZY3-90056-000.	E-18-2-27	HZY3-91057-003.	F-5-25
HZY3-40158-000.	F-8-10-8	HZY3-63102-010.	F-8-4	HZY3-90058-000.	E-14-10-17	HZY3-91057-003.	F-5-1-26
HZY3-40159-000.	F-8-10-9	HZY3-63107-000.	F-8-5	HZY3-90059-000.	E-6-10-36	HZY3-91151-000.	F-5-26
HZY3-40201-020ZC.	F-3-20-10	HZY3-63108-000.	F-8-6	HZY3-90063-000.	E-3-10-11	HZY3-91151-000.	F-5-1-27
HZY3-40201-612ZC.	F-3-20-	HZY3-63111-310ZD.	F-8-7	HZY3-90082-003.	E-3-10-12	HZY3-91152-003.	F-2-36
HZY3-40204-000.	F-4-13	HZY3-63143-H00	F-8-9	HZY3-90102-A00	F-3-20-31	HZY3-91212-003.	E-3-40
HZY3-40210-610.	F-3-20-12	HZY3-63201-000ZC.	F-8-10-14	HZY3-90104-010.	F-10-39	HZY3-91251-C01	F-3-27
HZY3-40212-010ZC.	F-3-20-13	HZY3-63205-000.	F-8-10-15	HZY3-90105-010.	F-3-20-32	HZY3-91251-C01	F-4-26
HZY3-40212-611ZC.	F-3-20-	HZY3-63208-000.	F-8-10-16	HZY3-90106-A00	F-8-10-31	HZY3-91254-003.	F-3-29
HZY3-40219-013.	F-10-9	HZY3-63212-000.	F-8-10-17	HZY3-90107-000.	F-7-11-16	HZY3-91254-003.	F-4-27
HZY3-40219-013.	F-11-11	HZY3-63223-000.	F-8-10-18	HZY3-90109-010.	F-8-11	HZY3-91255-003.	F-2-38
HZY3-40225-010.	F-3-20-14	HZY3-63224-000.	F-8-10-19	HZY3-90111-000.	F-3-20-34	HZY3-91301-003.	E-4-24
HZY3-40226-010.	F-3-20-15	HZY3-63225-000.	F-8-10-20	HZY3-90113-C00	F-3-20-36	HZY3-91303-000.	E-21-23
HZY3-41100-C03ZC.	F-3-10-1	HZY3-63226-000.	F-8-10-21	HZY3-90116-000.	FOP-2-9	HZY3-91304-000.	E-6-10-46
HZY3-41100-C13ZC.	F-3-10-	HZY3-63230-C00	F-8-10-22	HZY3-90117-000.	F-10-43	HZY3-91305-003.	E-6-10-47
HZY3-41100-E03ZC.	F-3-10-	HZY3-63347-C00	F-3-20-19	HZY3-90120-000.	F-3-14	HZY3-91306-003.	E-6-10-48
HZY3-41101-C00ZC.	F-3-4	HZY3-63710-C00ZC.	F-3-20-20	HZY3-90122-000.	F-3-20-37	HZY3-91351-C00	F-3-33
HZY3-41104-C01	F-3-7	HZY3-63715-C01ZC.	F-3-20-21	HZY3-90123-000.	F-5-13	HZY3-91351-C00	F-5-28
HZY3-41105-C01	F-3-8	HZY3-63718-000.	F-3-20-22	HZY3-90123-000.	F-5-1-13	HZY3-91351-C00	F-5-1-29
HZY3-41112-010.	F-4-14	HZY3-63722-010ZC.	F-3-20-24	HZY3-90124-000.	F-3-15	HZY3-91356-003.	F-4-29
HZY3-41112-611.	F-4-	HZY3-63728-000.	F-3-20-25	HZY3-90129-A00	F-3-20-38	HZY3-91356-003.	FOP-2-12
HZY3-41116-000.	F-4-15	HZY3-63729-003.	F-8-10-25	HZY3-90132-000.	F-3-20-39	HZY3-91358-003.	F-4-30
HZY3-41130-C00	F-5-8	HZY3-63731-A03ZC.	F-3-20-26	HZY3-90134-000.	F-3-20-40	HZY3-91358-003.	FOP-2-13
HZY3-41130-E00.	F-5-1-8	HZY3-63731-A12ZC.	F-3-20-	HZY3-90204-000.	E-3-10-15	HZY3-91359-003.	F-4-31
HZY3-41150-E00.	F-5-1-9	HZY3-63736-A03ZC.	F-3-20-27	HZY3-90205-000.	E-14-25	HZY3-91359-003.	FOP-2-14
HZY3-41151-C00	F-5-9	HZY3-63736-A12ZC.	F-3-20-	HZY3-90205-000.	E-14-10-19	HZY3-91401-A00	E-1-30
HZY3-41161-A00	F-5-10	HZY3-63751-C00	F-3-20-28	HZY3-90302-000.	F-3-20-42	HZY3-91402-020.	E-1-31
HZY3-41161-B00	F-5-1-10	HZY3-63756-C00	F-3-20-29	HZY3-90303-000.	F-4-19	HZY3-91403-000.	E-1-32
HZY3-41179-A00	F-10-12	HZY3-87121-R00	F-12-4	HZY3-90304-000.	F-7-11-18	HZY3-91404-000.	E-6-10-49
HZY3-41201-C00ZC.	F-5-11	HZY3-90001-000.	E-3-26	HZY3-90405-000.	F-7-11-19	HZY3-91405-000.	E-6-10-50
HZY3-41201-C00ZC.	F-5-1-11	HZY3-90002-000.	E-21-19	HZY3-90406-000.	E-1-23	HZY3-91451-000.	F-3-20-52
HZY3-41202-000.	F-5-12	HZY3-90003-000.	E-21-20	HZY3-90501-A00	F-10-54	HZY3-91508-000.	E-13-10-10

HZY3-91551-000.F-4-32
 HZY3-91551-000.FOP-2-15
 HZY3-91552-000.F-3-20-53
 HZY3-91556-000.F-8-15
 HZY3-91560-000.F-10-71
 HZY3-91651-003.F-3-20-55
 HZY6-16450-003.E-14-1
 HZY6-16718-013.E-18-30
 HZY6-16723-003.E-18-32
 HZY6-19269-000.E-18-10-16
 HZY6-24320-000.F-4-11
 HZY6-24320-610.F-4-
 HZY6-32414-640.F-7-11-6
 HZY6-36135-003.E-18-10-17
 HZY6-38235-004.F-7-30-4
 HZY6-39794-003.F-7-30-6
 HZY6-90103-000.F-3-13
 HZY6-90103-000.F-10-38
 HZY6-90135-004.F-7-30-8
 HZY6-91553-000.F-3-20-
 HZY9-17315-000.E-15-9
 HZY9-30419-003.E-20-4
 HZY9-30419-003.E-20-11-2
 HZY9-30419-003.F-7-11-1
 HZY9-32103-000.F-7-11-2
 HZY9-38553-003.E-20-11-6
 HZY9-56115-003.F-11-17
 HZY9-90017-000.E-15-18
 HZY9-90105-000.E-20-3
 HZZ0-90101-000.F-3-12
 HZZ3-06240-R30FOP-3-1
 HZZ3-06240-R40FOP-3-4-1
 HZZ3-06240-R60FOP-3-2-1
 HZZ3-06323-R20FOP-4-1
 HZZ3-06323-R30FOP-4-1-1
 HZZ3-06328-762.FOP-12-1
 HZZ3-24800-R00FOP-3-6-1
 HZZ3-24820-R11FOP-3-13
 HZZ3-24820-R21FOP-3-2-14
 HZZ3-24830-R41FOP-3-4-11
 HZZ3-32101-000.E-20-11-3
 HZZ3-32127-000.F-7-2
 HZZ3-32341-R31FOP-4-6
 HZZ3-32346-R21FOP-4-7
 HZZ3-32346-R31FOP-4-1-3
 HZZ3-32347-R01FOP-4-8
 HZZ3-35100-R11FOP-3-6-38
 HZZ3-35100-R11FOP-4-14
 HZZ3-35100-R11FOP-4-1-7
 HZZ3-37205-R01FOP-4-18
 HZZ3-87301-R00F-12-19
 HZZ3-87701-R00FOP-3-6-47
 HZZ3-87701-R40FOP-3-4-18
 HZZ3-87703-R01FOP-3-2-24
 HZZ3-87703-R81FOP-3-21
 HZZ3-91252-003.F-3-28
 HZZ3-91252-003.F-5-27
 HZZ3-91252-003.F-5-1-28
 HZZ5-06325-600.FOP-4-2
 HZZ5-06325-700.FOP-4-
 HZZ5-06325-800.FOP-4-
 HZZ5-16901-003.E-18-2-14
 HZZ5-16906-003.E-18-2-16
 HZZ5-16915-000.E-18-2-20
 HZZ5-16918-003.E-18-2-22
 HZZ5-16919-003.E-18-2-24
 HZZ5-32185-600.FOP-4-5
 HZZ5-32185-700.FOP-4-
 HZZ5-32185-800.FOP-4-
 HZZ5-32530-000.FOP-3-6-34
 HZZ5-32545-000.FOP-4-9
 HZZ5-32545-000.FOP-4-1-4
 HZZ5-32580-600.FOP-4-10
 HZZ5-32580-700.FOP-4-
 HZZ5-32580-800.FOP-4-
 HZZ5-37210-013.FOP-3-6-44
 HZZ5-37210-712.FOP-4-1-11
 HZZ5-37210-762.FOP-4-19
 HZZ5-38414-003.FOP-4-22
 HZZ5-38414-003.FOP-4-1-14
 HZZ5-91501-000.F-7-11-23

TOHATSU CORPORATION

**Address : 5-4,3-chome,Azusawa,Itabashi-ku,
TOKYO,174-0051 JAPAN**

Phone : TOKYO (03)3966-3117

FAX : TOKYO (03)3966-0090

Website : www.tohatsu.co.jp

**2015
PARTS CATALOG**

**BFT 200A
BFT 225A**